A4881

12855

THOS W

INSTRUCTION FOR SERVICING AND OPERATION OF PHYMOUTH MODEL HSG LOCGMOTIVE POWERED WITH INTURNATIONAL HARVESTER U263 ENGINE, SUNDSTRAND PUMP AND STAFFA MOTOR.

#### FOREWORD

Plymouth Locomotives are easy to operate and service, but it is desirable that the operator be familiar with the construction, function and care of the various parts of the locomotive.

The engine and accessory bulletins and these operating instructions should be carefully read. A study of the assembly prints furnished with each locomotive will give a clear conception of the machine.

## INSTRUCTIONS FOR ORDERING REPAIRS

Always give serial number, model and gauge of locomotive. This information will be found on the name plate. The serial number and model of the engine or accessories should also be given in connection with the above when parts for these are wanted. The engine and accessories are covered by separate bulletins. The locomotive parts, other than the engine and accessories are shown on assembly prints included with the parts lists. These prints give the symbol numbers, and by referring to the parts list the name and quantities used can be determined.

Always specify method of shipment of your order. If none is given we will use our best judgment and ship the cheapest way. Your careful attention and adherence to the above instructions will assist us in giving you prompt and correct service.

We carry a large stock of repairs at our factory in Plymouth, Ohio, to insure our customers of prompt service.

Your locomotive includes hydrostatic drive components and it was designed with you in mind. Ease of operation, maintenance, adjustment and repair was major design consideration.

Operators, maintenance men and repair men should study these instructions and the other books and instructions furnished before operating or servicing the locomotive.

# GENERAL INSTRUCTIONS

The general construction is simple. A variable displacement hydraulic pump is driven by the engine to produce a variable flow of hydraulic fluid under pressure. This flow is conducted through flexible high pressure hose to a hydraulic motor, the output speed of which is in direct ratio to the flow, and the output torque in direct ratio to the pressure. The direction of rotation of the output shaft is determined by the position of control lever on the pump.

The hydraulic motor is connected to a drive shaft which drives both axles by means of sprockets and chains.

The rate of speed is regulated by the volumn control of the pump; therefore, only a throttle and pump control lever are required for full operation of your locomotive. Service braking is accomplished hydrostatically. Therefore, only a parking or emergency brake is required.

The recommended method of operation is to set throttle at an engine speed suitable for the work to be done and then use pump control lever for all control operations, pushing the lever forward for a forward motion and pulling backward for a backward motion. This lever is spring loaded to return to neutral from any position and should be operated. Slowly and steadily to get smooth acceleration and deceleration. The operators will soon become adept at the manipulation of this control.

INSTRUCTIONS FOR SERVICING AND OPERATION OF PLYMOUTH MODEL HEG LOCONOTIVE

The lever on the pump does not directly control the displacement. It presets a hydraulic valve which in turn controls the fluid flow to hy-NOTE:

draulic cylinders which are built into the pump to control displacement. and direction of flow. There is a time lag between movement of lever and actual change of displacement. This time lag provides smooth acceleration and smooth hydrostatic braking.

For very slow locomotive speeds a throttle setting of approximately 1/2 is permissible. A higher engine speed will provide for a higher max. locomotive speed. A high engine speed is recommended when heavy train loads are to be handled even though a high locomotive speed is not desired.

The maximum train load that can be handled at high speed is limited by the power of the engine. It is possible to overload the engine and stall it if an attempt is made to accelerate an excessive train load to a high speed, or to accelerate too fast. The operator will soon learn to sense when the engine is being lugged and he will ease the control handle toward neutral to relieve the load on the engine.

There is a neutral position stop on the pump control hand lever quadrant. To pass this stop going from forward to reverse, or reverse to forward, it is necessary to move handle to the left or right, then forward or backward past stop. If the hand lever is not restrained it will be returned to neutral by the return spring. is a "Dead Man" feature.

### BRAKING

For normal service braking, it is only necessary to move the pump control lever toward neutral position until the desired amount of braking is obtained. Do not move control lever all the way to neutral until locomotive is nearly stopped because wheel rotation is stopped when lever is moved to neutral.

Do not use engine throttle to decelerate locomotive. Always use the pump control. This is important because it is necessary to maintain engine speed to prevent cavitation in the motor.

#### WARNING

Although it is possible to "plug" the controls by moving the control lever past the neutral position before the locomotive has come to a stop this practice is not recommended and the operator is warned that under certain conditions the engine may be stalled and rotated backwards which would result in damage to the hydrostatic components and the engine. If engine is stalled with pump in stroke the pump may not return to no stroke (neutral) and it may be necessary to activate the by-passing device per instructions under "Towing the Locomotive" to allow the engine to be started without building up pressure in the hydrostatic system.

#### PARKING BRAKE

The parking brake hand wheel is located to the right of the operator.

This parking brake should always be applied when the locomotive is left unattended. especially if it is parked on a grade with the engine stopped.

Your hydrostatic transmission is an effective parking brake when the engine is running and the charge pump can maintain the volumn of trapped fluid in the system. However, when the charge pump is not running normal internal leakage can, in time, result in

5-1-03 Signal 2 40 7 H . J . . .

INSTRUCTIONS FOR SERVICING AND OPERATION OF PLYMOUTH MODEL HSG LOCOMOTIVE

loss of fluid from the motor cylinders, if the locomotive is parked on a grade.

#### ENGINE

Your engine is an International Marvester Model U263. Study the instruction manuals carefully. It explains the operation and servicing of engine.

## INSTRUMENT PANEL

There are three gauges on the instrument panel which indicate the operating condition of the engine. They are engine oil pressure gauge, engine temperature gauge, and ammeter.

Other items on the panel are:

BATTERY SWITCH: This has two labeled positions and must be on to energize the electrical circuits. It should be turned off. if the locomotive is left unattended.

KEY SWITCH and STARTER: This switch has four positions. Left energizes the accessory circuits with ignition off. Vertical is off. Right energizes the accessory circuits with ignition on. Extreme Right against the spring energizes the starter.

ENGINE CHOKE CONTROL.

FRONT LIGHTS SWITCH: Pull out one notch for dim, all the way out for bright.

REAR LIGHTS SWITCH: Pull out one notch for dim, all the way out for bright.

FRONT DEFROSTER FAN SWITCH: Pull out to operate fan.

REAR DEFROSTER FAN SWITCH: Pull out to operate fan.

MEATER: The heater fan switch has four positions: Knob in is off, knob out one notch is slow, knob out two notches medium, knob out three notches is fast.

MANUAL RESET CIRCUIT BREAKERS at top of panel are labeled ACC .- ENG .- LIGHTS .\_ To reset breaker the red button should be depressed and immediately released. If overload or short circuit is not corrected, holding button depressed will burn out broaker.

The ACC. breaker protects the fans, window wipers and heater circuits.

The ENG, breaker protects the ignition system, fuel gauge, engine oil pressure gauge, water temperature gauge and ammeter.

The LIGHTS breaker protects all the light circuits and the trouble light socket under the left side of the hood on the fire wall.

The hydraulic temperature, charge pressure and filter gauges are explained in the hydrostatic system portion of these instructions.

# HYDROSTATIC SYSTEM

The controls of the hydrostatic system are covered under general instructions elsewhere in these sheets.

Specific instructions for servicing the separate components are given in the manufacturers bulletins furnished. These instructions should be studied carefully to learn the function of, and the proper service procedure, for each separate component...

A 80.

INSTRUCTIONS FOR SERVICING AND OPELATION OF PLYMOUTH MODEL HSG LOC MOTIVE

There are three gauges on the instrument panel which indicate the operating condition of the hydrostatic components. They are charge pressure gauge, fluid temperature gauge and filter condition indicator. The charge pressure should read at least 100 P.S.I. with engine running at idle speed and 180-220 P.S.I. with engine speed of 1000 R.P.M. or higher. The charge pressure should always be observed each time the engine is started and if the pressure is less than 100 P.S.I. the engine should be stopped immediately and the system checked using Sunstrand Bulletin #9454 as a trouble shooting guide.

The fluid temperature should never be allowed to exceed 180° F. under continuous operations. A maximum of 200° F. for very short periods of time (five minutes or less) is acceptable.

There is an oil cooler provided in the system to cool the fluid and it would be under the most adverse operating condition only that a high fluid temperature should be experienced; however, as an added safety measure a temperature switch is provided to blow the locomotive horn as a warning if the temperature reaches 200° F.

In the event that the temperature reaches 2000 F. it is suggested that the control handle be moved toward neutral <u>BUT NOT INTO NEUTRAL</u> and that the engine be operated, at approximately 1/2 throttle. This will keep the fluid circulating in the system 'and, allow it to be cooled while the load is reduced.

If the fluid filter condition indicator nears the red lined portion of the gauge when the fluid is warm this is warning that the filter element needs changing. Use only genuine replacement element providing 10 micron filtration.

The reservoir was filled at the factory with approximately 14 gal. of Mobile #300 hydraulic fluid.

NOTE: This fluid was used by Plymouth Locomotive Works for the initial fill because it was recommended as a suitable fluid for this application and because of its wide distribution. There are other fluids on the market which are also suitable.

The proper level of the fluid in the reservoir is approximately l" below the top (inside) and is level with the top of the baffle visible through the fill pipe. The filler cap contains an air filter to keep particulate matter out of the reservoir as it breathes due to varying fluid temperature. Keep cover over filler cap closed to protect cap from weather and dirt.

The fluid filter is located near the left rear corner of the reservoir and there is a shut off valve in the piping between the filter housing and the reservoir. This valve may be closed when changing filter elements to prevent excessive loss of fluid, but it MUST BE OPENED before attempting to start engine.

For long hydrostatic component life it is absolutely necessary that the fluid be kept clean; therefore, be very careful not to allow any contaminant to enter the system when changing filter element.

#### CHAIN DRIVE COMPONENTS

The final drive shaft is driven by the hydraulic motor which has a splined output shaft which fits an internal spline in the end of the final drive shaft. This is a greased spline engagement since it is in the same housing as the large heavy duty bearing carrying the shaft. This bearing housing and the bearing housing on the other end of

27. 3. 3. 3. 3-23-63 377, 77. 4. 61

INSTRUCTIONS FOR SERVICING AND OFFRATION OF PLYMOUTH MODEL HEG LCCCHOTIVE

the shaft were filled at the factory to the proper level with Mebilplex EP \$1 bearing lubricant. Check this lubricant yearly in the following manner. ( 10 10 )

For the large bearing nearest the motor there are two 1/8" pipe plugs, one on the front side of the housing and one on the rear. After carefully tleaning the exterior of the housing remove both pipe plugs and install a grease fitting in port on front of housing Pump Mobilplex EP #1 grease through this fitting until it comes out of the rear port. Use the same procedure for the other housing, pumping grease through the lowest port until it comes out the highest port. All pipe plugs should be reinstalled. Do not leave grease fitting installed.

The axic drive chains are lubricated by means of chain oilers. These oilers should be kept filled with oil and the flow adjusted so the chains show a liberal coating of oil at all times.

The chains were adjusted for proper tension at the factory but they should be checked frequently and not allowed to become excessively loose.

Chain tightness adjustment is made by moving the axles and this is done by means of the adjusting screws located at each axle boxing location. The proper adjustment is when the chain has a total up and down movement of approximately 1" to 1 1/2" measured in the center of the span. If top and bottom span of chain are both loose add the movement of each to obtain this measurement. Care should be taken to keep the axles parallel with each other and at 90° to center line of chains. Allow 1/64 clearance between each slide and axle bearing boxing. The clearance between ears on each axle bearing boxing and slides should be approximately 3/32 to provide 3/16 total end motion of axle. As wear occurs add shims between slides and frame to obtain this correct clearance.

## RADIATOR SHUTTERS

The control for the radiator shutters is mounted on the angle between the cab front sheet and the control stand. The shutters are held in an open position by springs. To close shutters turn the knob in a clockwise direction.

#### SANDERS

The sander operating handles located below the instrument panel.

To apply sand while moving in a forward direction pull the handle toward the operator and latch in either the first or second notch depending upon amount of sand desired. Move the handle toward the front of cab to apply sand when moving backward. The center notch of the bar is the off position.

## EMERGENCY FUEL SHUTOFF

The handles are located at the outside front corners of the cab. A quick pull on cither handle will move the lever off of the plunger on the spring loaded fuel shutoff valve causing it to close.

To reset, the valve move the lever over the valve plunger.

#### HAND THROTTLE

The hand throttle located on the left side of the control stand will hold the engine throttle at any desired position by meens of iriction discs. The amount of friction

1083×

lágax "

INSTRUCTIONS FOR SURVICING AND OPERATION OF PLYNOUTH MODEL HSD LOCOMOTIVE

can be varied by an adjusting nut on the underside of the hand throatle.

### WINDOW WIPERS

Each window wiper is individually controlled by the switch on the wiper.

#### BATTERY

Check water level every two weeks and keep filled to approximately 3/8" above plates with clean distilled water. Do not over fill.

Check the specific gravity occasionally. It should read 1.250 or higher for a fully charged battery.

# TOWING THE LOCOMOTIVE

If the locomotive must be towed with a dead engine for any reason the following instructions must be followed:

The hydrostatic system includes a device to unseat a high pressure relief valve, thus creating an effective bypass route for the hydraulic fluid, allowing it to bypass the pump when the locomotive is being towed and the motor is acting as a pump. This device is located near and to the right of the motor on the right side of the high pressure relief valve block. It will be recognized as a screw in the end of a round pressure relief valve block. For normal operap on the end of a hex. projection on side of relief valve block. For normal operap on the screw is backed out of round cap until it contacts stop and locked with locknut. To tow locomotive be sure parking brake is applied, back off locknut to head and screw in the screw until it contacts stop.

The locomotive can now be towed or pushed very slowly, after releasing brake.

### WARNING

When moving the locomotive in this manner there is no charge pressure and no cooling of the fluid; therefore, it is extremely important that the rate of movement be very slow, (no faster than one to one and one-half M. P. H.) A higher speed may cause cavitation in the motor and an excessive build up of heat in the fluid. Every few hundred feet, stop and check fluid temperature by feeling the relief valve block. If it is unconfortably warm, let it cool before proceeding.

To tow locomotive at a higher rate of speed or for a long distance it is suggested that the drive chains be removed.

- 1 3 - 10 20

OHUX "

INSTRUCTIONS FOR SERVICING AND OPERATION OF PLYMOUTH MODEL HSD LOCGMOTIVE

# THINGS TO DO EACH DAY

Check warer in radiator. Check engine lubricating oil. Check all fluid lines for leaks. Check tension of belts. Check tension of chains. Check level of hydraulic fluid in reservoir. Oil axle boxing slides. Fill chain oilers.

#### GENERAL CARE

After a new locomotive has been in service a week or so, check all bolts for tightness.

Keep locomotive clean, lubricated and adjusted.

The life of the hydrostatic components depends upon the type and condition of the fluid in the system. Always use a suitable fluid and be extra careful not to allow any contaminant to enter system.

Exclusive of the engine there are ten locations on the locomotive that require greasing with a grease gun. Two of these (on sprocket shaft) have been discussed elsewhere in these instructions. The other seven are located as follows:

One on outside of each axle bearing cover. These should receive additional lubricant each 100 hrs. Use a high grade medium bearing grease,

One on each end of the brake shaft on the outside side of the locomotive, one on the inner brake shaft bearing that is reached thru the opening above the right step. There is one fitting on the control stand in the operator's compartment. These fittings should be serviced as needed.

#### WARNING

In cold weather when the hydraulic fluid is cold and has high viscosity the engine should be run no faster than low idle RPM until a little heat is built up in the fluid.

Since the system charge pump is direct driven by the main pump shaft it operates at engine speed and at high speed with heavy fluid a pressure higher than that recommended may occur in the main pump housing due to resistance in lines and cooler.

Also, the hydraulic fluid filter may be subjected to an undue suction which may damage the filter element.

Never run engine faster than low idle R.P.M. if the pointer on the filter condition indicator is in the red lined portion of the dial.

#### CAPACITIES

×)

8 qts. - 9 qts. with filter change Engine Crankcase

6 gal. Radiator 2 1/2 pcs. Air Cleaner

19 gal. Hydraulic System

> PLYMOUTH LOCOMOTIVE WORKS Div. of The Fate-Root-Heath Co., Plymouth, Chio, U. S. A.

COLA

EQUIPMENT CHECK LIST -- OPERATORS

# 1. OPERATING CONTROLS AND INSTRUMENTS

The operator must thoroughly familiarize himself with the instruments and controls provided for operation of this engine. These are important differences between various engines; therefore, regardless of previous experience with other machines, the operator should fully understand what each control is for and how to use it. before starting to operate the engine.

# HOURMETER

The hourmeter indicates the actual hours of engine operation. Its range is from zero to 10,000 hours. When the hourmeter reaches 10,000 hours, it automatically . starts again at zero.

# 3. SAFETY ENGINE OIL PRESSURE INDICATOR

This indicator is part of the instrument panel (safety gauges) attachment. The safety engine oil pressure indicator shows the pressure of the lubricating oil circulating through the engine. If the oil pressure drops below minimum operating pressure, the engine will automatically stop.

# 4. HEAT INDICATOR

The heat indicator shows the temperature of the coolant circulating in the engine.

# SAFETY HEAT INDICATOR

This indicator is part of the instrument panel (safety gauge) attachment. The safety heat indicator registers the temperature of the coolant circulating in the engine. If the temperature of the coolant reaches 195 F, the engine will automatically stop.

#### AMMETER

This instrument indicates the rate at which the battery is being charged or discharged.

#### TACHOURMETER

The upper half of this indicator shows the engine rpm; the lower half of the indicator shows the indicated hours of engine operation. This indicator has a correction factor to determine the actual hours of engine operation from the indicated hours. Refer to example following.

#### EXAMPLE:

Engine rpm - 2000

# Indicated hours - 100

Todetermine the actual hours of operation, multiply the indicated hours (100) by the correction factor (.83). The actual hours: 83 hours.



ر دي. لالديمان

4000

44.40

5. IGNITION AND STARTER SWITCH

This switch has four positions: 1. Switch to the left ("ON") position for accessories; 2. "OFF" position; 3. "ON" position to the right to energize the electrical system; 4. Switch all the way to the right ("ST" position) for cranking the engine.

# PREPARING THE ENGINE FOR EACH DAY'S WORK

# 6. FUEL SYSTEM (GASOLINE)

Fill the fuel tank. Use a gasoline conforming to the specifications. DO NOT USE DIRTY FUEL.

# 7. STARTING the ENGINE

NOTE: Never operate the cranking motor for more than 30 seconds at one time. If the engine does not start, allow the cranking motor to cool two or three minutes before cranking again.

# 8. INSTRUMENT CHECK

Check all indicators immediately after starting, again upon reaching operating temperature and at frequent intervals during operation to assure proper care through prompt detection of irregularities. If any of the indicators do not register properly; stop the engine.

The ammeter should indicate "charge" whenever the engine is operating at a speed faster than low idle speed. If it indicates "discharge" or a high rate of "charge" continuously while the engine is operating at this speed, investigate the cause immediately.

## HEAT INDICATOR

The heat indicator point must be in "RUN" range, after the engine is warmed up, for the most efficient operation.

# ENGINE OIL PRESSURE INDICATOR

If the indicator pointer does not move into the "IDLE" range while idling or into the "RUN" range when the speed of the engine is increased, stop the engine and inspect the oil system to find the cause.

# 9. COOLING SYSTEM

NOTE: Do not start the engine until the cooling system is filled with coolant .. Remove the radiator cap or expansion tank filler cap and check to be sure the coolant comes to a level approximately one inch below the filler neck. Add coolant if necessary. Install the filler cap or radiator cap and tighten securely.

10. CAUTION: NEVER FILL THE FUEL TANK WHEN ENGINE IS OPERATING. KEEP THE FUNNEL OR HOSE NOZZLE USED FOR POURING IN THE FUEL, IN CONTACT WITH THE METAL OF THE TANK TO AVOID THE POSSIBILITY OF AN ELECTRIC SPARK IGNITING THE GAS.

BLOCKS UNDER AXIE BOXINGS. BLOCKS TO BE LEFT IN PLACE DURING SHIPMENT, AND REMOVED BY CUSTOMER.

DEC-03-2001 16:04 SPACE SYSTEMS LORAL 1 650 8524662 P.02/11 DATE: 4-22-96 (3040.4.5) TOTAL 11 SHEET 2\_ PLYMOUTH MODEL HSG 5 TON 25 GANGE LOCOMOTIVE INTERNATIONAL HARVESTER CO. INTERNATIONAL HARVESTER 5 CYLINDER ROD LHC V GASOLINE ENGINE, GOVERNED AT 2500 RFM UC 253 NO LOAD, RATED AT 92 HP @ 2400 RPM INCLUDES THE FOLLOWING BLOWER FAN 304549R93 FLYWHEEL WITH RING GEAR 305190R91 FLYWHEEL HOUSING 31844 IR91 OIL BATH AIR CLEANER 349144R91 STARTER 12 VOLT D-R1107350 · A Section Control of the section o ALTERNATOR 324 12V REG. D-R 1100805 601212C91 The state of the s VOLTAGE REGULATOR 124, MEG. D-E 1119507 4051210R91 SPARK FLUES CHAMPION 8 COM. PAN BELT 1 275301CL PROTTIL CONTROL. NAME 62-474-DA VALUE TRUPELATINE CAUSE 298009R91 WATER TENEFERTURE SENDER 1298016R91 OIL PERSONS GAUGE 327145R91 OTL PERSONE SENDER **建一种** 328331R91 AMPETER 702283Cl The second second MUFFLER 1265116R92 CLAMP FOR MUFFLER terminal and the second 2 district the MATI HAME OF PART THE RESERVE TO SERVE PRE CO. PARTS USED WITH ENGINE SYMBOL BOD 8 SUPPORT FOR ENGINE. REAR HS 325 SUPPORT FOR ENGINE. FRONT X5 RS 326 SHIM FOR FRONT ENGINE SUPPORT HR HS 32.7 SUPPORT FOR CTRCUIT BREAKER As I was HS 387 Company of the Compan RADIATOR AND CIL COOLER CLAMP TO MOIST OIL COOLER HS 206 SHIM DEDER HEZOG CLAMPS, LOWER HS 20.7 HOOD FOR FAN BRACKET FOR VF1568-12 COOLER, HPFKR HS 330. は本門へ RS 331 ANZLE TO SUPPORT RADIATIE. LEFT THE RESERVE OF THE PERSON NAMED IN HS 3321 ANGLE TO SUPPORT PARTATOR, RIGHT HS 332R COVER FOR OFFITTEE ON FAN HOOD 5种囊形/特赖 表 HS 333 2 PIPE WITH HEATER CONNECTION RS 381 DRATE COCE 1 PF 411 HOSE FOR PADIATOR UPPER PF 472 HOSE FOR ENGINE WATER INLET VF 11 OTI. COOLER. 1 VP 1568-17 RADIATOR R\_489 HOSE CLAMPS FOR RADIATOR HOSE

HOSE FOR RADIATOR. LOWER 2 3/8 1.D. x 4"

1 1/2 x 8" LONG PIPE. THO ONE END

1 1/2 x 6" LONG PIPE, THE ONE END

U BOLT FOR LOWER RADIATOR PIPE

2 x 1 1/2 PIPE BUSHING

2" PIPE PLUG 1/2 × 90° ELL 1 1/2 x 1/2 x 1 1/2 TEE

6 VP 815

RL 316

2

1

1

ī 2 DEC-03-2001 16:05 SPACE SYSTEMS LORAL 1 650 8524662 P.03/11

YMOUTH MODEL HSG	TUN CA	NAME OF BART	MAT
ROD	SYMBOL	NAME OF PART HYDRAULIC MOTOR BASE & DRIVE SPROCKET ASSEMBLY	"
132		HYDRAULIC MOTOR BASE & DRIVE STRUCTURE	N
	HS 85X	BASE FOR HYDRAULIC MOTOR & DRIVE SPROCKET	<u> </u>
	HS 86	ADAPTER FOR MOTOR	
1 +		RETAINER FOR OIL SEAL	3
1	HS 87	BELLINGE FOR COLI	H
1	HS 88	COVER FOR OIL SEAL	- 5
<del></del>	HS 89	SHAFT YOR DRIVING SPROCKETS LEC. VP 1582	<del>                                     </del>
	BS 90	SPOULTE BETYING DOUBLE, IN TOOTH	
1 1		DOWEL STID FOR STAFFA MOTOR MOUNT	11
1	HS 279	DOMEL STOP FOR STOP	
55.1	WF 1330		
	VR 1377		
			5 5 F
A A 4484	378		<b>,</b> +
. W	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1		12 M
	强,要是5 ~~		4
A STATE OF THE PARTY OF THE PAR			1,500
1.6	AC 1344437		を大き
The second second	· 大学 と 大学 に		7 529
2.1.1	the state of the state of the	我是是这个一个,一个一个,一个就是 <b>的</b> 我就是 <b>这种是一种的</b> 的特别的,我们就是我的一个人的,我们就是这个一个人的,我们也没有一个一个人的。	A COLOR
	3228		
			31 Just
	A5212-13		
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	3-	是 EL Transport (1)	<b>T</b>
- 6	1	CAPACITY IN S. 1 X 3 1/2 SECTO / NOT & LAW.	र लाहारी हिंदून गर्छ। क्षेत्रवर्ष
	<del></del>	- XIVE AND THE STATE OF THE STA	-11
1.2	<u></u>		* * * * * * * * * * * * * * * * * * *
	·		- A-
- 4	•	CAPSCERS ST. 3. 3/4 x 6 St., ST. 5.	San San
_ <del> </del>		THE PARTY OF THE P	
<u> </u>	1.400	WOODRUFF WY	2 - FEE
	₹32		· 通用 · 公司令
- 4		1/8 SQ. HD. PIPE PLUG. FOR HS86 & HS88	The art year
	<u> </u>	HYDROSTATIC COMPONENTS	L_
		THE THE PARTY TO STAND	
4	HS 30	CAP SCREW FOR HYDRAULIC PUMP	
<u></u>	PS 31	VASUER FOR MASO	<del></del>
	BS 92	STID FOR HAS IN MARIFOLD	
<u> </u>		THE TAX THE TAX TO SEE THE TAX TO SE	, 1
1	RS 93X	FARLY WALL TO A LOW THE C. US 101 DIATE	
6	HS 94X	STUD FOR BESSE MANIFOLD & HS 193 PLATE	
	HS 184		—↓
		REWORK OF SUNDSTRAND 9800831 PLUNGER GUIDE	
1	HS 185	PLUMER POR SHIOADING HELIEF VALVE	
1	HS 186	PLUSTEE PER DELANDATION TO THE ART WANTED TO	- 1
		PLACE WITH MANY ABAPTERS OF HS 95% HANTFOLD	Tarabathan Ta
		Market Company of the	
i			
1	HS 228	SPECIAL PARAMETER FOR	Agreem to
5-1	E 231		
w cata			
			1000
*1		13 Dec 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	e e
	. 125 385	TALL TO BE SHEET TO SEE THE SECOND SE	
			district of the
			[A <sub>2</sub> [N]
			4
		AND THE PROPERTY OF THE PARTY OF A PARTY OF	
	TP 045-2	A STATE OF THE WASHING PROJUCT OF THE PARTY	
	VP 965-3	/4 STAT-B-SEAL WASHER, MOTOR DRAIN FITTING & PLUE	
	▼P 1395-	WYDRAULTC FIRE	-
,	▼P 1395-	HTDRAULIC FUND	
	<b>VP</b> 1395-	OTL FILTER, WITH #1588 CONDITION GAUGE	
	▼P 1395- ▼P 1396 ▼P 1397	OTL FILTER, WITH #1588 CONDITION GAUGE EIRMENT FOR VP1396 FILTER, EXTRA	
	▼P 1395- ▼P 1396 ▼P 1397	OTL FILTER, WITH #1588 CONDITION GAUGE EIRMENT FOR VP1396 FILTER, EXTRA	
	▼P 1395- ▼P 1396 ▼P 1397	OIL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUND BELVE ASSEMBLY	
	VP 1395- VP 1396 VP 1397 VP 1561- VP 1566-	OTL FILTER, WITH #1588 CONDITION GAUGE OTL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUNG SELVE ASSEMBLY 200 TEMPERATURE SWITCH, EXD, FLUID WARNING MANTPOLD VALVE ASSEMBLY WITH BY-PASS DEVICE	
	VP 1395- VP 1396 VP 1397 VF 1561- VP 1566- VP 1572	OTL FILTER, WITH #1588 CONDITION GAUGE OTL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUNG SELVE ASSEMBLY 200 TEMPERATURE SWITCH, EXD, FLUID WARNING MANTPOLD VALVE ASSEMBLY WITH BY-PASS DEVICE	
	VP 1395- VP 1396 VP 1397 VF 1561- VP 1566- VP 1572 VP 1573	OTL FILTER, WITH #1588 CONDITION GAUGE OTL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUND DELVE ASSEMBLY 200 TEMPERATURE SWITCH, MYD, FLUID WARNING MANIFOLD VALVE ASSEMBLY WITH BY-PASS DEVICE 100" RING MET FOR VP 1572 VALVE	
	VP 1395- VP 1396 VP 1397 VF 1561- VP 1566- VP 1572	OTL FILTER, WITH #1588 CONDITION GAUGE OTL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUNG SELVE ASSEMBLY 200 TEMPERATURE SWITCH, EXD, FLUID WARNING MANTPOLD VALVE ASSEMBLY WITH BY-PASS DEVICE	
	VP 1395- VP 1396 VP 1397 VF 1561- VP 1566- VP 1572 VP 1573	OTL FILTER, WITH #1588 CONDITION GAUGE OTL FILTER, WITH #1588 CONDITION GAUGE ELEMENT FOR VP1396 FILTER, EXTRA 6 HYDRAULIG FUND DELVE ASSEMBLY 200 TEMPERATURE SWITCH, MYD, FLUID WARNING MANIFOLD VALVE ASSEMBLY WITH BY-PASS DEVICE 100" RING MET FOR VP 1572 VALVE	

DEC-03-2001 16:06 CHECKEN: 44

SPACE SYSTEMS LORAL

1 650 8524662

P.04/11

DATE: 3-22-68 TOTAL 11 SHEET 4 PLYMOUTH MODEL HSG 5 TON 36 GAUGE LOCOMOTIVE NAME OF PART SPLINE ADAPTER FOR HYDRAULIC MOTOR SYMBOL ROD VP 1582 HYDRAULIC TUBE ASSEMBLY VP 1584 AEROQUIP HOSE ASSEMBLY 18" LONG 1 VP 1600 2 APROQUED HOSE ASSEMBLY 27" LONG **∀P** 1600-1 RELIEF VALVE, FLUID LINE TO COOLER 2 VP 1605 6-74446-16 SPLIT PLANCE 1" AEROQUEP 22550-219 "O" BING FOR PUMP PORTS AELOO ULP 2 1000年度の大学の大学の 6-7444-20 SVLTT YLANGE 1 1/4" 22550-222 TWALEG FOR E 1/A SPLIT FLANGE CLASS ALLOUULP ATROUTE 1900548-44 Fire. The Lines 22012-8 0-8193 WILLIAM GUE THE DAY AND ADAPTED TO THE RESIDENCE OF THE PARTY O ATTENDED. 10-51-312-00 STEEL NOR MOTER PERSON TO SHOW THE THE REAL PROPERTY AND THE PARTY FURN.ON MOTOR 是我们也是我们的一个人,我们就是我们的一个人,我们就是我们的一个人。 CAPSCREE ME 8 7/16 x 1 1/2 KC FGR 1 1/4 SPC CAPSCREV St. 1.3/8 x 1 1/4 MC 1 SPLIT YLAND CAPSCREW St. 1.3/8 x 3/4 MC NITS L.V. - Z THE PERSON NAMED IN -16 \* HUT 376-21 MY LORD TOLD STD. BEAT THEATED, CO. BRAKE ASSEMBLY PRACOCK HANDREAKE WITH 61 LINKS OF CHAIN PLUS #1040HS #15 KMD LINK - EN CONTRACTOR PEARL SHAFT WITH LEVERS **BS 240Y** Service of the last PIE FOR END OF BRAKE SHAFT HS 241 BLOCK FOR POSITIONING BRAKE SHOE LEVER - 13 18 243 **60** 5 PIN FOR JL 3390 SHEAVE **ELS** HS 245 PIN FOR BRAKE CHAIN ANCHOR HS 246 24.42 FIN FOR REAKE SHOE HB 2471 - A- 3487 1-9 N. W.S. ROD TO ALIGN BRAKE SHOE ... DL 135 SPRING FOR BRAKE SHOE RETURN & BRAKE CHAIN \_**Z** DL 166 · at BRAKE SHOW 1294 GREASE PETTING हैं के प्रतिकार के किस की किस क NO THE OWNER OF THE PERSON NAMED IN LOCK PLATE FOR H\$245 PIN A STATE OF STATE 3397 MEAVE FOR BRAKE CHAIR BUSINES FOR 113390 SHEAVE THE PART OF THE PARTY OF THE PA and the standard property of the second standard School Section 18 CAPSCREWS, 1/2-13 x 3 3/4" LONG 2 FLEXLOCK NUT 1/2+13 一一种运用的社会 2 THROTTLE ASSEMBLY MODIFICATION OF THE 367 742 RI GOV, SPRING BRACKET CES HS 393 ROD FOR THROTTLE, FRONT HS 394 SUFFICIET FOR THROTTLE CABLE ON ENGINE BS 395 POLCRUM LEVER FOR THROTTLE RF 396 PUSH-PULL CABLE FOR THROTTLE **VP** 1606 CLEVIS & PIN FOR PUSH-PULL CABLE VP 1607

DEC-03-2001 16:07 SPACE SYSTEMS LORAL 1 650 8524662

)

P.05/11 TOTAL 11 SHEET 5 PLYMOUTH MODEL HSG 5 TON 36 GAUGE LOCOMOTIVE MATL NAME OF PART SYMBOL ROD AXLES & WHEELS SPROCKET ON AXLE 18 T. FL 37 Š HUB FOR AXLE SPROCKET FL 38B CI BOXING FOR AXIE FT. 90B CI CENTER FOR CARVHEEL FL 538C 4 CI COVER FOR AXLE BOXING •FL 2795 4 PLATE TO RETAIN BEARING ON AXLE FL 2796 4 CAPSCREW FOR BEARING RETAINING PLATE 5 FL 2816A 12 og 🛊 💆 PLUG FOR AXLE SPROCKET FL 3745 **3.8** 京場 停止 京都 4 RETAINER POR AXTE SPROCKET PLUG FL 3746 THE PARTY OF 4 AXLE FL 5083Y 2 BRARING SPACER FOR AXLE BOXING PL 593 4 janustinas ir ir ir BOLT FOR SPROCKET TL 367 12 BEARING. TIMEN 580 COME. 572 CUP 8 SHIR TIMES .. 005 THICK FOR FL2796 T50608 12 SHIM TIMEN .007 THICK FOR F12 796 T50609 12 SHIM TINGEN .020 THICK FOR FL2796 T50610 · 经生产工作业务 TIRE FOR CARWHEEL **VP** 15 - 大学 小学 4 - 15 - 2 - 44 F/M #61.1 NUT. FLEXLOCK 3/4-16 FOR TL 367 12 The second second CAPSCREW 3/4-10 x 1 3/4 16 EVERLOCK WASHER 3/4 16 WOODRUFF KEY The state of the s 4 ALKHITE GREASE FITTING GC 13 4 FRAME AND RELATED PARTS MS TIE BAR UNDER AXLE BOXING HS 181 4 . ... v 🗫 . . v 🗫 . FRAME ASSEMBLY The of the state o HS 324 TIE BAR FOR FRAME 2 HS 345 8 STEP FOR FRAME HS 346 MS. SPRING. FOR AXLE CL 60 SHIM UNDER AXLE BOXING (SHIPPING ONLY) THE CHARGE STATE FL 2086 4 SLIDE FOR AXLE BOXING FL 3235A 8 COUPLING PIN -428-65 FL 3810 2 BAR TO CLAMP AXLE BOXING SLIDE FL 5005 8 SHIM FOR AXIR BOXING SLIDE FL 5006 8 WASHER FOR SPRING SEAT RL 813 4 WASHER OVER RL813 RL 878Y 4 CAPSCREW 3/4-10 x 2 1/2 FOR RL 813 4 SLIDE CLAMPING CAPSCREW 3/4-10 x 4 16 SLIDE ADJUSTING SET SCREW 3/4-10x 4 16. PLAIN WASHER 3/4 4 3/4 LOCKWASHER 4 - 1 4克 ( 1 4 **5** 5 ) 3/4 - 10NIE 16 FOR HS345 TIE BAR 1/4 - 7NUT 8 0.20 CHAINS & CHAIN OTLERS 3 DRIVE CHAIN TO AXYES 5 2 VP 9140T-44 OFFSET LINK 2 VP9142T

DEC-03-2001 16:08 SPACE SYSTEMS LORAL 1 650 8524662 P.06/11 CHECKED: Jalan DATE: 3-22-68 TOTAL 11 SHEET 6 PLYMOUTH MODEL HSG 5 TON 36 GAUGE LOCOMOTIVE MATL NAME OF PART SYMBOL ROD S CLIP FOR 5/16 COPPER TUBES **VP 261** 6 CHAIN OTLERS VP 443 ٠2 MS SUPPORT FOR CHAIN OILERS JL 5303 MI 1/4" PIFE BLBOWS × 900 BSP 1/4" CLOSE MIPPLE 2 BSP 1/4" x 2 1/2" LONG NIPPLE 2 CHAIR OTLER TUBES 5/16 COPPER x 54" LONG COPPE 2 88-LB Ż The second secon Leg A BELLEVILLE SELECTION ASSY. STORE SERVICE SHORE SERVICES HS 391 BANKA BA 3- T WF 1611 CALL THE BOTTLE SHOW IN 16. 47 1612 ··· TAGEN SOUTH OF THE SECOND SECURITY AND THE RESERVE OF THE PERSON The second secon OF LEATHER SALE PEDESTAL FOR OPERATORS SEAT FL 3894 ADJUSTING POST TO OFFICE SEAT FL 3927 PLUS FOR SEAT BASE RL 256A · 1 SEAT AND BACK BEST VP 742 1 THE RESERVE TO SERVE 2" FIRE CHOPLES A State Commence and the state of t HORN PUSH BUTTON FOR HORN VP 28A HORN 12 V. VP 622 -RELAY POR HORN **VP 623** Add Street CAR HEATER HEATER FOR CAR VP 735-12 ----CLASS FOR HEATER HOSE · e. VP 812 PF 171 3/8 PINE A V/A" LONG THREAD ONE END. 2 and the second second 65" LONG TIPE STREET SEASO ATT HOSE S/E-14 1 人名英格兰 医多种性 医多种性 医多种性 医二甲基二氏 医二氏病 医大量性 医皮肤 一二十二 · 3... A STATE OF THE PARTY OF THE PAR ALC: NO PORT AND A MISCELLAMEOUS

FRAME IN CAB FOR CHART

CLOSURE FOR CAR FLOOR

REAR SECTION OF FLOOR

FIRE EXPLINENTSHER. S. DRY CHEMICAL

TWOORING

LEFT FROMT SECTION OF FLOOR

CENTER PRONT SECTION OF FLOOR

RIGHT FRONT SECTION OF FLOOR

REFLECTOR

SUE VISOR

FL 3995

VP 744

**VP 1060** 

WP 1601

HS 358

HS 371

HS 372

HS 373

HS 374

2

4

1

HRS

HRS

MOOD

VACE

MOOD

WOOD

\_\_\_\_

١

	114545	3 EUN 30 GAN	KER LOCOMOTIVE SHEET / TOTA	MAT
	ROB	SYMBOL	NAME OF PART	
	1	HS 1034	CONTROL STAND ASSEMBLY	
<u>.</u>	╫╤┯╂	HS 280H	STOP FOR HANDLE ON CONTROL STAND	
	2		CONTROL STAND	
	11	HS 280X	CONTROL STATE	
	1	HS 282	LEVER FOR CONTROL HANDLE	
		NS 283	HUB FOR CONTROL LEVER	and the second second
		HS 284	HANDLE FOR CONTROL STAND	
<u> </u>		HS 285	EXPANSION PLUG FOR CONTROL HANDLE	ja .
<u> </u>	1		PIN FOR CONTROL HANDLE	
		HS 286	PIN FOR CONTROL TOTAL	Lagrania Miller
		HS 287	ROCKER ARM FOR INDEXER	1. In his set in F
	4	HS 288	PIN FOR ROCKER ARM ROLLER	The second second
		198 289	COVER FOR ROCKER SPRING RECESS	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
		RS 351	TAPPED BLOCK TO MOUNT CONTROL STAND	
200 July 14.			LEVER FOR TIME CONTROL ROD	
والمرافة مداريس والمراب والمراب		* HS 352	LIVE FOR THE CONTRACT	
· · · · · · · · · · · · · · · · · · ·		HS 353	HOLDER FOR ECA17 BEARING	
Salah Ang Salah	23 miles	- HS 354	THAT WITE CAN PLATE	
		RS 355	HOD FOR WHAT CONTROL	
اً الله المدينة على المراكبة			BRACE FOR CONTROL STAND	
	A-7 1	HS -589	BRACE FOR AMERICA	
9-148-3- Standard	<b>₹</b>	A CONTRACTOR OF THE PARTY OF TH		
		DL 466	STACE	
	4-1	- GC 18	GREASE FETTING	
			- EXPTRE	المنابعة والمنابعة والمناب
فيتبيه فمينا فدادت ودار مالينا أراسي	w	EC 417		
		ML 1805A		
	- T	Mr. 1805B	SPACKE 5/16 TRICK	
		PTA 5-19	YOKE END	
		PTA5-20	PTW FOR PTA 5-19	THE RESIDENCE OF THE PARTY.
<u> </u>	-   2		SPRING FOR ROCKER ARM	The state of the s
1	4-4-	PTA 10-64	DIRING INC. MANAGE CONT.	10 2 Xa
	_ <u>f</u> ;	<u> </u>		Mar Charge (C
	1 2	VP 345	SPRING THE CONTROL HANDLE	
	2	VP 1116	BALL IN CONTROL HANDLE	
72				7.0
	<del></del>		NICE BALL BEARING	<u> </u>
		1614DC		(金属) 1000年
	3		#3 x 1 1/2" TAPER PIN	
	2		3/8-24 TAM NUT	TOTAL PARTY
	<del>-   -   -   -   -   -   -   -   -   -  </del>		11-11	
<del> </del>	<del></del> -			, , , , , , , , , , , , , , , , , , ,
				F. 1
				:
			FIEL TANK & RELATED PARTS	100
		FT. 78D	TANK FOR FIET.	
	- 1-3	F7. 1503	SANDLE NO PET. TANK	5-3 <b>-3-3-3-3-3-3-3-3-3-3-3-3-3-3-3-3-3-3</b>
		4		
7	3 7		I - A-R THE PROPERTY WITH TAKE	
	7 2	FT. 1505	RAND FOR CLAMPING FUEL TANK	<b>大学</b> 经基本条件
	. 경소 <b>라</b>	F1, 1505		
1.175	. 경소 <b>라</b>	F1, 1505	TAPPED BLOCK FOR PIEL TANK BRACK	
		FT: 1505	TAPPED BLOCK FOR PIEL TANK BRACK	
		FT: 1505	TAPPED STACE FOR PIET TANK BRACE	
Sylvanian Sylvan		HS 347	TAPPED STAGE FOR PIET TANK BRACE TAPPED NEWS PIET TANK BRACE BRACE FOR PIET TANK SADDIE	
		FI: 1505 FI: 367 FI: 368 FI: 350	TAPPED BLACK FOR PIEL TANK BRACK TAPPED WESEN FOR PIET TANK BRACK REACE FOR PIET TANK SADDLE SUPPORT FOR EMERGENCY SHOT OFF VALVE	
Sylvanian Sylvan		HS 347	TAPPED BLOCK FOR PIET TANK BRACK TAPPED BLOCK FOR PIET TANK BRACK RRACE FOR FIET TANK SADDLE SUPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN _ SRORT _ 21 LINKS	
Sylvanian Sylvan		HS 347	TAPPED BLOCK FOR PIEL TANK BRACK TAPPED BLOCK FOR PIEL TANK BRACK BRACK FOR FIEL TANK SADDLE SUPPORT FOR EMERGENCY SHOP OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS	
Sylvanian Sylvan		#3 36.7 #8 36.7 #8 350 #8 356	TAPPED BLOCK FOR PIEL TANK BRACK TAPPED BLOCK FOR PIEL TANK BRACK BRACK FOR FIEL TANK SADDLE SUPPORT FOR EMERGENCY SHOP OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS	
Sylvanian Sylvan		#3 36.7 #8 36.7 #8 350 #8 356	TAPPED BLOCK FOR PIET TANK BRACK TAPPED BLOCK FOR PIET TANK BRACK RRACE FOR FIET TANK SADDLE SUPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN _ SRORT _ 21 LINKS	
Sylvanian Sylvan		#S 347 #S 348 #S 350 #S 386	TAPPED BLACK FOR PUBL TANK BRACK TAPPED MEANY PUR PUBL TANK BRACK RRACK FOR FUEL TANK SADDLE SUPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SINCET - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING x 32" LONG	
Sylvanian Sylvan		FI. 1505 RS 347 RS 348 RS 350 RS 386	TAPPED BLACK FOR PIEL TANK BRACK TAPPED BLACK FOR PIEL TANK SADDLE REACT FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SHORT - 21 LINES CHAIN - LONG - 82 LINES 3/8 COFPER TUBING * 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE	
Sylvanian Sylvan		#S 347 #S 348 #S 350 #S 386	TAPPED BLACK FOR PUBL TANK BRACK TAPPED WESEN FOR PUBL TANK SADDLE REACE FOR FIEL TANK SADDLE SUPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SHORT - 21 LINES CHAIN - LONG - 82 LINES 3/8 COFFEE TUBING * 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE	
Sylvanian Sylvan		FI. 1505 FI. 1505 FI. 347 FI. 348 FI. 350 FI. 386 FI. 386 FI. 386 FI. 386 FI. 386	TAPPED BLACK FOR PUBL TANK BRACK TAPPED WESEN FOR PUBL TANK SADDLE REACE FOR FIEL TANK SADDLE SUPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SHORT - 21 LINES CHAIN - LONG - 82 LINES 3/8 COFFEE TUBING * 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE	
	1 2 3 3 3 3 3 1 1 2 2 1 2 2 2 1 1 2 2 2 2	FI. 1505 RS 347 RS 348 RS 350 RS 386	TAPPED BLACK FOR PIEL TANK BRACK TAPPED BLACK FOR PIEL TANK SADDLE REACT FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SHORT - 21 LINES CHAIN - LONG - 82 LINES 3/8 COFPER TUBING * 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE	
		HS 367 HS 368 HS 350 HS 356 DL 625A HL 902 HL 1336	TAPPED BLOCK FOR PIEL TANK BRACE TAPPED BLOCK FOR PIEL TANK BRACE BRACE FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING × 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE	
	1 2 3 3 3 3 3 1 1 2 2 1 2 2 2 1 1 2 2 2 2	FI. 1505 FI. 1505 FI. 347 FI. 348 FI. 350 FI. 386 FI. 386 FI. 386 FI. 386 FI. 386	TAPPED BLOCK FOR PIEL TANK BRACE TAPPED BLOCK FOR PIEL TANK BRACE BRACE FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING × 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE CLOBE VALVE 1/4"	
	1 2 3 3 3 3 3 1 1 2 2 1 2 2 2 1 1 2 2 2 2	FI. 1505 RS 34.7 RS 34.8 RS 350 RS 356 DL 625A HL 902 HL 1336 PF 130	TAPPED BLOCK FOR PIEL TANK BRACE TAPPED BLOCK FOR PIEL TANK BRACE BRACE FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING × 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE CLOBE VALVE 1/4"	
	2 -1 -2 -1 -2 -1 2	HS 367 HS 368 HS 350 HS 356 DL 625A HL 902 HL 1336	TAPPED BLOCK FOR PIEL TANK BRACE TAPPED BLOCK FOR PIEL TANK BRACE BRACE FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING × 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE	
	2 -1 -2 -1 2 -1 2 -1 1 2	PI. 1505 RS 347 RS 348 RS 350 RS 386 DL 625A HL 902 HL 1336 PF 130 PF 158	TAPPED BLACK FOR PUBL TANK BRACK TAPPED BLACK FOR PUBL TANK SADDLE BRACK FOR FIREL TANK SADDLE SUPPORT FOR EMERGENCY SHOT OFF VALVE CHAIN - SHORT - 21 LINES CHAIN - LONG - 82 LINES 3/8 COFFER TUBING * 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE GLOBE VALVE 1/4" GASOLINE EMERGENCY SHUTOFF VALVE	
	2 -1 -2 -1 -2 -1 2	PI. 1505 PS. 34.7 PS. 34.8 PS. 350 PS. 386 PJ. 625A HIL 902 HIL 1336 PF. 130 PF. 158	TAPPED BLOCK FOR PIEL TANK BRACE TAPPED BLOCK FOR PIEL TANK BRACE BRACE FOR FIEL TANK SADDLE SHPPORT FOR EMERGENCY SHIPL OFF VALVE CHAIN - SHORT - 21 LINKS CHAIN - LONG - 82 LINKS 3/8 COFFER TUBING × 32" LONG  SPRING FOR SHUTOFF VALVE PULL HANDLE LEVER FOR SHUTOFF VALVE EMERGENCY SHUTOFF VALVE PULL HANDLE CLOBE VALVE 1/4"	

DEC-03-2001 16:09

SPACE SYSTEMS LORAL

1 650 8524662 P.08/11

CHECKED: J.T.D. DATE: 3-22-68 TOTAL 11 SHEET 8 PLYMOUTH MODEL HSG 5 TON 36 GAUGE LOCOMOTIVE MATL. NAME OF PART SYMBOL ROD PIPE NIPPLE 1/4" x 2 THREAD BACK 1 1/8 FROM END BSP BSP PIPE NIPPLE 2" x 11 1/2" LONG RSP PIPF NIPPLE 2" x 5" LONG PIPE ELBOW 2" x 450 BRASS IMPERIAL 90° CONNECTOR 5/16 COPPER x 1/4 I.P.T. 89 LB. COPPER 5/16 COPPER TUBE x 18" LONG Santa Sa BATTERY & BATTERY BOX - **- 25**6-7 BATTERY HOD-8D 12 WOLT 1144H BOX FOR BATTERY HS 378 AMELE TO SUPPORT BATTERY BOX COURS. 18 379 1 COVER FOR CABLE AT KIND OF MATTERY BOX HS 392 BAR TO GLAR MATTERY DL 9010 COVER FOR SATISFET COMPARTMENT DL 9382 1 STID FOR SATISTY BOX DL 9383 5/16-18 WING WOT PERL BACK SPONCE RUBBER, 5/32 x 1" x 72 1/2" 1982 | RUBBER 2 1 INSTRUMENT PANEL, GAUGES & ELECTRICAL PARTS SUPPORT FOR FILTER CONDITION GAUGE المواقق ا 18.8 HS 174 HRS PANEL FOR INSTRIMENTS RS 376 1 HRS END FOR INSTRUMENT PANEL HS 377A 1 9 ... CLIP FOR INSTRUMENT PANEL END HS 377B 2 3 CLIP FOR CONDUIT BOX HS 382 HORS SUPPORT FOR CONDUIT HS 383 MS BRACKET FOR HEADLIGHT DL 5687 ANGLE FOR BATTERY CABLE CLIP DL 6401 CHOKE CONTROL **VP** 61 PANEL LIGHT VP 208 DOME LIGHT FOR CAB. USE #1141 21 C.P. 12V BULB 2 VP 269 1 SWITCH FOR DEFECTION FAN 2 VP 291 HYDRAULIC FLUID, TEMPERATURE GAUGE VP 444 The state of the s SWITCH FOR HEATER VP 520 SWITCH FOR HEADLIGHTS VP 535A VP 651-12 HEADLIGHTS ----٨. KEY & STAFFE SECTION \* **VP** 709 INSPECTION LIGHT. USR #1004 12V. 15 C.P. D.C. ERTS VP 740 1 SOCKET FOR DESPECTION LIGHT V# 740A 1 DEFROSTER FANS 2 VP 741 TERMINAL STRIP VP 1126-101 HYDRAULIC CHARGE PRESSURE GAIGE VP 1153 1 BATTERY DISCONNECT SWITCH VP 1199 CIRCUIT BREAKER 25 AMP. MANUAL RESET 3 VP 1246M-25 CIRCUIT BREAKER 35 AMP. AUTO. RESET VP 1247A-35 VP 1248 HOURMETER MOUNTING RING FOR HOUSEMETER VP 1249 VP1292-12-65 WINDOW WIPER MOTOR ARM FOR WINDOW WIPER VP 1293 4 BLADE FOR WINDOW WIPER VP 1294-14 GAUGE, FILTER CONDITION VP 1396B

DEC-03-2001 16:10 SPACE SYSTEMS LORAL 1 650 8524662 P.09/11

CHECKEUT J.A DATE: 3-22-68 SHEET 9 FOTAL 11 PLYMOUTH MODEL HSG 5 TON 36 GAUGE LOCOMOTIVE MATL NAME OF PART SYMBOL RODI ELECTRIC FUEL GAUGE, RECEIVER VP 1608 FLECTRIC FUEL GAUGE SENDER VP 1609 ADAPTER FOR ELECTRIC FUEL GAUGE VP 1610 SWITCH FOR DOMELIGHT PB-93 ENG. WATER TEMPERATURE GAUGE 298009B91 ENG. OTL PRESSURE CAUCE 32 7 14 5 R 9 1 AMMETER 702283C1 ALSO LISTED ON SHEET 42 WITH THE PARTS PERSONAL PROPERTY AND AND ASSESSED. - 2 BET THE RESERVE OF THE PARTY OF THE The second second - 一元 かり かつかり 会 大学 一次 3 47. THE PARTY OF THE P 79 C 79 The second section of the section VP1542-2:375 RAINCAP FOR 2 3/8 O.B. EXHAUST PIPE and palaces to a september of the company of the co 3/8-16 MC M 1 1/4 STATMLESS STEEL CAPSCREW MER HS341 2 \$10-24 x 1/2 STATRLESS STEEL BOLT WITH MUT E L.W. POR SPART REPORTED 6 HYDRAULIC RESERVOIR BREATHER & CAP FOR HS343 RESERVOIR HS 125X RESERVOIR FOR HYDRAULIC FLUID HS 343 HRS SUPPORT FOR VP1396 FILTER HS 344 BLOCK TO SUPPORT VPI396 FILTER М H3 356 SUPPORT FOR PLOTD FIFE HS 363X MS TAPPED BLOCK FOR HE343 FL 2968 2 MS PORT TO HERE SUPPORT DL 244 メイ<del>ルの</del>ション**数 / 188**2 1 DL SLLIN THE PARTY OF THE P 1/2" SHUTOFF COCK FOR HE343 RESERVOIR DRATE PF 435 SENTOFF COCK PETWEEN RESERVOIR & PILTER PF 437 THE WELL STOPPETS POOR THE BOOK MADE TOCK LATE THEM? & LINE €~ **68.**8 A Secretaria SOOR FOR HOOD WITH LOCK, KYCHT PRORT & LEFT 2-21 108.5 HS 335 HRS STOR FOR HOOD, INFI RS 336 HRS STOR FOR MOCD, MIGHT HS 337 HE S TOP FOR HOOD, FRONT HS 338 HRS TOP FOR HOOD REAR & SAND BOX HS 339 S SUPPORT FOR SHUTTER, UPPER HS 340 S SUPPORT FOR SHUTTER. LOWER **HS 341** HRS COPPER ON HOLD TOP RS 342 HRS SEAL AROUND AIR CLEANER HS 370 MS BLOCK TO SPACE HOOD TOP DL 5892 CI NAME PLATE FOR FRONT OF HOOD DL 9456 S HINGE FOR HOOD DOOR 8 VP 99A S LOCK FOR HOOD DOOR VP 1585A

DEC-03-2001 16:11 SPACE SYSTEMS LORAL 1 650 8524662 P.10/11 DATE: 3-22-08 (MECKED: 1.....

	1106		LOCOMOTIVE SHEET TO LOTSE IT	ATT.
	ROD	SYMBOL	CAB ASSEMBLY	
			CAB ASSEMBLY	S
		HS 328	WEATHER STRIP FOR DOOR	
	4	HS 329	CLOSURE FOR FRONT OF CAB	HRS
	1. 1	HS 357	CLOSURE FOR FRONT OF GLAD	
	$\Box$		DOOR HANDLE. INNER	MS
	2	BL 987A	HAND HOLD FOR REAR OF CAB	MS
	7 2	BL 1072	HAND HOLD FOR REAR OF CAD	
			TAN DAY DICHT	HDR.S
	1	FL 3859	DOOR FOR CAB, RIGHT	- 111
	1	FL 3860	DOOR FOR CAR, LEFT  RAR FOR DOOR SLIDE, LOWER INNER	MS
	2	FL 3878	MAR FOR MARIE OFFICE	· <b>HS</b>
	2	FL 3879	BAR FOR DOOR SLIDE, OUTER CLOSUR FOR FUEL TANK FIFE	
The matter of	4 1	FL 3932	The second of th	
	1	FL 3933	GASKET FOR FL3932 CLOSURE SHIM UNDER WEATHER STRIP, CAB DOORS	
	<b>♦</b> •	PL 3983	SHIN GROEK WEATHER STREET, CRO LOVE	
** * **	<u>.                                    </u>	6.		
	-	N -		3º -
	- 1	ML 1308B	BRACKET FOR CAB DOME LIGHT	-
		ii	18 - 26	S 61.4
	4	VP 548	GLASS FOR GAB, 1/4 SAFETY 18 x 26 GLASS FOR CAB, BUOLITE SAFETY GLASS 1/4 SAMESTER	F (22)
	4	VP 749	GLASS FOR CAS. SCOLLES SAFELL GLASS I	<b>G</b> ENT OF THE
· · · · · · · · · · · · · · · · · · ·	T'		IMLAND FILLER STRIP, 87 5/8 LG, FOR VP548	RIBI
	4	33197-R	INLAND FILLER STRIP, 87 5/8 LG, FOR VF548 INLAND WINDOW CRANNEL. 87 5/8 LG, FOR VF548	R (B)
	4	755474	INLAND WINDOW CHANNEL. 8/ 5/8 LAI, FUN VI PAR 1707/4 G	RIBI
	4	33197-R	INLAND FILLER STRIP, 95 3/4 LG, FOR VP749 INLAND WINDOW CHANNEL, 95 3/4 LG, FOR VP749	
	4	755474	INLAND WINDOW CHANNEL, 95 3/4 LG. FOR VENTS	
				6 3
	2		1" THICK GLASS WOOL INSULATING BLANKET x 24 1/4 x	7
	$\neg \Box$		FOR FL3859 & FL3860 DOOR	
				<del></del>
			CANDAD CEOUR	
			SANDER GROUP	C
	4		HEAD POR SAND VALVE	C
	4	AL 1214	SPRING FOR SAND VALVE	
			THE TAX CAND WATTE	C
	4		HOUSING FOR SAND VALVE	C
	4		DEFLECTOR FOR SAND IN VALVE	-
	1	CL 81	LEVER POR SANDER SOMET	
100		CT. 82	The state of the s	C
	2		BRACKET FOR SANDER SHAFT	<i>&gt;</i> €
	1	CL 84	HARDLE FOR SANDER OFERALION	
		CL 139	Will be a second of the second	2 ° कार
	4			T -
	4	CI. 160	STATE SALES VALVE	
		CI. 160	PIN FOR CLS1 LEVER	. ) <sub>2</sub>
	1	CI. 160 CL 322	PTH FOR CLS1 LEVER	
	1	CL 160 L CL 322	PIN FOR CLS1 LEVER  COVER FOR SAND BOX	)* <b>8</b>
	1	CL 160 L CL 322 2 FL 1475 2 FL 1476	PIN FOR CLS1 LEVER  COVER FOR SAND BOX CHAIN FOR FL1475 COVER	)* <b>1</b>
	1	CL 160 CL 322 FL 1475 FL 1476 FL 1478	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR	0 5
	1	CL 160 CL 322 FL 1475 FL 1476 FL 1478 FL 1478 FL 3920X	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE	S 1
	2 2 2	CL 160 CL 322 FL 1475 FL 1476 FL 1478	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR	. > 2
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER	C S
	2 2 2	CL 160 CL 322 FL 1475 FL 1476 FL 1478 FL 1478 FL 3920X	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE	C S
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X	PIN FOR CLS1 LEVER  COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER SUFFORT FOR SAND PIFE REAR	
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X	COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER	
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X  HS 388	PIN FOR CLS1 LEVER  COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER SUFFORT FOR SAND PIFE REAR	
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X  HS 388	PIN FOR CLS1 LEVER  COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER SUFFORT FOR SAND PIFE REAR	
	2 2 2	CL 160  CL 322  FL 1475  FL 1476  FL 1478  FL 3920X  FL 3921X  HS 388	PIN FOR CLS1 LEVER  COVER FOR SAND BOX CHAIN FOR FL1475 COVER GUIDE FOR SANDER CONNECTING BAR CONNECTING BAR FOR SANDER HANDLE SHAFT FOR SANDER SUFFORT FOR SAND PIFE REAR	C S

DATE:	3-22-6	8 .	CHECKEL	: J.T	D'.				<u></u>			TIVE N			
						rve	-				9	HEET !	1 TOTA	L 11	
LAMOU	TH MOD	EL H	SG 5 TO	LUCU	- P- 1	EDWI	ITP I	HOSE &	FITT	ING					
				<u> </u>		ALKOO!	1 1 1								
			SE TO LE	WITE C	TVE	<u></u> .									<u> </u>
NOTE		_													
		150 1	TTTINGS	USED V	ITH	EACH	HOS	R ARE	INDIC	VIED	AFTER	HOSE			
<u> </u>	<u>-</u> -	KNC.	H BY ITE	M NUM	SER.	AND A	RE I	TEMEZ	<u>TA 02</u>	THE E	ND OF	HOSE	LIST_		
<del></del>												TION O			
RQD	HOSE		LENGTH		CTII			LOC	VITON	UK DE	, orașa a		.J. <del></del>		ردائي ڪا پھوڻي
				1 1	XX	<u> </u>	+	<del></del>							<b>安全不安保。</b>
	<u> </u>			KND	1	KMD 2									
+				1	-	1	_				- 4 157 ·		TO ES	2. A. S.	
<del> </del> -	1503		* *:57	1-2-1	3	33 2		CHARG		THE S				7	10 mg
1 1	1503		2.9	4	3	3 2		711.71	R COM	344		Tation and apple	4-7-F	- 471	
7 : 1	1503	- Marie 1	10 SA 10 S		<del>-3</del>		<u> </u>	T.L				P. M. S. T. Land			
1	grad et a	1 1 1 1 E	1 mg	2,201		9.4	* 10+4 -	grinda, in selekt	A CONTRACTOR	AD CA		EXSER	(1)(1)		
1	1.503	-10	34		-71	~ <b>8</b>   '	2	FIAL	A 10.1	TACK	PORT	T 10	127		
1	1503	-10	13	13	22	12	10		(articles par	<del>a</del> lmi aj sir <del>a</del>	معالطات رس	To the second			
<del> </del>	1 2 2 2			15	11	: 11	9			FUE	CASE	TQ_FE		5	
<del>  - <u>-</u> -</del>	1503	_	35	9	11		9	PEPE	TO LE	MEL I	\$ 18 9 di		* 1 1 T		2 L 18 c
+ +-	1503		19	9	11	11	9	1.00	rf Vai	A A COMPANY		<u> </u>	والمراجع المراجع		
1 1		-12		9	11		2	<u> OUTL</u>	KT_GF	COOL	IR TU	GE FIN			
1	1503		17	9	11_	12 1	4	PLUI	D FIL	<u> </u>	<u> </u>	4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4		Maria de la compansión	
						L				<del> </del>	-	-	14 <u>1 13 1</u>		· 1000年
		·				<del> </del>					<u> </u>				<u> </u>
			•	_		-								. ,	· · ·
							AER	OOUTP	TITI	NGS					
<del></del>	ROD		TOOL												<u> </u>
TIE	1	707	792-4-4S	STRA	ICH	T ADA	PIER	7/16	-20 J	IC TO	7/16	-20 ST	AIGHT		<u> </u>
<del>-   -   -</del>	1 3		1-2-48	STR	<u> IGR</u>	T ADA		. 7 <i>L</i> 18	-20		1/8.	HALE F		u (a ti	
3	6	411	-45			<u> </u>			-20 J						
4	1		4-2-45	900	ADA	PIER	PTT S	7/10	5-20 J	IC TO	1/4	MALE P	IPE TH	EKAD	
5	_   1	207	1-4-4-8 2702-8-10												
- 6	1	202	<u> /02-6-10</u>	BOT	ž.	REPERV	Z 150	" RES	G & US	W VP9	65-3/	4 STAT	0-8# AE.	, , , , x <sub>1</sub> ,	
<del>-   -</del>	<del>-   , -</del>	+;;;	1296-109												C 427
, <del>'</del> á	11	描	1296-103 1-12-108	375	ΧŒ	7 541	2.14	- F 7	/LA-L	770	THEFA	D X WAYN		1	A STATE OF THE PARTY OF THE PAR
<del>-                                    </del>	<del>-  </del>														<del>.</del>
10	1		21-12-125 2702-10-1 1-125											C 277	A MACHEN
E 11	9														
12	L	13	0261-125 2702-8-14	70-	SWI	LVAL I		778-	14 11	: 10	3/4-14	SILAI	CAL I		· · · · · · · · · · · · · · · · · · ·
13		_						PP 1	1/16	_ 17 T	11: 10	// O= 14			DAPTER
14		20	<b>2702-10-</b> 23-12-12:	13 51	BALL	A DOTTO D	1 1	$\frac{1}{116-12}$	JIC	TO 3/4	4 MALE	PIPE	THREAD		
15	1	+20	23-12-12	45	291114	TE IEV	<u> </u>								<del></del>
<del>                                     </del>	-   -	+		1											
<del>                                     </del>	$-\dagger$	+	.""	1											
1	$\dashv$	┪												·	
H															<u></u>
	_1_														
				1											
				+							·				
		<del></del>						<del></del> -			<del></del>				
		<del> -</del>	· · · · · · · · · · · · · · · · · · ·	<del> </del>											
<del>   </del>		-		_											

PART NUMBER DESCRIPTI	CON OTY.
1) 9006150-1190 Back-up W	Vasher 2
2) 9004101-1190 "O" Ring	2
3) 9004100-0200 "O" Ring	,1,

•			<u></u>	7 <i>1 G11114</i>	
	PARALLELISM :TIR)	BASIC LOCATION (R.)  PERPENDICULARITY (TIR)		LOGATIONITIES	SCALE
		MATL.		Mountin	anifold Valve g Seal Packar SUNDSTRAND
-		DESIGN JOS NO. 5	53 1. 3-3-44	64.77	HYDRO-TRANSMISSI
		CHECKER	0.0045		LA SALLE, ILLING
	WAS P/N 9700/90 ENG. REL.			l	)49 I
EG _ET DATE BY	REMARKS	RELEASED BY		<u>,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,</u>	

1 650 8524662 P.02/0

# PARTS LIST

Variable Displacement Pump

Model 23-2036

				Dest Description	
Ref#	Qty	Part Number		Part Description	
1	4	9007200-2536	•	Hex Head Screw	
2	4	9009610-2850		Washer	
3	1	9801038-03		Charge Pump Assembly	•
4,	1	9801074		Charge Pump Gasket	
5	2	9800648	• '	Check Valve Assembly	•
5A	2	9800721	و	Check Valve	* .
5B	. 2	9004101-0150	٠.	'O' Ring	
	4	9007200-4430		End Cap Screw	
6		9007200-4438		End Cap Screw	ina ing kabupatèn sa
7	. · · · 4	9009610-4778	**	Washer	o magnitude
8	•	-		End Cap	and the second s
9		9230285		Shim	*
10	lA/R	9230482	•	End Cap Gasket	•
11	1	9230127		Rear Bearing	·
12	. I	9001415-0002		Pin	
13	1	9004800-3110		Valve Plate	
. 14	1 •	9230197		Bearing Plate	
. 15	1	9230288		Pin .	
°16	2	9004800-3708		'O' Ring	
17	1	9004101-0140		<del>-</del>	•
• 18	1	9230239		Pump Housing Hex Head Screw	
19	7	9007200-2530			•
20	2	9007200-2526		Hex Head Screw	
21	. 9	9009610-2850		Washer	
22	1	9003560-2500		Jam Nut	
23	1	9009660-2500		Washer	
24	1 .	9800916		Control Handle	
25	1	9800917		Spacer_	
26	1	9004600-0607		Cotter Pin	
27	1	9009610-2850		Washer	
28	1	9800893		Control Valve Assembly	
29	1	9800432		Orifice	,
30	3	9004101-0140		'O' Ring	•
31	ī	9801076		Pin	•
32	-	•		Not Used	
33	1	9800138	•	Control Valve Gasket	
34	ī	9005001-1200		Plug	
35	ī	9005101-4400		Hex Head Plug	
36	ī	9004201-2500		'O' Ring	
37	6	9007200-4416		Hex Head Screw	
38		9009610-4778		Washer	
39	2	9230018		Trunnion	
40	A/R	9230019		Shim	
40 41	2	9004100-2320		'O' Ring	
41 42	2	9001430-0001		Trunnion Bearing	
43	1	9230469		Drive Shaft	
44	1	9001435-0001		Front Bearing	
45	י ז	9800210		Connecting Link	
46	2	9006320-0025		Retaining Ring	
40		/00000.07-0		<del>-</del> -	


		3	+ +	
		2 - 23-2036		
•			Pivot Pin	
47	1	9004830-2501	Retaining Ring	
48	4	9006320-0062	Pin	
49	2	9004830-6201	Front Cover Gasket	•
50	1	9230124	Pin	
51.	2 .	9004800-3708	Front Cover	
52	. 1	9230128	Washer	• •
53	· 12	9009610-4778	Hex Head Screw	
54	4 & 8	9007200-4422 & 4424	Seal	•
55	. 1	9240147	'O' Ring	_
56	2	9004102-1360	Seal Spring	7
57	. 8	9220242	Groove Pin	
58	1	9004610-1212		
59	1	9004100-2380	'O' Ring	
60	1	9240093	Seal Retainer	Articles of State Control
61	1	9006201-0387	Retaining Ring	- <del>- Leader Eligi</del> ca
62	4	9007300-1906	Socket Head Screw	. **
63	. 2	9 <b>2</b> 20419	Sleeve Retainer	•
64	4	9005001-0600	Plug	
65	2	9220691	Servo Sleeve	•
66 .	2 •	9004100-1440	'O' Ring	• •
67	; <b>Ž</b>	9004100-1420	'O' Ring	
68	2	9007200-2508	Cap Screw	
69	` Ž	9009625-2601	Washer	•
	2	9220479	Spring Guide	
70	2	9220436	Servo Spring	
71 73	2	9510014	Servo Piston	
72	2	9004830-6201	Pin ,	
73	4	9006320-0062	Retaining Ring	•
7 <del>4</del>	2	9230151	Servo Link	
75	1	9230247	Pilot	
76	1	9006250-0250	Retaining Ring	
77	1	9230014	Spring Retainer	
78	1	9230015	Spring Guide	
79	1	9230011	Cylinder Block Spring	
80	. 1	9230013	Spring Seat	
81	9	9230012	Retainer Spring	·—
82	7	9220760	Pin	
83	1	9230248	Cylinder Block Assem	prà
84	1	· 9230158	Retainer Guide	
85	1	9230234	Slipper Retainer	
86	. 1	9230241	Piston Assembly	
87	9	9230235	Thrust Plate	•
. 88	1	9230235	Swashplate	
89	1	9230223	. <del>"</del>	

1 650 8524662


P.03/08

SPACE SYSTEMS LORAL

NOV-27-2001 16:45




# INSTALLATION PROCEDURE ORIFICING PUMP CONTROL TO SLOW RESPONSE CHANGING CONTROL OR CONTROL GASKET



- Wash all dirt from top of pump.
- Disconnect the case drain hose which runs between the pump and reservoir at the pump and raise as high as possible to keep loss of oil at a minimum.
- Remove (9) 1/4"-20 screws. 3.
- Raise pump control as high as possible and tilt toward front of pump. This should be done carefully to prevent damaging the pump control gasket and to 4. make sure the three "O" rings remain in place and are not jarred loose to fall inside the pump. (See #2)
- Inspect the control gasket and if it is damaged, it should be replaced. 5.
- Immediately cover the opening into the pump with a clean shop towel. This will prevent anything from falling into the internal parts of the pump while installing the orifice.
- To replace the control valve or the control valve gasket take the following 7. steps:
  - (a) Cover the opening into the pump housing with a clean cloth.
  - (b) Remove the orifice, if used, and the three "O" rings from the control valve housing.
  - (c) Remove the small cotter pin.
  - (d) Remove the small washer.

contain an "O"

ring.



Follow-up linkage

Orifice plug pressed into and held by "O" ring in Port #3.




View of Underside of Pump Control Fig 2

- (e) Remove the clevis pin. NOTE: The clearance between this pin and the three holes it passes thru is very small. Wiggling the control valve from side to side as the pin is pulled will ease the job of removing it. Do not
- (f) Put the new gasket in place. Coating the gasket with light grease will help
- (g) Place the link to the swash plate in the follow up linkage and push the clevis pin into place.
- (h) Put the washer on the clevis pin.
- (i) Put the cotter pin into place. Do not reuse the old cotter pin.
- Place the three "O" rings into place in the control valve housing. It is recommended that the "O" rings be coated with light grease to hold them in place. 8.
- Insert the orifice plug into the I.D. of the "O" ring in Port #3 (See Fig. 2). NOTE: The orifice is provided with a small projection or guide on one side. 9. This guide is designed to fit into the drilled hole in the control valve housing. The orifice plug is so designed that the slight press between it and the I.D. of the "O" ring will hold the orifice plug in place while the pump control is being bolted back down.
- Remove the cloth covering the opening into the pump. 10.
- Swing the follow-up linkage as far as possible toward the rear of the pump and lower the pump control to its normal position. 11.
- Replace the (9) 1/4"-20 bolts, tightening them SNUGLY. Replace case drain hose 12.
- Replace lost oil and run system for a short period and recheck for proper oil 13. level in reservoir.
- Reconnect the linkage to the control and if necessary, readjust the mechanical "stops" so that the mechanism driven by the pump operates at the desired speed. 14.

# REPLACEMENT PROCEDURE CHARGE PUMP CHECK VALVES





# Replacement Procedure

- 1. Wash all dirt from pump.
- 2. Disconnect the suction hose between the reservoir and charge pump at the charge pump. Raise the loose end as high as possible to minimize the loose of oil.

Fig. 1

- Disconnect the pump case drain hose (not the large high pressure liese to the top case drain port in the pump. This is the hose running between the pump and the cooler or reservoir. Raise the loose end as high as pressible to minimize the loss of oil. The high pressure hose is shown disconnected in Fig. 1 for clarity only.
- Remove two 1/4-20 hex. head cap screws from each side of the charge pump.

  Do not loosen the two screws located one at the top and one at the bottom.

  These two screws are used to hold the charge pump together and are not attached to the end cap.
- 5. Remove the charge pump assembly. This assembly is located by a spread pin. It may be necessary to wiggle the charge pump to overcome the friction of this spread pin. Do not use a screwdriver or anyother tool to force the

charge pump away from the main pump. NOTE: Note position of tang on charge pump shaft. If the shaft is then turned, it can be returned to its original position, making reassembly of the tang into the slot of the main pump drive shaft much easier.

- 6. Remove the two check valves. This can be done with a wide bladed screen driver or flat piece of metal approximately 3/32" thick by 5/8" wide used.
  - Install the two new check valves. Seat the "O" rings with light greaters proved their being damaged as the valve is screwed into place. Make the valves are turned in tight.
- Install the charge pump gasket. If the gasket is damaged in any way, if about the replaced.
- 9. Install the charge pump. Slip body onto the spread pin and tighten the thin bolts. Forque the bolts to 70-75 meh pounds. NOTE: The tang on the charge pump drive shaft must be aligned with and engaged into the corresponding slot in the main pump drive shaft.
- Reconnect hoses.
- 11. Replace lost oil.
- 12. Start vehicle engine at a slow idle for approximately two minutes. Check oil level to be sure its at the level called out in the vehicle specifications.

Sundstrand Hydro-Transmission Bulletin #9422 January, 1965

SPACE SYSTEMS LORAL


PARTS LIST

Variable Displacement Pump


Model 23-2036

	_	Part Number	Part Description	
Ref #	<u>Qty</u>		Hex Head Screw	
	4	9007200-2536	Washer	
2	4	9009610-2850	Charge Pump Assembly	
3	1	9801038-03	Charge Pump Gasket	
4.	1	9801074	Check Valve Assembly	
5	2	9800648	er1, 37a lara	
5A	2	9800721	-	• •
5B	. 2	9004101-0150	'O' Ring	- المراق
6	4	9007200-4430	End Cap Screw	
7	- 4	9007200-4438	End Cap Screw	VIII 4
8	. 68	9009610-4778	" Washer	and the state of the state of
	1	9230285	End Cap	-42.
9	lA/R	9230482	Shim	,
10	INIK	9230127	End Cap Gasket	4
11	1	9001415-0002	Rear Bearing	
12	1	9001413-0002	Pin '-	•
13	. 1	-	Valve Plate	
. 14	7	9230197	Bearing Plate	
. 15	1	9230288 .	Pin .	
÷16	2	9004800-3708	'O' Ring	
17	1	9004101-0140	Pump Housing	
- 18	1	9230239	Hex Head Screw	
. 19	7	9007200-2530	Hex Head Screw	
20	2	9007200-2526	Washer	
21	9	9009610-2850	Jam Nut	
22	1	9003560-2500	Washer	
23	1	9009660-2500	Control Handle	
24	1 .	9800916	Spacer	
25	1	9800917	Cotter Pin	
26	1	9004600-0607		
27	1	9009610-2850	Washer Control Valve Assembly	
28	1	9800893		
29	_	9800432	Orifice	
30	_	9004101-0140	'O' Ring	
31	_	9801076	Pin	
. 32	• -	•	Not Used	
33	_	9800138	Control Valve Gasket	
34	<b>'</b>	9005001-1200	Plug	
	_	9005101-4400	Hex Head Plug	•
35	_	9004201-2500	'O' Ring	
36		9007200-4416	Hex Head Screw	
. 3*	•	9009610-4778	Washer	
	_	9230018	Trunnion	
3'	,	9230019	Shim	
. 4	_	9004100-2320	'O' Ring	
4	_	9001430-0001	Trunnion Bearing	
4		9230469	Drive Shaft	
	.3	9001435-0001	Front Bearing	
	.4 1	9800210	Connecting Link	
	.5 1	9006320-0025	5!	
4	<u> 2</u>	700072040025	<del>-</del>	

DEC-03-2001	16:13	SPACE SYSTEMS LORAL	1 650 8524662	P.02/03
		23-2036		
•	•	9004830-2501 -	Pivot Pin	•••
47	1	9004330-0062	Retaining Ring	
48	4	9004830-6201	Pin	
. 49	2	9230124	Front Cover Gasket	
50	1	9004800-3708	Pin _	
51.	2	9230128	Front Cover	• •
52	· 1	9009610-4778	Washer	
53	· 12	9007200-4422 & 4424	Hex Head Screw	
54	4 & 8	9240147	Seal	
55	. 1	9004102-1360	'O' Ring	
<sub>.</sub> 56	2	9220242	Seal Spring	
57	. 8	9004610-1212	Groove Pin	,
58	1	9004100-2380	'O' Ring	
59	1	9240093	Seal Retainer	And the same
60	1	9006201-0387	Retaining Ring	
61	1	9007300-1906	Socket Head Screw	
62	4	9220419	Sleeve Retainer	
63	2	9005001-0600	Plug	
64	- 4	9220691	Servo Sleeve	
65	2	9004100-1440	'O' Ring	• .
66 .	2 •	9004100-1420	'O' Ring	,
67	: 2	9007200-2508	Cap Screw	
68	2	9009625-2601	Washer	
69	. 2 2	9220479	Spring Guide	0
70		9220436	Servo Spring	
71	2 2	9510014	Servo Piston	
72	2	9004830-6201	Pin ,	1
73	4	9006320-0062	Retaining Ring	•
74	2	9230151	Servo Link	
75	_	9230247	Pilot	
76		9006250-0250	Retaining Ring	
77	-	9230014	Spring Retainer	
78	-	9230015	Spring Guide	,
79	_	9230011	Cylinder Block Spring	
80		9230013	Spring Seat	
81	_	9230012	Retainer Spring	: <del></del>
82	•	9220760	Pin Cylinder Block Assen	ably
83		9230248	Cylinder Block 21020	
84	_	. 9230158	Retainer Guide	
8:		9230234	Slipper Retainer	
8	_	· · · · · · · · · · · · · · · · · · ·	Piston Assembly	٠.
8	٠ .		Thrust Plate	
			Swashplate	•
8	19	,	•	




# INSTALLATION PROCEDURE ORIFICING PUMP CONTROL TO SLOW RESPONSE CHANGING CONTROL OR CONTROL GASKET



- Wash all dirt from top of pump.
- Disconnect the case drain hose which runs between the pump and reservoir at the pump and raise as high as possible to keep loss of oil at a minimum.
- Remove (9) 1/4"-20 screws. 3.
- Raise pump control as high as possible and tilt toward front of pump. This should be done carefully to prevent damaging the pump control gasket and to make sure the three "O" rings remain in place and are not jarred loose to fall inside the pump. (See #2)
- Inspect the control gasket and if it is damaged, it should be replaced. 5.
- Immediately cover the opening into the pump with a clean shop towel. This will prevent anything from falling into the internal parts of the pump while 6. installing the orifice.
- To replace the control valve or the control valve gasket take the following 7. steps:
  - (a) Cover the opening into the pump housing with a clean cloth.
  - (b) Remove the orifice, if used, and the three "O" rings from the control valve housing.
  - (c) Remove the small cotter pin.
  - (d) Remove the small washer.

contain an "O"

ring.



Follow-up linkage

Orifice plug pressed into and held by "O" ring in Port #3.




View of Underside of Pump Control Fig 2

- (e) Remove the clevis pin. NOTE: The clearance between this pin and the three holes it passes thru is very small. Wiggling the control valve from side to side as the pin is pulled will ease the job of removing it. Do not
- (f) Put the new gasket in place. Coating the gasket with light grease will help
- (g) Place the link to the swash plate in the follow up linkage and push the clevis pin into place.
- (h) But the washer on the clevis pin.
- (i) Put the cotter pin into place. Do not reuse the old cotter pin.
- Place the three "O" rings into place in the control valve housing. It is recommended that the "O" rings be coated with light grease to hold them in place. 8.
- Insert the orifice plug into the I.D. of the "O" ring in Port #3 (See Fig. 2). NOTE: The orifice is provided with a small projection or guide on one side. 9. This guide is designed to fit into the drilled hole in the control valve housing. The orifice plug is so designed that the slight press between it and the I.D. of the "O" ring will hold the orifice plug in place while the pump control is being bolted back down.
- Remove the cloth covering the opening into the pump. 10.
- Swing the follow-up linkage as far as possible toward the rear of the pump and 11. lower the pump control to its normal position.
- Replace the (9) 1/4"-20 bolts, tightening them SNUGLY. Replace case drain hose 12.
- Replace lost oil and run system for a short period and recheck for proper oil 13. level in reservoir.
- Reconnect the linkage to the control and if necessary, readjust the mechanical "stops" so that the mechanism driven by the pump operates at the desired speed.

Sundstrand Hydro-Transmiss Bulletin #9423 January, 1965

# CHARGE PUMP CHECH VALVES

SS/L



# Replacement Procedure


- Wash all dirt from pump.
- Disconnect the suction hose between the reservoir and charge pump at the charge pump. Raise the loose end as high as possible to minimize the loss of oil.
- Disconnect the pump case drain hose (not the large high pressure hose) at the top case drain port in the pump. This is the hose running between the pump and the cooler or reservoir. Raise the loose end as high as possible to minimize the loss of oil. The high pressure hose is shown disconnected in Fig. 1 for clarity only.
- Remove two 1/4-20 hex. head cap screws from each side of the charge pump. Do not loosen the two screws located one at the top and one at the bottom. 4. These two screws are used to hold the charge pump together and are not attached to the end cap.
- Remove the charge pump assembly. This assembly is located by a spread pin. It may be necessary to wiggle the charge pump to overcome the friction of this spread pin. Do not use a screwdriver or anyother tool to force the

(Over)

charge pump away from the main pump. NOTE: Note position of tang on charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft much easier.

- Remove the two check valves. This can be done with a wide bladed screw-driver or flat piece of metal approximately 3/32" thick by 5/8" wide used as a screwdriver.
- 7. Install the two new check valves. Coat the "O" rings with light grease to prevent their being damaged as the valve is screwed into place. Make sure the valves are turned in tight.
- 8. Install the charge pump gasket. If the gasket is damaged in any way, it should be replaced.
- 9. Install the charge pump. Slip body onto the spread pin and tighten the four bolts. Torque the bolts to 70-75 inch pounds. NOTE: The tang on the charge pump drive shaft must be aligned with and engaged into the corresponding slat in the main pump drive shaft.
- 10. Reconnect hoses.
  - 11. Replace lost oil.
  - 12. Start vehicle engine at a slow idle for approximately two minutes. Check oil level to be sure its at the level called out in the vehicle specifications.

Sundstrand Hydro-Transmission Bullerin #9422 January, 1965



#### HEAVY DUTY TRANSMISSION START-UP PROCEDURE

Before installing a transmission on a machine, inspect the transmission for damage in shipping or handling. All tools, pans, cans, plugs, etc., must be clean prior to use on the system.

Never use drained oil.

- (1) After the units have been installed, remove the threaded plug in the charge pressure port from the side of the main pump housing (See Figure 1). Install a 600 PSI gauge with a short section of hose to this port. The threaded plug may be either 1/8 NPT or 7/16-20 straight thread.
- (2) Check all fittings to be sure they are tight.
- (3) Loosen the charge pump line at the inlet to the charge pump (See Figure 1).
- (4) Fill the pump case through the case drain opening with an approved oil (See last page for oils)
- (5) Fill the reservoir with an approved oil. When oil appears at the loosened hose at the charge pump inlet, tighten the hose and continue filling the reservoir. Leave reservoir cap loose so air will escape.
- NOTE: If gravity feed does not fill the line to the charge pump, it must be filled by hand.
- (6) The pump must be in neutral. It is recommended that the control linkage be left disconnected until after initial start-up.
- (7) With the coil wire removed or the rack closed, turn the engine over for fifteen seconds.
- (8) Start the engine maintaining as low an idle as possible for five minutes. During start-up, pressure surges will be seen on the 600 PSI gauge. While running at low idle, charge pressure must be above 100 PSI. If it is not, shut down and trouble shoot according to Bulletin 9454.

Cont. on Page 2

Cont. from Page 1

- (9) Increase engine speed to approximately 1000 RPM. Charge pressure on the 600 PSI gauge should be 180-220 PSI.
- (10) Shut down engine and connect linkage to displacement control.
- (11) Check fluid level in reservoir and add an approved oil if necessary.
- (12) Start engine and run at 1500 to 2000 RPM. Charge pressure should be 180-220 PSI.
- (13) Move the directional control handle slightly to the forward and reverse position. Charge pressure will drop to 150-190 PSI when pump is in stroke.
- (14) Should the charge pressure fall below 100 PSI during the start-up procedure discontinue start-up until trouble has been found. See trouble shooting Bulletin #9454.
- (15) Shut down engine, remove gauge and replace plug in gauge port. Check reservoir oil level and tighten oil fill cap.

Machine is now ready for operation.

HEAVY DUTY VARIABLE DISPLACEMENT PUMP




Figure I.

### RECOMMENDED OILS

Approved oils for Use in Sundstrand Hydrostatic Transmissions

Approval has been given for the following oils for use in Sundstrand Hydrostatic Transmissions:

For operating temperatures above 10°F.

- I. Mobilfluid 300 from the Mobil Oil Company.
- 2. Rykon Industrial Oil No. 21 or American Hydraulic Oil All Weather from the American Oil Company.
- 3. Hy-Tran from International Harvester.

NOTE: For "make-up" in the field when the above oils are not available Type A - Suffix A automatic transmission fluid (Mobilfluid 200 from the Mobil Oil Company) may be added.

These oils may be mixed in any ratio to fill a system as they are compatible.

For operating temperatures below 100F.

1. Mil-H-5606 Hydraulic Fluid.

NOVEMBER, 1966 BULLETIN 9429

#### STANDER TO A TOWN OF THE REPORT OF THE ANDREAD ISSUED A

## VARIABLE PUMP OR VARIABLE MOYOR DISASSEMBLY PROCEDURE

### 1. Remove pump from the installation or vehicle.

- A. If possible, the pump should be steam cleaned while still on the vehicle or installation and before any hose is disconnected. If a steam cleaner is not available, wash the pump, especially the fittings, with fuel oil or suitable solvent. Do not use paint thinner or acctone. Remove any dirt from the vehicle or installation which could be accidently dislodged and enter the pump during the reinstallation procedure.
- B. Disconnect all hose. In most cases, it is recommended that the oil be discarded and replaced with new oil when the system is again started.
- C. Remove the mounting bolts and set the pump on a clean work bench. A few minutes spent cleaning off a work bench before starting to work will save time later as the work progresses.

  Putting a drip pan approximately 18" square by l" deep under the pump will help to keep the oil, that is still in the pump, off the work bench and floor.

### 2. Remove the shaft scal (Item 1).

A. A few pumps are designed with a seal that is held in place with four cap screws. Most seals are held in place with a large snap ring (Item 45). Remove either the cap screws or the snap ring as the case may be.

00:02

NOV-28-2001

- retainer can usually be removed without the use of tools. Due to the squeeze on the "O" ring (Item 1A), the seal retainer (Item 47) and the steel half of the seal (Item 1C), Items 1A, 1B and 1C will all be removed with the seal retainer. Set this group aside in a place where the seal cannot be damaged by a stip of a wrench.

  NOTE: Unless the seal is going to be replaced, the lapped surface of the steel half of the seal (Item 1C) should be protected from damage at all times.
- C. Remove the bronze half of the seal (Item ID). This part is held in place by the squeeze on the "O" ring (Item IF). It can usually be wiggled off the shaft with the fingers. A few seals incorporate a small spread pin in the drive shaft to "drive" the bronze half of the seal. In a very few cases, this pin may have worn a groove into the I.D. of the seal half. If so, hold the shaft stationary and rotate the seal half as far as it will go in the direction of shaft rotation. This will again line up the slot in the seal half with the drive pin and the seal half can be removed. However, once in awhile even after the drive pin is lined up with the slot, it may be necessary to pry the part loose by using two screw drivers. If this is necessary, make sure all pressure is applied against the sides of the seal half and that the lapped scaling surface is not damaged in any way.

NOV-28-2001 00:02

### 3. Remove the charge pump litem 22%.

- A. The charge pump is held in place by four boits (Item 21) located clong the straight sides of the charge pump. The other two bolts located on the top and bottom portion of the charge pump are used to hold the three main sections of the charge pump together when it is removed from the main pump.
- B. The charge pump is "located" by a spread pin between it and the end cap of the main pump. Due to the drag of this pin, It may be necessary to "work" the charge pump up and down while pulling to separate it from the main pump. DO NOT PRY with a screw driver or other tools!
- C. Remove and inspect the charge pump gasket (Item 20). If it is all right, lay is aside with the charge pump. If it is damaged in any way, it should be replaced.
- 4. Remove the two check valves (Item 24). The body of the check valve assembly is threaded. The whole check valve assembly can be removed by unscrewing it from the end cap. The check valves are turned in quite tight at the factory, and it may be necessary to use a small drag link socket or equivalent to remove them.

### 5. Remove the end cap.

A. The end cap is held by eight hex head bolts (Item 19) and is positioned by two dowel plus (Item 26). Usually as the last bolt is removed, the end cap will be pushed away from the housing a short distance. If this does not happen, it will be necessary to break it loose by the careful use of a plastic or babbit hammer. NOTE:

Never force a screw driver or wedge between any two surfaces of any Sundstrand product.

- R. The valve plate (Item 52) is loosely doweled (Item 51) to the end cap for position only. However, due to the extreme flatness of the face of the end cap and the mating surface of the valve plate, an oil seal will exist between these two parts causing the valve plate to cling to the end cap. On occasion, the brass bearing plate (Item 53) will, for the same reason, cling to the valve plate. Therefore, as the end cap is lifted, extreme caution should be exercised to prevent the valve plate from being damaged should it become loose and fall.
- C. Set the end cap aside with the lapped surface up. The lapped surface should be protected from damage at all times.
- 6. Remove the end cap gasket (Item 15) and "O" ring (Item 17). If either is damaged, they should be replaced.
- 7. Remove the valve plate (Item 52). If the valve plate remained on the end cap, they can be separated by first washing both parts with clean fuel oil or solvent. This will break the oil scal and the parts can then be easily separated.

If the valve plate remained with the brass bearing plate in the pump, it can be removed by sliding it to one side off the valve plate and lifting.

8. Remove the brass bearing plate (Item 53). The material in this plate is relatively soft and can be easily scratched and damaged. Wash the plate with clean fuel oil or solvent to break the oil seal and lift the plate from the cylinder block (Item 55). There are drain slots milled into the back of the brass bearing plate running radially to the outside diameter.

SS/L

P.05/11

As an aid in removing the mass bearing plate, a crass pry can be carefully inserted into one of these drain grooves and the bearing plate lifted. Do not force these two pieces apart at any other point other than at the drain slots.

- Remove the rear bearing (Item 50). Use a standard bearing puller to pull the rear bearing. Be sure you can rotate bearing cage while pulling. Pull only on the inner race not the cage or rollers. The pump shaft should be protested from damage by placing a suitable piece of metal between the rain of the puller and the shaft. NOTE: The face of the cylinder block (Item 55) is a lapped surface and can be easily damaged by careless handling of the puller while assembling the jaws under the bearing.
- Remove the spring guide (Item 72). This part is a sleeve type spacer and is not held in place by any mechanical tie.
- Remove the cylinder block (Item 55): Place the pump housing (Item 39) 11. in a horizontal position. Grasp the block with the fingers and pull. The piston assemblies (Item 56) and retainer (Item 63) usually stay in the
  - housing and have to be removed later. However, if it is possible to remove the block with the pistons still in place, it simplifies the job.
- 12. Remove the slipper retainer guide (Item 62). If the pistons came out with the block as it was removed, this step has been taken care of. If it stays in the housing, rotate the guide slightly until the two splines are again lined up and slip it back down the shaft (Item 48) and out of the hous-

SS/L

P.06/11

ing. A few pumps contain spacers located inside the guide and fitting between the guide and the neck of the cylinder block. They should be discarded and not returned to the pump during reassembly.

- 3. Remove the nine pistons (Item 56) and the slipper retainer (Item 65).

  If the pistons remained in the clock as it was removed, this step has been taken care of. If hey remained in the housing, insert your hand or hands, as space allows, into the housing and gather up all nine pistons. This will prevent their lodging against the sides of the housing hampering their removal. Some or all of the slippers may form an oil seal with the thrust plate (Item 64) making it necessary to pail on that piston individually to break it loose.
- 14. Remove the thrust plate (Item 64). This part is cradled in the swash plate (Item 61) with very little side clearance. If the pump is to be completely disassembled, it is easier to remove the thrust plate after the swash plate has been removed from the housing. If the swash plate is not going to be removed, a metal rod approximately 10" long with a small book approximately 1/16" high on the end makes a good tool for removing the thrust plate. Two notches are provided in the L.D. of the swash plate on a plane parallel to the center line of the trunnions. These notches provide clearance behind the thrust plate permitting the engagement of the hook. By pulling first on one side and then the other, the thrust plate can be "worked" out of the swash plate and removed.

- eight bolts (Item 2) and positioned by two dowel pins (Item 3). It may be necessary to jar the cover loose with a plastic or babbit hammer. Do not drive a screw driver or wedge between the cover and housing.
- 16. Remove the front cover gasket (Item 42). If necessary, scrape both the front cover and pump housing free of any particles of gasket materaial that might have remained on either.
- 17. Remove the drive shaft (Item 48). With the front cover removed, the shaft will easily slide out the front of the housing.
- 18. Remove the control valve assembly (Item 14).
  - A. Remove the eight cap screws (Item 13) which hold the control in place and lift the control assembly as high as possible.
    - B. Remove the small clevis pin (Item 9) which connects the two followap links on the control with the connecting link attached to the swash plate. If the control valve assembly (Item 14) is being removed without the rest of the pump being disassembled, it is strongly recommended that before removing the small cotter key (Item 10) used to hold the clevis pin, a long place of tag wire or equivalent be run through the eye of the cotter key. This will prevent the cotter key from accidentally falling into the pump if dropped.

The clevis pin (Item 9) can now be removed. The clearance between the O. D. of the body of this pin and the I. D. of the three holes it passes through is very small; therefore, the pin does not slide out easily. Wiggling the control housing (Item 14) as you pull on the

SS/L

trol valve assembly (Item 14) is being removed without the pump being disassembled, take care not to drop the clevis pin isside the pump housing. If you do and it cannot be fished out with a magnet, it will be necessary to disassemble the pump piece by piece until the clevis pin is found.


Lay the control valve assembly aside. Further disassembly of this valve is usually not necessary. It should be thoroughly washed and blown out with compressed air.

- 19. Remove the trunnions (Item 59). Remove the three bolts (Item 66) that hold each trunnion in place. Use a spanner wrench and rotate the trunnion back and forth with one hand as you push on the inside face of the trunnion with the other hand. It is necessary to overcome the drag of the "O" ring (Item 53) to remove the trunnion. The inner race of the trunnion bearing (Item 50) usually, but not always, comes out with the trunnion.
- 20. With the trunnions removed, it is now possible to lift the swash plate (Item 61) out of the Mousing.

The pump is now completely disassembled. All parts should be inspected. Those needing to be replaced should be replaced and those needing rework, reworked. Thoroughly wash all parts in clean solvent or fuel oil and then heep them clean. Wrap them in either clean rags or plastic. If the parts are to remain disassembled for any period of time.

they should be protected from rust and accidental damage. You can save yourself a lot of time and effort by not allowing any lapped surface to become scratched or nicked. The parts of any quality piece of hydraulic equipment do not have to be treated like the parts out of a watch; but on the other hand, due to the high pressures the pumps and motors are required to handle today, any abuse to the parts during the repair procedure will result in an inefficient or inoperative unit after it is assembled.

Sundstrand Hydro-Transmissic Bulletin #9427 January, 1964 Revised: March, 1965



### <u> PUMP REASSEMBLY</u>

The primary thing to keep in mind when assembling any piece of hydraulic equipment is cleanliness. The same care and cleanliness should be extended to the parts of the pump that would be extended to the injectors of a diesel engine. Just prior to assembly, each part, old and new and especially those with lapped surfaces, should be carefully, but thoroughly, scrubbed to remove any trace of dirt or lapping compound. As the parts are assembled they should be liberally covered with the type oil the pump will eventually operate in. Never allow two unlubricated surfaces to move against each other.

The following is a step-by-step procedure to follow in reassembling the pump.

1. Replace Bearings, if necessary (Items #50, #60, #63).

If necessary, replace any of the four tapered Bearings. This should be done with care. If possible they should be pressed rather than driven into place.

BEARING FITS

		BENEING ELTS	
Bearing		Mating Part	Fit
	Cup*	Front Cover (Item #43)	Slip
Front	Cone	Drive Shait (Item #46)	Press
Item #63 Rear Item #50		End Cap (Item #16)	Slip
	Cup	Drive Shaft (Item #46)	Press
	Cone		Press
Trunnion Item #60	Cup	Swash Plate (Item #61)	Slip
	Cone	Trunnion (Item #59)	92.0
		Trunnion (Item #59)	Sli

- \* Sec procedure for establishing shaft end play Step #3.
- \*\* Do not press the cone of the Rear Bearing onto the Shaft until the Cylinder Block is in place, see Step #19, or unless the drive shaft end play is to be checked, see Step #3.
- 2. Set preload on Trunnion Bearings (Item #60).

If either a new Swash Plate (Item #61), Trunnion (Item #59), or Trunnion Bearings (Item #60) were replaced or if the plastic Trunnion Gaskets (Item #57) were lost, it will be necessary to establish the desired preload on the Trunnion Bearings as follows.

الإنجاب وروعة فالك

- A. Ramove the "O" Rings#from the Trunmions.
- B. Return the same thickness of Gasket (Item #57) to each Trunnton that was present when the pump was disassembled.
- C. Slip the Trunnion Bearing Cones onto the Trunnions.
- D. Place the Swash Plate (Item #61) in the Housing, lining up the bearing races with the Trunnion cores in the Housing (Item #39).
  - E. Insert the Trunnions, minus the "O" Rings, into the Housing and Swash Plate. The clearance between the Trunnions and their bores in the Housing is small, therefore, it is easy to bind the Trunnions as they are being put into place. A plastic hammer may be used to lightly tap the Trunnions as an aid in assembly.
  - F. Tighten one Trunnion Bolt (Item #66) on each Trunnion.
  - G. Attach a spring scale to either of the two bores for the Swash Plate Pin (Item #41). With the proper thickness of Trunnion Gaskets, it will require between 3 and 4 pounds pull to move the Swash Plate. Add or subtract Gaskets (Item #57) until this reading is obtained. Gaskets should be added or subtracted evenly to each side. The total thickness of Gaskets on one Trunnion should not exceed the total thickness of Gaskets on the other by more than .005".
- H. When the proper preload is established, remove the Trunnions from the Housing.
- 3. Set Shaft end play. (Should be .003" to .013")

If a new Drive Shaft (Item #48), End Cap (Item #16), Front Cover (Item #43), and Front Bearing (Item #63) are used, the Shaft end play should be checked as follows.

- A. Press the Cone of both the Front and Rear Bearings onto the Drive Shaft.
- B. Install the End Cap Gasket (Item #15) and End Cap (Item #16).
- C. Tighten two of the End Cap Bolts to 27-30 ft. lbs.

- D. Put the Front Cover Gasket (Rem #42) ento the Housing,
- E. Place the Drive Shaft in the Housing with the Cone of the Rear Bearing in its Cup.
- F. Place the Front Cover (Item #43) into place.
- G. Tighten at least one bolt (centrally located) on each side to 27-30 ft. lbs.
- H. The end play of the Shaft can now be checked and should be between .003" and .013".
- 4. Assemble the Servo Pistons (Item #35).

NOTE: If the old Swash Plate (Item #61), the two Servo Piston Assemblies (Items #27 thru #41), and the two Servo Sleeves (Item #17) are to be reused, they should all be returned to the same position they were removed from. See Step #10 for the correct procedure to follow to set the neutral position of the Swash Plate if any of these parts are replaced with new or if the parts have become mixed up.

- A. Check the grooves on the O.D. of the Servo Piston (Item #35) making sure there are no burrs or foreign material present.
- B. Place the Servo Control Spring (Item #28) in the I.D. of the Servo Piston (Item #35).
- C. Insert the Spring Guide (Item #27) into the Servo Control Spring.
- D. Insert the 1/4-20 screw (Item #29) into the Washer (Item #30) and drop both into the I.D. of the Spring Guide so the screw threads extend thru the hole in the end of the Guide.
- E. Compress the Servo Control Spring until the 1/4-20 screw can be engaged and tightened into the Servo Piston.
- F. Place the Servo Piston Link (Item #38) into the Clevis of the Servo Piston.
- G. Insert the Servo Piston Pin (Item #37) into place. pinning the Link to the Swash Plate.

- .H. .Faster the Serve Piston Pin into piece with two Snap Rings (Item #36).
- I. Assemble the other Piston Assembly in the same manner.
- 5. Attach the Servo Piston Assemblies to the Swash Plate.
  - A. Lay the Swash Plate flat on the workbench and place the free end of the Servo Piston Links (Item #38) into the two Clevises provided on the Swash Plate. The joggle in the Servo Piston Link should be arranged so that the Pistons are "stepped" outward from the center line of the pump.
  - B. Insert the two Swash Plate Piston Pins (Item #41) thru the Clevis of the Swash Plate, pinning both Links to the Swash Plate.
  - C. Fasten the pin in place with two Snap Rings (Item #40).
- 6. Attach the Control Link (Item #7) to the Swash Plate.
  - A. Position the Control Link (Item #7) in the Clevis provided in the Swash Plate.
  - B. Insert the Clevis Pin (Itam #6) into place pinning the Link to the Swash Plate.
  - C. Fasten the Pin in place with two small Snap Rings (Item #5).
- 7. Install the Swash Plate (Item #61).
  - A. Set the pump Housing on the bench with the Front Cover opening facing you and the opening for the Control upward.
  - B. Insert the Swash Plate with the Servo Piston Assemblies and Control Link attached into the Housing. As this is done, the two Servo Pistons should be placed into the openings provided for the Servo Sleeves. This should be done with care to prevent damage to the Pistons.

NOTE: Make sure the Swash Plate is positioned so that the Control Link (Item #7) is next to the opening provided in the Housing for the Control Assembly (Item #14), and pointing toward the End Cap (rear) end of the Housing.

- 6. instal the Trunnions.
  - A. Cover the Trunnion "O" Rings (Item #56) with grease and put them in place on the Trunnions. The grease is used to prevent the "O" Ring from being damaged as the Trunnion enters the Housing.
  - B. Place the Tournions thru the bores in the Housing and into the Swart Plate. The clearance between the Trunnion and its bore is small and it is, therefore, easy to bind the two parts together. A plastic or babbit hammer thay be used to lightly tap the Trunnion "home", if necessary.
  - C. Tighten the Trunnion Bolts (Item #66) to 27-30 ft. lbs.
  - 9. Install the Servo Sleeves (Item #18).
    - A. Cover the "O" Rings (Items #33 and #34) with grease and put them in place on the Sleeves.

NOTE: "O" Ring (Rem #34) is slightly smaller in O.D. than (Rem #33) and goes in the groove toward the open end of the Sleeve.

- B. Turn both Sleeves into the Housing until the scribed lines on the Sleeves and those on the Housing line up. These lines should have been scribed at the factory during the original assembly or at the time of disassembly. If the Swash Plate, all parts of the Servo Piston Assemblies and both of the Servo Sleeves are to be returned to the pump and not replaced with new parts, linking up the scribed marks will return the Swash Plate to its neutral position.
- 10. Setting neutral position of Swash Plate.

If any of the parts mentioned in Step #9B were replaced with new parts or as a check to make sure the Swash Plate is in absolute neutral, the following procedure should be used.

A. Turn both Servo Sleeves into the Housing as evenly as possible, until all angular play is taken out of the Swash Plate. This will happen when the Servo Sleeves are both just touching the Spring Guides (Item #27). Do not turn the Sleeves in beyond this point causing any compression of the Servo Control Spring (Item #28).

SS/L

Using a depth miles measure from the machined surface of the He sing, which makes contact with the End Cap Casket, to the machined surface of the Swash Plate. This is the surface against which the Thrust Plate bears. The massurement should be made at two points equally spaced from the center line of the pump and as near to the outside liameter of the machined recess as possible. Measure one side then the other. Note which side is low and back off (tern counterclockwise) the Servo Sleeve nearest this side 1/8 - 1/4 turn. Turn the other Sleeve in (clockwise) a like amount or until the angular free play is again removed from the Swash Plate. Repeat this process until the machined recess of the Swash Plate is absolutely parallel to the machined surface of the Housing which touches the End Cap Gasket and there is absolutely no angular free play in the Swash Plate.

Install the Sleave Retainer (Item #31).

Use the Socket Head Set Screws (Item #32) previously removed. Use a screwdriver to set Retainer in slot in the Sieeve to prevent the sleeve rotation.

- Install the Control Assembly (Item #14).
  - Put the Control Casket (Item #4) in place.
  - Cover the three "O" Rings (Item #12) with grease to hold them in place and put them in the recesses provided in the Control Valve Housing.
  - If used, press the Orifice Plug (Item #11) into "O" Ring in the middle port in the Control Valve Housing.
  - Place the Swash Plate Link (Item #7) between the "Follow-Up" Linkage of the Control.
  - Put the small Snap Ring in the groove in the Clevis Pin (Item #9) and insert it thru the "Follow-Up" Links and the Swash Plate Control Link.
  - Place the small Washer (Item #8) on the Clevis Pin.
  - Insert the small Cotter Pin (Item #10) thru the Clevis Pin. Do not use the old Cotter Pin.
  - Fasten in place using the proper bolts (Item #13). Tighten to 85-90 in. lb. NOTE: Be sure to put the proper length bolt in the correct hole.

12. Install the Thrust Plate (Item #64).

Place the Thrust Plate into the machined recess in the Ewash Plate. The chamfored side goes against the Ewash Plate. The clearance between this Plate and its recess is small, therefore, care should be taken to insure it lies flat.

13. Install the Drive Shaft (Item #46).

If the Cone of the Rear Bearing was pressed onto the Drive Shaft to establish the shaft end play, it should be removed at this time. The cone of the Front Bearing should be in place. Slide the Shaft thru the I.D. of the Swash Plate from the Front Cover End taking care not to move the Thrust Plate out of position.

- 14. Install the Front Cover Gasket (Item #42).
- 15. Install the Front Cover (Item #43).

Tighten the bolts that hold it in place to 27-30 ft. lbs.

- 16. Assemble the Cylinder Block.
  - A. If a new Cylinder Block (Item #55) is used or if the old Block was completely disassembled, it will be necessary to assemble the Spring Seat (Item #68), the Block Spring (Item #54), the Spring Retainer (Item #69) and Retaining Ring (Item #70) into the Block as follows.
    - (1) Place the Spring Seat (Item #68) into the Block. The chamfered side of this part goes toward the spline end of the Block.
    - (2) Drop the Block Spring into the Block.
    - (3) Place the Spring Patainer (Itam #69) on top of the Block Spring with the notched side toward the face of the Block.
    - (4) Secure a bolt at least approximately an inch longer than the Block. Slide a washer (or washers) with an O.D. larger than the I.D. of the Block Spline. Slide this bolt thru the Block and place a washer (or washers) on the other end that is slightly smaller in O.D. than the O.D. of the Spring Retainer (Item #69).

Tighten a nut onto the bolt until the Block Spring is compressed enough for the Spring Retainer to move past the groove for the Retaining Ring (Item #70).

- (5) Assemble the Rataining Ring into the slot provided in the I.D. of the Block and remove the bolt and washers.
- (6) Put nine (9) Slipper Retainer Springs (Rem #67) into the Block. Place the Recainer Guide (Rem #62) on the Block. The missing tooth of the spline in the Guide should be lined up with the missing tooth in the spline of the Block. Cover the Guide with oil.
- (7) Place the nine (9) Piston Assemblies (Item #56) into the Slipper Retainer (Item #65).
- (8) Assemble the nine (9) Pistons into the Block. This is easiest done by holding the Slipper Retainer over the Block so that the Pistons will barely enter the bores. When all nine (9) Pistons are started in the bores, lower the Slipper Retainer to the Retainer Guide and push all nine (4) Pistons down into the Block.
- (9) Cover the Cylinder Block and Piston Assemblies liberally with clean oil.
- 17. Assemble the Cylinder Block Assembly into the Housing.
  - A. Lay the Housing on its side with the control up (Item #14).
  - B. Turn the Drive Shaft until the missing tooth in the spline is on top.
  - C. Pull the Drive Shaft as far as possible toward the front of the pump and clamp a collar or "C" clamp onto it to prevent it being bumped or pushed toward the rear of the pump as the assembly continues.
  - D. Pick up the Cylinder Block Assembly and slide it into the Housing and onto the Drive Shaft. It is necessary to line up the missing tooth on the Shaft with the missing tooth in the Retainer Guide and the Cylinder Block. Push the Block all the way "home".

P.09/13

16. Install the Spring Guide (Rem -72).

SS/L

This sheeve-like part is used as a spacer. It should slide freely onto the Shalt and into the Block. If it does not drop into place freely, the Block Spring is not concentrically positioned and should be moved into proper position with a screwdriver.

19. Press the cone of the Rear Bearing (Item #50) onto the Shaft.

This can either be done with an Arbor Press or a bearing puller. In either case, make sure the tool is clean and no dirt will fall into the pump. As the cone is pressed into position, the Retainer Springs (Item #67) will be compressed and the whole Cylinder Block Assembly will drop a quarter to three quarters of an inch, depending on the size pump, into the Housing.

20. Install the Bearing Plate (Item #53).

Set the pump Shaft downward on the block of wood used during disassembly.

NOTE: Do not bump or push the Shaft toward the rear of the pump. If this happens, the Shaft Spline can become disengaged with the Spline in the Retainer Guide and the two parts can then become out of phase. The Retainer Guide will, in this case, be extensively damaged as the End Cap is bolted in place.

Put the Dowel Pins (Item #71) into the Block. Make sure the face of the Cylinder Block and the Bearing Plate are absolutely free of any foreign material such as dirt, lint, etc. These two parts should lie absolutely flat against the other.

Cover the Bearing Plate liberally with oil.

21. Place the Valve Plate (Item #54) on the End Cap (Item #16).

Put the Cup of the Rear Bearing/and Dowel Pin (Item #51) in place in the End Cap. Make sure the End Cap and Valve Plate are free of any dirt or lint that would prevent the parts from laying absolutely flat against the other.

Cover the face of the End Cap with a thin, even coat of oil soluable grease such as vasoline. Put the Valve Plate (Item #52) into place and press it down into the grease.

- 22. Put the Eng Cap Gasket (Item #15), "O" Ring (Item #17), and Dowel Pins (Item #26) into place on the Housing. Coating the Gasket with a thin, even coat of light grease will make it easier to remove the Gasket should it be necessary to again service the pump in the future.
- 23. Install the End Cap (Item #16).

SS/L

Carefully pick up the End Cap, with the Valve Plate in place, turn it over, and lower it in place until the Valve Plate touches the Bearing Plate. This should be done carefully so as not to disloge the Valve Plate.


Tighten the End Cap Bolts to 27-30 ft. lbs.

- 24. Install the Charge Pump (Item #22).
  - A. Lay the pump on its side.
  - B. Place the Charge Pump Casket in place, making sure the opening for the Charge Pressure Relief Valve of the Charge Pump is not covered. This Casket can be put on in four different positions, three of which are wrong.
  - C. Make sure the Aluminum Spacer is in place over the Eler Shaft.
  - D. Line up the angle of the tang on the Charge Fump Shaft with the slot in the main pump Drive Shaft.
  - E. Insert the Charge Pump Drive Shaft into the main pump End Cap and the Charge Pump Body onto the Spread Pin used as a locator pin.
  - F. Tighten the four bolts that hold the Charge Pump in place to 85-90 in. lbs.
  - 23. Install the Shaft Seal (Item #1).
    - A. Gover the Shaft Seal "O" Ring (Item #1F) with grease and put it in place in the J.D. of the Shaft Seal (Item #1D).
    - B. Check the and of the pump Drive Shaft for any burns that would got the Shaft Seal "O" Ring. Slide the Shaft Seal (Frem #1D) that the Shaft and press it into place with the skirt had against the inner race of the Front Bearing.

- C. Place the Seal Springs (Item #1B) in place in the Seal Retainer (Item #2644/The Stop Pin (Item #46) should be driven securely into the Seal Retainer.
- D. Cover the Housing Seul "O" Ring (Item #1A) with grease and put it in place on the skirt of the Housing Seal (Lam #1C).
- E. Press the Housing Seal (Item #1C) into the Retainer with the fingers, engaging the Stop Pin in the slot in the Housing Seal. Press down on the Housing Seal, compressing the Seal Springs. Release the pressure and make sure the Seal Springs push the Housing Seal back to its original position. This will insure an even pressure being maintained between the Seal halves.
- F. Cover the Retainer "O" Ring (Item #1E) with grease and put it in place on the O.D. of the Retainer.
- G. Push the Retainer, as assembled in Steps D thrû F, into the Housing far enough to allow the Snap Ring (Item #45) to be put in place.
- H. Using a large set of Tru-Arc pliers, place the Saal Snap Ring in place.
- 26. Using a lever, such as a pair of Channel Locks, rotate the pump Shaft several revolutions by hand, making sure it turns fairly free.

If the pump is to be in storage for any length of time, it should be completely filled with oil and all ports plugged. Just prior to being installed on a vehicle, the Shaft should again be rotated several revolutions by hand.

Sundstrand Hydro-Transmission Bulletin #9428 February, 1965



### SUNDSTRAND HYDRO-TRANSMISSION SERVICE BULLETIN TROUBLE SHOOTING PROCEDURE

100

System\* Will Not Operate in Either Direction.

C	$\mathbf{a}$	u	S	e

- System Low on
- B. Faulty Control Linkage to Pump
- By-Pass Valve (If Used) Stuck Open-
- Disconnected Coupling
- or Zero Charge

### Remedy

- Check oil level in reservoir and reples necessary.
- Locate and fix leak or leaks causing the
- Check the entire linkage to make sure is cor l. nected and free to operate as it should
- Make sure the By-Pass or Dumping Valve is closing properly.
- NOTE: Do not confuse By-Pass Valve with the high pressure relief valves located in the motor manifold.
- Check to see that the coupling from the prime mover to the pump and the coupling from the motor shaft to the driven mechanism is not slipping or broken.
- 公場・金襴をよった こうしょうきょう まんしきょう かんご Install pressure gage (capable of 600 PSI) in either the 1/8 N.P.T. in the charge purity of in the side of the main pump.
- NOTE: Charge pressure may also be taken at taching a pressure gage to the port on the rear of the motor manifold (See Bulletin . #9438). This port, however, is blocked by the shuttle valve when the hydrostatic system is in neutral: therefore, the system. must be operating either in the forward or ma reverse direction to obtain a pres
- The word "system" denotes both pump and motor plus all lines, va filters, controls, etc., leading to and in between them.

SS/L

- 2 -

reading at this port. Operating pressure may also be taken at the manifold as explained in Bulletin #9438:

- Set pump speed to at least 500 RPM. Charge pressure should read at least 120 PSI or more when main pump control lever is in pumping position and fluid motor is operating.
- 3. Low charge pressure may be caused by
  - a. Charge pressure relief valve in charge pump stuck open.
  - b. Filter or suction line clogged.
  - c. Charge pump drive shaft sheared
  - d. Internal damage to pump or motor
- F. Low and Fluctuating Charge Pressure
- be noisy. Check all fittings, especially around filter, in the suction line and locate the point or points where air is being drawn into the system. Tighten fittings and joints where air leak exist.
- 2. Charge pressure relief valve in the motor ment fold stuck open. Pressure will be normal when the pump is in neutral but low when in stroke.
- 3. Internal damage to pump or motor.
- G. Faulty\*Check Valves
- end cap of the pump under the charge person check the following: (See Bulletin #9422)
  - a. Check valve to see if poppet or ball is missing.
  - b. Check to see if the valve seat is eroded.
- NOTE: If any of the above conditions exist, replace both check valves with Sundstrand Part #9800402.

H. Internal Damage To Pump or Motor indicated by:

- 75

- 1. Low or zero charge pressure (See [-E]. Charge pressure may also fluctuate rapidly.
- 2. Maximum obtainable operating pressure in both forward and reverse is less than the normal lief valve setting. Charge pressure. Shick also be lower than normal, will draw to set the when the maximum pressure is reasonable.
- 3. Pieces or flakes of brass in the rectangle filter.
- 4. Noisy unit (pump or motor).

NOTE: Heither unit is considered amaged, the other unit carefully checked.

II. System Operates in One Direction Only.

#### Cause

### \_\_\_\_\_

A. Faulty Control Linkage

### Remedy

- i. Check the entire linkage to make aura it is renected and free to operate as it should
- 2. Make sure the control "stop", if wast is of adjustment.
- B. High Pressure Relief Valve Stuck Open
- the system operates in the direction of would not operate before, one of the sure relief valves is stuck open.

  valves should be examined and the valve disassembled and cleaned.

  relief valves and retest system.
- C. One Check Valve Faulty
- Follow instructions given in I-G.
- D. Faulty Directional Control Valve (Located on Pump)
- NOTE: Do not change the position of any of the nats or the slotted plug on the end of the control unless it is necessary to remove the control valve spool.

Disconnect control linkage at directional control arm; Move the control arm back and forth by hand. If it moves freely with no resistance, the control valve should be removed and checked for broken parts or a bent control shaft.

### III. Neutral Difficult or Impossible to Find

SS/L

#### Cause

### A. Faulty Linkage

# B. Control Valve Out of Adjustment

### Remedy

- 1. Disconnect control linkage at direction arm. If system now returns to neutron age to the control is out of adjustment in some way.
- I. See H-D NOTE.
- 2. If the hex nuts and slotted plug have been moved out of adjustment, the following steps:
  - a. Disconnect control linkage at the control.
  - b. Remove the two 1/8" pipe plugs on the rounds, part of the control housing.
  - back the slotted plug off two turns (counts reclockwise).
  - feel it make contact with the speins less the control specie. It should just the spring seat:
  - to prevent it from moving and tighter the enjam nut.
  - f. Loosen the larger of the two jam nats.

NOV-27-2001 16:14

SS/L

650 852 5865 P.05/07

-5-

- h. Replace pipe plugs and start system. If system creeps in either direction, turn hex behind large jam nut in or out until neutral is found.
- 1. Hold hex to prevent it from moving and tighten large jam nut.
- Reconnect control linkage.

tree of the

新型(Wangaranga) 1995年 19

it I. Remove the two sleeve retainers.

+\$/ v. - 1 **1** 

- 2. Return the serve cylinders to their crisical posttion. When the proper position of the serve cylind was established at the factory, both the serve cylinder and the pump housing were marked with corresponding scribed lines. Matching these factorial return the cylinder or cylinders to their priginal position and re-establish neutral.
- Re-install the two sleeve retainers and restake.
   necessary.

NOTE: Servo cylinders do not move out of position on their own. If they get out of adjustment, it has to be done by human hands.

IV. System Operating Hot (Reservoir Temperature Above 1800).

#### Cause

of Adjustment

. Oil Level Low

Remedy

Replenish oil supply.

- 1. Clean cooler air passages.
- f. Cooler by-pass valve, if used, stuck open-
- D. Clogged Filter or Suction Line

C. Oil Gooler Being,
By-Passed

- E. Internal Leakage (Usually accompanied)
- I. Replace filter. Clean er replace suction line.
- f. One of the high pressure relief valves may be stuck partially open. Install gages and read the charge

-6-

by loss of acceleration and cower?

SS/L

pressure and operating pressure in both directions. If the operating pressure is 200 PSI or more, lower than normal in one direction and normal in the other. switch the high pressure relief valves. If the low pressure also switches to the opposite side of the circuit, disassemble, check and clean the faulty (low relief valve. Reinstall and recheck. Charge pres sure should be normal at all times.

Internal parts of pump or motor (or bothle corne Maximum obtainable operating pressure the normal high pressure relief walve and in the directions when this pressure is the pressure will drop to or very near to will also be notsy at this point with the issuing from the unit that is most worn. unit is considerably worn or damaged. We dhen unit should also be carefully checked. Repiker the parts in the units affected or replace the complete unit.

### System Noisy

### Cause

Air in System

### Remedy

- Low oil level in reservoir.
- Suction line between reservoir and charge pump, in cluding suction filter, leaking at some point and allowing air to be drawn into system. A good indication of air in the system is a considerable amount of foam in the reservoir.
- End of return line within the reservoir not submerg in oil.
- Hose or Tubing Not Properly Insulated
- Make sure hose or tubing is not touching any metal that can act as a sounding board for the natural hydraulic hum.
- Insulate hose and tubing clamps with rubber to absc noise.

Acceleration and Deceleration Sluggish.


### · Cause

### Remedy.

- A. Air in System
- 1. See Step V-A.

- B. Low Charge Pressure
- 1. See Step E-3.
- C. Control Orifice Plug
- E. Remove the bolts that Roll the control place and check the Statics. Here is that the first that is clean, remove the charge air through the passage between the and control.
- D: Internal Wear or Damage
- i. See Step I-H.
- E. Engine Lugs Down
- 1. Consult vehicle engine manual

Sundstrand Hydro-Transmission February, 1965 Builetin #9454





# replacement of major assemblies

SUNDSTRAND HYDRO-THANSMISSION

DIVISION OF SUNDSTRAND COMPORATION LA SALLE, ILLINOIS

### CONTENTS

SECTION 1 REPLACEMENT OF MAIN PUMP

SECTION 2 REPLACEMENT OF MOTOR

BESTION 3 REPLACEMENT OF CHARGE PUMP

SECTION 4 REPLACEMENT OF CHECK VALVES

SECTION 6 REPLACEMENT OF MANIFOLD

SECTION & REPLACEMENT OF

HIGH PRESSURE RELIEF VALVES

SECTION TO REPLACEMENT OF

DISPLACEMENT CONTROL

seem in a resplacement of within of

NOV-27-2001

### INTRODUCTION

It may become necessary to replace a part of the hydrostatic transmission. The following procedures will assist you. As with all hydraulic equipment, cleanliness is very important. Before removing any of these components, clean the immediate area to prevent dirt from getting into the transmission. While working on the transmission, it would be a good opportunity to inspect all hoses for tightness, change the filter and oil, if necessary, and replace any oil lost during servicing.


Variable Displacement Fump Model

23-2036


Ref # 1 2 3 4 5 5 A 5 B 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38	Qty 4 1 1 2 2 2 4 4 8 1 1A/R 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Part Number 9007200-2536 9009610-2850 9801038-03 9801074 9800648 9800721 9004101-0150 9007200-4430 9007200-4438 9009610-4778 9230285 9230482 9230127 9001415-0002 9004800-3110 9230197 9230288 9004101-0140 9230239 9007200-2530 9007200-2526 9009610-2850 9009660-2500 9009660-2500 9009660-2500 9009660-2500 9009660-2500 9009660-2500 9009660-2500 9009660-2500 9800916 9800917 9004600-0607 9009610-2850 9800893 9800432 9004101-0140 9801076	Part Description  Hex Head Screw Washer Charge Pump Assembly Charge Pump Gasket Check Valve Assembly Check Valve 'O' Ring End Cap Screw End Cap Screw Washer End Cap Gasket Rear Bearing Pin Valve Plate Bearing Plate Pin 'O' Ring Pump Housing Hex Head Screw Hex Head Screw Washer Jam Nut Washer Control Handle Spacer Cotter Pin Washer Control Valve Assembly Orifice 'O' Ring Pin Not Used Control Valve Gasket Plug Hex Head Plug 'O' Ring Hex Head Screw Washer
	2	9230018	Trunnion
39 <sup>.</sup> 40	A/R	9230019	Shim
41	2	9004100-2320	'O' Ring
	2	9001430-0001	Trunnion Bearing
· 42	1	9230469	Drive Shaft
43	1	9001435-0001	Front Bearing
4-1		9800210	Connecting Link
45	1	9006325-0025	Retaining Ring
46	2	9006320-0025	1/0/001111112

NOV-27-2001 17:18	3	SPACE SYSTEMS LORAL	1 650 8524662	P.04/0
		23-2036		
47	1	9004830-2501	Pivot Pin	
48	4	9006320-0062	Retaining Ring	
49	2	9004830-6201	Pin	
50	ī	9230124	Front Cover Gasket	
51	2	9004800-3708	Pin	
51 52	1	9230128	Front Cover	
53	. 12	9009610-4778	Washer	
54	4 & 8	9007200-4422 & 4424	Hex Head Screw	
54 55	1	9240147	Seal	
56	2	9004102-1360	'O' Ring	2
•	8	9220242	Seal Spring	
<b>57</b>	ì	9004610-1212	Groove Pin	
58	i	9004100-2380	'O' Ring	
59	1	9240093	Seal Retainer	•
60	i	9006201-0387	Retaining Ring	· .
61	4	9007300-1906	Socket Head Screw	·
62	2	9220419	Sleeve Retainer	
63		9005001-0600	Plug	•
64	4 2	9220691	Servo Sleeve	
65	2.	9004100-1440	'O' Ring	
66	2 .	9004100-1420	'O' Ring	
67	2	9007200-2508	Cap Screw	
68	. 2	9009625-2601	Washer	
69			Spring Guide	
70	2	9220479	Servo Spring	
71	2	9220436	Servo Piston	
72	2	9510014	Pin ,	
73	2	9004830-6201 9006320-0062	Retaining Ring	
7 <u>4</u>	4	9230151	Servo Link	
75	2	9230247	Pilot	
76	1	9006250-0250	Retaining Ring	
77	1	9230014	Spring Retainer	
78	, ,	9230015	Spring Guide	
79	1	9230013	Cylinder Block Sprin	ng
80		9230011	Spring Seat	
81	1	9230013	Retainer Spring	
82	. 9	9230012	Pin	
83	1	9230248	Cylinder Block Ass	embly
84	1		. Retainer Guide	
85	1		Slipper Retainer	. '
86	1	• •	Piston Assembly	
87	9		Thrust Plate	
. 88	1	9230235	Swashplate	
. 80	1	9230225	O 44 C C C C C C C C C C C C C C C C C C	


P.04/05



# nain pump







### A. REMOVAL (See Figure C)

- Remove control linkage from Displacement Control.
- Loosen reservoir cap to relieve any system pressure.
- 3. Place drain pan or bucket under the pump.
- 4. Remove the five (5) hoses. Place clean plastic plugs in lines and pump ports to prevent oil loss as each line is removed. (Do not use rags).
- 5. Remove the four (4) mounting bolts.
- Place a sling around pump or an eye holt in the trunnion, remove pump from application.




FIG. D

#### B. INSTALLATION

- 1. Mount pump on application using the four (4) mounting bolts.
- 2. Remove all shipping plugs as lines are installed. See plumbing diagram at rear of bulletin for correct line installation. Be sure lines are tightened to correct torques.

NOTE: It is recommended the pump case be filled by hand to assure proper lubrication upon start-up. See Fig D.

 Install control linkage to Displacement Control. Consult owners manual for setting of neutral.

# replacement of charge pump




FIG. G




FIG. H



FIG. 1

#### BULLETIN 9482 SECTION 3

#### A. REMOVAL

- 1. Remove the line connecting charge pump to reservoir and plug with clean plastic plug to prevent draining of reservoir.
- 2. Remove the four (4) capscrews.

NOTE: Do not remove the capscrew at the top and bottom of the charge pump, as these hold the charge pump together. See Figure G.

3. Pull charge pump away from main pump.

NOTE: Do not use sharp tools to pry charge pump from main pump. A scratch on the sealing surface may cause a leak. If charge pump does not pull loose, tap lightly on side of charge pump with plastic hammer to break paint or gasket seal.

#### B. INSTALLATION

- 1. Install a new gasket. Make sure the new gasket is properly installed. See Figure H. If positioned wrong the relief valve port is covered by the gasket.
- 2. Line up the drive tang on charge pump shaft with slot in main pump shaft. See Figure I. The charge pump should assemble freely with main pump freely. Do not force charge pump into position.
- 3. Torque the four (4) mounting bolts to 10-11 ft. lbs.

# replacement of charge pump




FIG. J

#### BULLETIN 9482 SECTION 3

- 4. Install connector to charge pump. Torque 14-20 ft. lbs.
- 5. Install line from reservoir to connector on charge pump.

NOTE: Excessive tightening may distort charge pump and cause leaks or malfunction.

6. Check oil level in reservoir.

## replacement of check valves







FIG. L

#### BULLETIN 9482 SECTION 4

#### A. REMOVAL

- 1. Remove charge pump. See Section 3.
- 2. Using a drag link, unscrew check valve from end cap. See Figure K.

NOTE: There are two check valves. It is advisable to replace both check valves when servicing unit. See Figure L.




FIG. M

#### B. INSTALLATION

- Prior to installation, inspect "O" rings for damage. See Figure M. Apply a light coat of oil.
- On 20 through 23 series pumps, torque check valves 30-40 ft, lbs.
- On 24 through 27 series pumps, torque check valves to 80-90 ft. lbs.
- NOTE: The checks must be below the face of the end cap. See Figure K.

### CHARGE PUMP CHECH VALVES

SS/L



#### Replacement Procedure

- Wash all dirt from pump.
- Disconnect the suction hose between the reservoir and charge pump at the charge pump. Raise the loose end as high as possible to minimize the loss of oil.
- Disconnect the pump case drain hose (not the large high pressure hose) at the top case drain port in the pump. This is the hose running between the pump and the cooler or reservoir. Raise the loose end as high as possible to minimize the loss of oil. The high pressure hose is shown disconnected in Fig. 1 for clarity only.
- Remove two 1/4-20 hex. head cap screws from each side of the charge pump. Do not loosen the two screws located one at the top and one at the bottom. 4. These two screws are used to hold the charge pump together and are not attached to the end cap.
- Remove the charge pump assembly. This assembly is located by a spread pin. It may be necessary to wiggle the charge pump to overcome the friction of this spread pin. Do not use a screwdriver or anyother tool to force the

(Over)

charge pump away from the main pump. NOTE: Note position of tang on charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft. If the shaft is then turned, it can be returned to its charge pump shaft much easier.

- Remove the two check valves. This can be done with a wide bladed screw-driver or flat piece of metal approximately 3/32" thick by 5/8" wide used as a screwdriver.
- 7. Install the two new check valves. Coat the "O" rings with light grease to prevent their being damaged as the valve is screwed into place. Make sure the valves are turned in tight.
- 8. Install the charge pump gasket. If the gasket is damaged in any way, it should be replaced.
- 9. Install the charge pump. Slip body onto the spread pin and tighten the four bolts. Torque the bolts to 70-75 inch pounds. NOTE: The tang on the charge pump drive shaft must be aligned with and engaged into the corresponding slat in the main pump drive shaft.
- 10. Reconnect hoses.
  - 11. Replace lost oil.
  - 12. Start vehicle engine at a slow idle for approximately two minutes. Check oil level to be sure its at the level called out in the vehicle specifications.

Sundstrand Hydro-Transmission Bullerin #9422 January, 1965

### replacement of displacement control valve

#### **BULLETIN 9482** SECTION 7








FIG. V

#### A. REMOVAL

- 1. Remove control linkage from Displacement Control Valve Assembly.
- 2. Remove the nine (9) capscrews holding valve to pump housing. See Figure U.
- 3. Lift Valve away from housing and remove cotter pin and washer. See Figure V. Remove pin from link in

NOTE: Caution must be exercised to prevent these parts from falling into pump.

4. Remove orifice and "O" rings from control valve. See Figure W.




FIG. W

#### B. INSTALLATION


- 1. Install orifice, tip down, and new "O" rings in Control Valve.
- 2. Install new gasket on control valve dry.
- 3. Install pin in control valve links and pump link.
- 4. Place washer in pin, install cotter pin and spread.

NOTE: Caution should be exercised during installation of these parts to prevent them falling into unit. Lightly coating parts with petroleum jelly inot grease is advised.

5. Install valve to pump and torque the nine (9) bolts 10-11 ft. lbs.



# e replacement of motor or pump shaft seal



#### BULLETIN 9482 SECTION 8

#### A. REMOVAL

- 1. Remove unit from installation. See Section 1 or 2.
- 2. Insert Tru-Arc #7 pliers in snap ring holes, compress ring and roll out. See Figure Y.
- Remove aluminum seal retainer with screwdriver. See Figure Z.
- 4. Remove steel stationary seal (This generally comes out with retainer). See Figure AA.
- With fingers or two screwdrivers remove bronze rotating part of seal from drive shaft. See Figure FF.
- 3. See Figure CC and account for all the parts shown.


#### B. INSTALLATION

NOTE: Always replace both stationary and rotating parts of seal. Do not mix old and new parts.

- 1. Wash and clean air dry new seal parts.
- 2. Install the seal springs into aluminum seal retainer. Install new "O" rings dry on stationary steel part of seal and place seal into retainer so notch is located in pin in retainer. See Figure DD.
- ). Install large "O" ring on O.D. of retainer. See Figure DD.
- 4. Install new "O" ring in I.D. of bronze retating part of seal, See Fig. ure EE.

FIG. DD


#### INSTALLATION PROCEDURE ORIFICING PUMP CONTROL TO SLOW RESPONSE CHANGING CONTROL OR CONTROL GASKET



- Wash all dirt from top of pump.
- Disconnect the case drain hose which runs between the pump and reservoir at the pump and raise as high as possible to keep loss of oil at a minimum.
- Remove (9) 1/4"-20 screws. 3.
- Raise pump control as high as possible and tilt toward front of pump. This should be done carefully to prevent damaging the pump control gasket and to make sure the three "O" rings remain in place and are not jarred loose to fall inside the pump. (See #2)
- Inspect the control gasket and if it is damaged, it should be replaced. 5.
- Immediately cover the opening into the pump with a clean shop towel. This will prevent anything from falling into the internal parts of the pump while 6. installing the orifice.
- To replace the control valve or the control valve gasket take the following 7. steps:
  - (a) Cover the opening into the pump housing with a clean cloth.
  - (b) Remove the orifice, if used, and the three "O" rings from the control valve housing.
  - (c) Remove the small cotter pin.
  - (d) Remove the small washer.

contain an "O"

ring.



Follow-up linkage

Orifice plug pressed into and held by "O" ring in Port #3.



View of Underside of Pump Control Fig 2

- (e) Remove the clevis pin. NOTE: The clearance between this pin and the three holes it passes thru is very small. Wiggling the control valve from side to side as the pin is pulled will ease the job of removing it. Do not
- (f) Put the new gasket in place. Coating the gasket with light grease will help
- (g) Place the link to the swash plate in the follow up linkage and push the clevis pin into place.
- (h) But the washer on the clevis pin.
- (i) Put the cotter pin into place. Do not reuse the old cotter pin.
- Place the three "O" rings into place in the control valve housing. It is recommended that the "O" rings be coated with light grease to hold them in place. 8.
- Insert the orifice plug into the I.D. of the "O" ring in Port #3 (See Fig. 2). NOTE: The orifice is provided with a small projection or guide on one side. 9. This guide is designed to fit into the drilled hole in the control valve housing. The orifice plug is so designed that the slight press between it and the I.D. of the "O" ring will hold the orifice plug in place while the pump control is being bolted back down.
- Remove the cloth covering the opening into the pump. 10.
- Swing the follow-up linkage as far as possible toward the rear of the pump and 11. lower the pump control to its normal position.
- Replace the (9) 1/4"-20 bolts, tightening them SNUGLY. Replace case drain hose 12.
- Replace lost oil and run system for a short period and recheck for proper oil 13. level in reservoir.
- Reconnect the linkage to the control and if necessary, readjust the mechanical "stops" so that the mechanism driven by the pump operates at the desired speed.

Sundstrand Hydro-Transmiss Bulletin #9423 January, 1965

#### STANDER TO A TOWN OF THE REPORT OF THE ANDREAD ISSUED A

#### VARIABLE PUMP OR VARIABLE MOYOR DISASSEMBLY PROCEDURE

#### 1. Remove pump from the installation or vehicle.

- A. If possible, the pump should be steam cleaned while still on the vehicle or installation and before any hose is disconnected. If a steam cleaner is not available, wash the pump, especially the fittings, with fuel oil or suitable solvent. Do not use paint thinner or acctone. Remove any dirt from the vehicle or installation which could be accidently dislodged and enter the pump during the reinstallation procedure.
- B. Disconnect all hose. In most cases, it is recommended that the oil be discarded and replaced with new oil when the system is again started.
- C. Remove the mounting bolts and set the pump on a clean work bench. A few minutes spent cleaning off a work bench before starting to work will save time later as the work progresses.

  Putting a drip pan approximately 18" square by l" deep under the pump will help to keep the oil, that is still in the pump, off the work bench and floor.

#### 2. Remove the shaft scal (Item 1).

A. A few pumps are designed with a seal that is held in place with four cap screws. Most seals are held in place with a large snap ring (Item 45). Remove either the cap screws or the snap ring as the case may be.

00:02

NOV-28-2001

- retainer can usually be removed without the use of tools. Due to the squeeze on the "O" ring (Item 1A), the seal retainer (Item 47) and the steel half of the seal (Item 1C), Items 1A, 1B and 1C will all be removed with the seal retainer. Set this group aside in a place where the seal cannot be damaged by a stip of a wrench.

  NOTE: Unless the seal is going to be replaced, the lapped surface of the steel half of the seal (Item 1C) should be protected from damage at all times.
- C. Remove the bronze half of the seal (Item ID). This part is held in place by the squeeze on the "O" ring (Item IF). It can usually be wiggled off the shaft with the fingers. A few seals incorporate a small spread pin in the drive shaft to "drive" the bronze half of the seal. In a very few cases, this pin may have worn a groove into the I.D. of the seal half. If so, hold the shaft stationary and rotate the seal half as far as it will go in the direction of shaft rotation. This will again line up the slot in the seal half with the drive pin and the seal half can be removed. However, once in awhile even after the drive pin is lined up with the slot, it may be necessary to pry the part loose by using two screw drivers. If this is necessary, make sure all pressure is applied against the sides of the seal half and that the lapped scaling surface is not damaged in any way.

NOV-28-2001 00:02

#### 3. Remove the charge pump litem 22%.

- A. The charge pump is held in place by four boits (Item 21) located clong the straight sides of the charge pump. The other two bolts located on the top and bottom portion of the charge pump are used to hold the three main sections of the charge pump together when it is removed from the main pump.
- B. The charge pump is "located" by a spread pin between it and the end cap of the main pump. Due to the drag of this pin, It may be necessary to "work" the charge pump up and down while pulling to separate it from the main pump. DO NOT PRY with a screw driver or other tools!
- C. Remove and inspect the charge pump gasket (Item 20). If it is all right, lay is aside with the charge pump. If it is damaged in any way, it should be replaced.
- 4. Remove the two check valves (Item 24). The body of the check valve assembly is threaded. The whole check valve assembly can be removed by unscrewing it from the end cap. The check valves are turned in quite tight at the factory, and it may be necessary to use a small drag link socket or equivalent to remove them.

#### 5. Remove the end cap.

A. The end cap is held by eight hex head bolts (Item 19) and is positioned by two dowel plus (Item 26). Usually as the last bolt is removed, the end cap will be pushed away from the housing a short distance. If this does not happen, it will be necessary to break it loose by the careful use of a plastic or babbit hammer. NOTE:

Never force a screw driver or wedge between any two surfaces of any Sundstrand product.

- R. The valve plate (Item 52) is loosely doweled (Item 51) to the end cap for position only. However, due to the extreme flatness of the face of the end cap and the mating surface of the valve plate, an oil seal will exist between these two parts causing the valve plate to cling to the end cap. On occasion, the brass bearing plate (Item 53) will, for the same reason, cling to the valve plate. Therefore, as the end cap is lifted, extreme caution should be exercised to prevent the valve plate from being damaged should it become loose and fall.
- C. Set the end cap aside with the lapped surface up. The lapped surface should be protected from damage at all times.
- 6. Remove the end cap gasket (Item 15) and "O" ring (Item 17). If either is damaged, they should be replaced.
- 7. Remove the valve plate (Item 52). If the valve plate remained on the end cap, they can be separated by first washing both parts with clean fuel oil or solvent. This will break the oil scal and the parts can then be easily separated.

If the valve plate remained with the brass bearing plate in the pump, it can be removed by sliding it to one side off the valve plate and lifting.

8. Remove the brass bearing plate (Item 53). The material in this plate is relatively soft and can be easily scratched and damaged. Wash the plate with clean fuel oil or solvent to break the oil seal and lift the plate from the cylinder block (Item 55). There are drain slots milled into the back of the brass bearing plate running radially to the outside diameter.

SS/L

P.05/11

As an aid in removing the swass bearing plate, a crass pry can be carefully inserted into one of these drain grooves and the bearing plate lifted. Do not force these two pieces apart at any other point other than at the drain slots.

- Remove the rear bearing (Item 50). Use a standard bearing puller to pull the rear bearing. Be sure you can rotate bearing cage while pulling. Pull only on the inner race not the cage or rollers. The pump shaft should be protested from damage by placing a suitable piece of metal between the rain of the puller and the shaft. NOTE: The face of the cylinder block (Item 55) is a lapped surface and can be easily damaged by careless handling of the puller while assembling the jaws under the bearing.
- Remove the spring guide (Item 72). This part is a sleeve type spacer and is not held in place by any mechanical tie.
- Remove the cylinder block (Item 55): Place the pump housing (Item 39) 11. in a horizontal position. Grasp the block with the fingers and pull. The piston assemblies (Item 56) and retainer (Item 63) usually stay in the
  - housing and have to be removed later. However, if it is possible to remove the block with the pistons still in place, it simplifies the job.
- 12. Remove the slipper retainer guide (Item 62). If the pistons came out with the block as it was removed, this step has been taken care of. If it stays in the housing, rotate the guide slightly until the two splines are again lined up and slip it back down the shaft (Item 48) and out of the hous-

SS/L

P.06/11

ing. A few pumps contain spacers located inside the guide and fitting between the guide and the neck of the cylinder block. They should be discarded and not returned to the pump during reassembly.

- 3. Remove the nine pistons (Item 56) and the slipper retainer (Item 65).

  If the pistons remained in the clock as it was removed, this step has been taken care of. If hey remained in the housing, insert your hand or hands, as space allows, into the housing and gather up all nine pistons. This will prevent their lodging against the sides of the housing hampering their removal. Some or all of the slippers may form an oil seal with the thrust plate (Item 64) making it necessary to pail on that piston individually to break it loose.
- 14. Remove the thrust plate (Item 64). This part is cradled in the swash plate (Item 61) with very little side clearance. If the pump is to be completely disassembled, it is easier to remove the thrust plate after the swash plate has been removed from the housing. If the swash plate is not going to be removed, a metal rod approximately 10" long with a small book approximately 1/16" high on the end makes a good tool for removing the thrust plate. Two notches are provided in the L.D. of the swash plate on a plane parallel to the center line of the trunnions. These notches provide clearance behind the thrust plate permitting the engagement of the hook. By pulling first on one side and then the other, the thrust plate can be "worked" out of the swash plate and removed.

- eight bolts (Item 2) and positioned by two dowel pins (Item 3). It may be necessary to jar the cover loose with a plastic or babbit hammer. Do not drive a screw driver or wedge between the cover and housing.
- 16. Remove the front cover gasket (Item 42). If necessary, scrape both the front cover and pump housing free of any particles of gasket materaial that might have remained on either.
- 17. Remove the drive shaft (Item 48). With the front cover removed, the shaft will easily slide out the front of the housing.
- 18. Remove the control valve assembly (Item 14).
  - A. Remove the eight cap screws (Item 13) which hold the control in place and lift the control assembly as high as possible.
    - B. Remove the small clevis pin (Item 9) which connects the two followap links on the control with the connecting link attached to the swash plate. If the control valve assembly (Item 14) is being removed without the rest of the pump being disassembled, it is strongly recommended that before removing the small cotter key (Item 10) used to hold the clevis pin, a long place of tag wire or equivalent be run through the eye of the cotter key. This will prevent the cotter key from accidentally falling into the pump if dropped.

The clevis pin (Item 9) can now be removed. The clearance between the O. D. of the body of this pin and the I. D. of the three holes it passes through is very small; therefore, the pin does not slide out easily. Wiggling the control housing (Item 14) as you pull on the

SS/L

trol valve assembly (Item 14) is being removed without the pump being disassembled, take care not to drop the clevis pin isside the pump housing. If you do and it cannot be fished out with a magnet, it will be necessary to disassemble the pump piece by piece until the clevis pin is found.


Lay the control valve assembly aside. Further disassembly of this valve is usually not necessary. It should be thoroughly washed and blown out with compressed air.

- 19. Remove the trunnions (Item 59). Remove the three bolts (Item 66) that hold each trunnion in place. Use a spanner wrench and rotate the trunnion back and forth with one hand as you push on the inside face of the trunnion with the other hand. It is necessary to overcome the drag of the "O" ring (Item 53) to remove the trunnion. The inner race of the trunnion bearing (Item 50) usually, but not always, comes out with the trunnion.
- 20. With the trunnions removed, it is now possible to lift the swash plate (Item 61) out of the Mousing.

The pump is now completely disassembled. All parts should be inspected. Those needing to be replaced should be replaced and those needing rework, reworked. Thoroughly wash all parts in clean solvent or fuel oil and then heep them clean. Wrap them in either clean rags or plastic. If the parts are to remain disassembled for any period of time.

they should be protected from rust and accidental damage. You can save yourself a lot of time and effort by not allowing any lapped surface to become scratched or nicked. The parts of any quality piece of hydraulic equipment do not have to be treated like the parts out of a watch; but on the other hand, due to the high pressures the pumps and motors are required to handle today, any abuse to the parts during the repair procedure will result in an inefficient or inoperative unit after it is assembled.

Sundstrand Hydro-Transmissic Bulletin #9427 January, 1964 Revised: March, 1965



#### <u> PUMP REASSEMBLY</u>

The primary thing to keep in mind when assembling any piece of hydraulic equipment is cleanliness. The same care and cleanliness should be extended to the parts of the pump that would be extended to the injectors of a diesel engine. Just prior to assembly, each part, old and new and especially those with lapped surfaces, should be carefully, but thoroughly, scrubbed to remove any trace of dirt or lapping compound. As the parts are assembled they should be liberally covered with the type oil the pump will eventually operate in. Never allow two unlubricated surfaces to move against each other.

The following is a step-by-step procedure to follow in reassembling the pump.

1. Replace Bearings, if necessary (Items #50, #60, #63).

If necessary, replace any of the four tapered Bearings. This should be done with care. If possible they should be pressed rather than driven into place.

BEARING FITS

		BENEING ELTS		
Bearing		Mating Part	Fit	
	Cup*	Front Cover (Item #43)	Slip	
Front	Cone	Drive Shait (Item #46)	Press	
Item #63		End Cap (Item #16)	Slip	
Rear	Cup	Drive Shaft (Item #46)	Press	
Item #50	Cone		Press	
Trunnion	Cup	Swash Plate (Item #61)	Slip	
Item #60	Cone	Trunnion (Item #59)	92.0	
Item #60		Trunnion (Item #59)	Sli	

- \* Sec procedure for establishing shaft end play Step #3.
- \*\* Do not press the cone of the Rear Bearing onto the Shaft until the Cylinder Block is in place, see Step #19, or unless the drive shaft end play is to be checked, see Step #3.
- 2. Set preload on Trunnion Bearings (Item #60).

If either a new Swash Plate (Item #61), Trunnion (Item #59), or Trunnion Bearings (Item #60) were replaced or if the plastic Trunnion Gaskets (Item #57) were lost, it will be necessary to establish the desired preload on the Trunnion Bearings as follows.

الإنجاب وروعة فالك

- A. Ramove the "O" Rings#from the Trunmions.
- B. Return the same thickness of Gasket (Item #57) to each Trunnton that was present when the pump was disassembled.
- C. Slip the Trunnion Bearing Cones onto the Trunnions.
- D. Place the Swash Plate (Item #61) in the Housing, lining up the bearing races with the Trunnion cores in the Housing (Item #39).
  - E. Insert the Trunnions, minus the "O" Rings, into the Housing and Swash Plate. The clearance between the Trunnions and their bores in the Housing is small, therefore, it is easy to bind the Trunnions as they are being put into place. A plastic hammer may be used to lightly tap the Trunnions as an aid in assembly.
  - F. Tighten one Trunnion Bolt (Item #66) on each Trunnion.
  - G. Attach a spring scale to either of the two bores for the Swash Plate Pin (Item #41). With the proper thickness of Trunnion Gaskets, it will require between 3 and 4 pounds pull to move the Swash Plate. Add or subtract Gaskets (Item #57) until this reading is obtained. Gaskets should be added or subtracted evenly to each side. The total thickness of Gaskets on one Trunnion should not exceed the total thickness of Gaskets on the other by more than .005".
- H. When the proper preload is established, remove the Trunnions from the Housing.
- 3. Set Shaft end play. (Should be .003" to .013")

If a new Drive Shaft (Item #48), End Cap (Item #16), Front Cover (Item #43), and Front Bearing (Item #63) are used, the Shaft end play should be checked as follows.

- A. Press the Cone of both the Front and Rear Bearings onto the Drive Shaft.
- B. Install the End Cap Gasket (Item #15) and End Cap (Item #16).
- C. Tighten two of the End Cap Bolts to 27-30 ft. lbs.

- D. Put the Front Cover Gasket (Rem #42) ento the Housing,
- E. Place the Drive Shaft in the Housing with the Cone of the Rear Bearing in its Cup.
- F. Place the Front Cover (Item #43) into place.
- G. Tighten at least one bolt (centrally located) on each side to 27-30 ft. lbs.
- H. The end play of the Shaft can now be checked and should be between .003" and .013".
- 4. Assemble the Servo Pistons (Item #35).

NOTE: If the old Swash Plate (Item #61), the two Servo Piston Assemblies (Items #27 thru #41), and the two Servo Sleeves (Item #17) are to be reused, they should all be returned to the same position they were removed from. See Step #10 for the correct procedure to follow to set the neutral position of the Swash Plate if any of these parts are replaced with new or if the parts have become mixed up.

- A. Check the grooves on the O.D. of the Servo Piston (Item #35) making sure there are no burrs or foreign material present.
- B. Place the Servo Control Spring (Item #28) in the I.D. of the Servo Piston (Item #35).
- C. Insert the Spring Guide (Item #27) into the Servo Control Spring.
- D. Insert the 1/4-20 screw (Item #29) into the Washer (Item #30) and drop both into the I.D. of the Spring Guide so the screw threads extend thru the hole in the end of the Guide.
- E. Compress the Servo Control Spring until the 1/4-20 screw can be engaged and tightened into the Servo Piston.
- F. Place the Servo Piston Link (Item #38) into the Clevis of the Servo Piston.
- G. Insert the Servo Piston Pin (Item #37) into place. pinning the Link to the Swash Plate.

- .H. .Faster the Serve Piston Pin into piece with two Snap Rings (Item #36).
- I. Assemble the other Piston Assembly in the same manner.
- 5. Attach the Servo Piston Assemblies to the Swash Plate.
  - A. Lay the Swash Plate flat on the workbench and place the free end of the Servo Piston Links (Item #38) into the two Clevises provided on the Swash Plate. The joggle in the Servo Piston Link should be arranged so that the Pistons are "stepped" outward from the center line of the pump.
  - B. Insert the two Swash Plate Piston Pins (Item #41) thru the Clevis of the Swash Plate, pinning both Links to the Swash Plate.
  - C. Fasten the pin in place with two Snap Rings (Item #40).
- 6. Attach the Control Link (Item #7) to the Swash Plate.
  - A. Position the Control Link (Item #7) in the Clevis provided in the Swash Plate.
  - B. Insert the Clevis Pin (Itam #6) into place pinning the Link to the Swash Plate.
  - C. Fasten the Pin in place with two small Snap Rings (Item #5).
- 7. Install the Swash Plate (Item #61).
  - A. Set the pump Housing on the bench with the Front Cover opening facing you and the opening for the Control upward.
  - B. Insert the Swash Plate with the Servo Piston Assemblies and Control Link attached into the Housing. As this is done, the two Servo Pistons should be placed into the openings provided for the Servo Sleeves. This should be done with care to prevent damage to the Pistons.

NOTE: Make sure the Swash Plate is positioned so that the Control Link (Item #7) is next to the opening provided in the Housing for the Control Assembly (Item #14), and pointing toward the End Cap (rear) end of the Housing.

- 6. instal the Trunnions.
  - A. Cover the Trunnion "O" Rings (Item #56) with grease and put them in place on the Trunnions. The grease is used to prevent the "O" Ring from being damaged as the Trunnion enters the Housing.
  - B. Place the Tournions thru the bores in the Housing and into the Swart Plate. The clearance between the Trunnion and its bore is small and it is, therefore, easy to bind the two parts together. A plastic or babbit hammer thay be used to lightly tap the Trunnion "home", if necessary.
  - C. Tighten the Trunnion Bolts (Item #66) to 27-30 ft. lbs.
  - 9. Install the Servo Sleeves (Item #18).
    - A. Cover the "O" Rings (Items #33 and #34) with grease and put them in place on the Sleeves.

NOTE: "O" Ring (Rem #34) is slightly smaller in O.D. than (Rem #33) and goes in the groove toward the open end of the Sleeve.

- B. Turn both Sleeves into the Housing until the scribed lines on the Sleeves and those on the Housing line up. These lines should have been scribed at the factory during the original assembly or at the time of disassembly. If the Swash Plate, all parts of the Servo Piston Assemblies and both of the Servo Sleeves are to be returned to the pump and not replaced with new parts, linking up the scribed marks will return the Swash Plate to its neutral position.
- 10. Setting neutral position of Swash Plate.

If any of the parts mentioned in Step #9B were replaced with new parts or as a check to make sure the Swash Plate is in absolute neutral, the following procedure should be used.

A. Turn both Servo Sleeves into the Housing as evenly as possible, until all angular play is taken out of the Swash Plate. This will happen when the Servo Sleeves are both just touching the Spring Guides (Item #27). Do not turn the Sleeves in beyond this point causing any compression of the Servo Control Spring (Item #28).

SS/L

Using a depth miles measure from the machined surface of the He sing, which makes contact with the End Cap Casket, to the machined surface of the Swash Plate. This is the surface against which the Thrust Plate bears. The massurement should be made at two points equally spaced from the center line of the pump and as near to the outside liameter of the machined recess as possible. Measure one side then the other. Note which side is low and back off (tern counterclockwise) the Servo Sleeve nearest this side 1/8 - 1/4 turn. Turn the other Sleeve in (clockwise) a like amount or until the angular free play is again removed from the Swash Plate. Repeat this process until the machined recess of the Swash Plate is absolutely parallel to the machined surface of the Housing which touches the End Cap Gasket and there is absolutely no angular free play in the Swash Plate.

Install the Sleave Retainer (Item #31).

Use the Socket Head Set Screws (Item #32) previously removed. Use a screwdriver to set Retainer in slot in the Sieeve to prevent the sleeve rotation.

- Install the Control Assembly (Item #14).
  - Put the Control Casket (Item #4) in place.
  - Cover the three "O" Rings (Item #12) with grease to hold them in place and put them in the recesses provided in the Control Valve Housing.
  - If used, press the Orifice Plug (Item #11) into "O" Ring in the middle port in the Control Valve Housing.
  - Place the Swash Plate Link (Item #7) between the "Follow-Up" Linkage of the Control.
  - Put the small Snap Ring in the groove in the Clevis Pin (Item #9) and insert it thru the "Follow-Up" Links and the Swash Plate Control Link.
  - Place the small Washer (Item #8) on the Clevis Pin.
  - Insert the small Cotter Pin (Item #10) thru the Clevis Pin. Do not use the old Cotter Pin.
  - Fasten in place using the proper bolts (Item #13). Tighten to 85-90 in. lb. NOTE: Be sure to put the proper length bolt in the correct hole.

12. Install the Thrust Plate (Item #64).

Place the Thrust Plate into the machined recess in the Ewash Plate. The chamfored side goes against the Ewash Plate. The clearance between this Plate and its recess is small, therefore, care should be taken to insure it lies flat.

13. Install the Drive Shaft (Item #46).

If the Cone of the Rear Bearing was pressed onto the Drive Shaft to establish the shaft end play, it should be removed at this time. The cone of the Front Bearing should be in place. Slide the Shaft thru the I.D. of the Swash Plate from the Front Cover End taking care not to move the Thrust Plate out of position.

- 14. Install the Front Cover Gasket (Item #42).
- 15. Install the Front Cover (Item #43).

Tighten the bolts that hold it in place to 27-30 ft. lbs.

- 16. Assemble the Cylinder Block.
  - A. If a new Cylinder Block (Item #55) is used or if the old Block was completely disassembled, it will be necessary to assemble the Spring Seat (Item #68), the Block Spring (Item #54), the Spring Retainer (Item #69) and Retaining Ring (Item #70) into the Block as follows.
    - (1) Place the Spring Seat (Item #68) into the Block. The chamfered side of this part goes toward the spline end of the Block.
    - (2) Drop the Block Spring into the Block.
    - (3) Place the Spring Patainer (Itam #69) on top of the Block Spring with the notched side toward the face of the Block.
    - (4) Secure a bolt at least approximately an inch longer than the Block. Slide a washer (or washers) with an O.D. larger than the I.D. of the Block Spline. Slide this bolt thru the Block and place a washer (or washers) on the other end that is slightly smaller in O.D. than the O.D. of the Spring Retainer (Item #69).

Tighten a nut onto the bolt until the Block Spring is compressed enough for the Spring Retainer to move past the groove for the Retaining Ring (Item #70).

- (5) Assemble the Rataining Ring into the slot provided in the I.D. of the Block and remove the bolt and washers.
- (6) Put nine (9) Slipper Retainer Springs (Rem #67) into the Block. Place the Recainer Guide (Rem #62) on the Block. The missing tooth of the spline in the Guide should be lined up with the missing tooth in the spline of the Block. Cover the Guide with oil.
- (7) Place the nine (9) Piston Assemblies (Item #56) into the Slipper Retainer (Item #65).
- (8) Assemble the nine (9) Pistons into the Block. This is easiest done by holding the Slipper Retainer over the Block so that the Pistons will barely enter the bores. When all nine (9) Pistons are started in the bores, lower the Slipper Retainer to the Retainer Guide and push all nine (4) Pistons down into the Block.
- (9) Cover the Cylinder Block and Piston Assemblies liberally with clean oil.
- 17. Assemble the Cylinder Block Assembly into the Housing.
  - A. Lay the Housing on its side with the control up (Item #14).
  - B. Turn the Drive Shaft until the missing tooth in the spline is on top.
  - C. Pull the Drive Shaft as far as possible toward the front of the pump and clamp a collar or "C" clamp onto it to prevent it being bumped or pushed toward the rear of the pump as the assembly continues.
  - D. Pick up the Cylinder Block Assembly and slide it into the Housing and onto the Drive Shaft. It is necessary to line up the missing tooth on the Shaft with the missing tooth in the Retainer Guide and the Cylinder Block. Push the Block all the way "home".

P.09/13

16. Install the Spring Guide (Rem -72).

SS/L

This sheeve-like part is used as a spacer. It should slide freely onto the Shalt and into the Block. If it does not drop into place freely, the Block Spring is not concentrically positioned and should be moved into proper position with a screwdriver.

19. Press the cone of the Rear Bearing (Item #50) onto the Shaft.

This can either be done with an Arbor Press or a bearing puller. In either case, make sure the tool is clean and no dirt will fall into the pump. As the cone is pressed into position, the Retainer Springs (Item #67) will be compressed and the whole Cylinder Block Assembly will drop a quarter to three quarters of an inch, depending on the size pump, into the Housing.

20. Install the Bearing Plate (Item #53).

Set the pump Shaft downward on the block of wood used during disassembly.

NOTE: Do not bump or push the Shaft toward the rear of the pump. If this happens, the Shaft Spline can become disengaged with the Spline in the Retainer Guide and the two parts can then become out of phase. The Retainer Guide will, in this case, be extensively damaged as the End Cap is bolted in place.

Put the Dowel Pins (Item #71) into the Block. Make sure the face of the Cylinder Block and the Bearing Plate are absolutely free of any foreign material such as dirt, lint, etc. These two parts should lie absolutely flat against the other.

Cover the Bearing Plate liberally with oil.

21. Place the Valve Plate (Item #54) on the End Cap (Item #16).

Put the Cup of the Rear Bearing/and Dowel Pin (Item #51) in place in the End Cap. Make sure the End Cap and Valve Plate are free of any dirt or lint that would prevent the parts from laying absolutely flat against the other.

Cover the face of the End Cap with a thin, even coat of oil soluable grease such as vasoline. Put the Valve Plate (Item #52) into place and press it down into the grease.

- 22. Put the Eng Cap Gasket (Item #15), "O" Ring (Item #17), and Dowel Pins (Item #26) into place on the Housing. Coating the Gasket with a thin, even coat of light grease will make it easier to remove the Gasket should it be necessary to again service the pump in the future.
- 23. Install the End Cap (Item #16).

SS/L

Carefully pick up the End Cap, with the Valve Plate in place, turn it over, and lower it in place until the Valve Plate touches the Bearing Plate. This should be done carefully so as not to disloge the Valve Plate.


Tighten the End Cap Bolts to 27-30 ft. lbs.

- 24. Install the Charge Pump (Item #22).
  - A. Lay the pump on its side.
  - B. Place the Charge Pump Casket in place, making sure the opening for the Charge Pressure Relief Valve of the Charge Pump is not covered. This Casket can be put on in four different positions, three of which are wrong.
  - C. Make sure the Aluminum Spacer is in place over the Eler Shaft.
  - D. Line up the angle of the tang on the Charge Fump Shaft with the slot in the main pump Drive Shaft.
  - E. Insert the Charge Pump Drive Shaft into the main pump End Cap and the Charge Pump Body onto the Spread Pin used as a locator pin.
  - F. Tighten the four bolts that hold the Charge Pump in place to 85-90 in. lbs.
  - 23. Install the Shaft Seal (Item #1).
    - A. Gover the Shaft Seal "O" Ring (Item #1F) with grease and put it in place in the J.D. of the Shaft Seal (Item #1D).
    - B. Check the and of the pump Drive Shaft for any burns that would got the Shaft Seal "O" Ring. Slide the Shaft Seal (Frem #1D) that the Shaft and press it into place with the skirt had against the inner race of the Front Bearing.

- C. Place the Seal Springs (Item #1B) in place in the Seal Retainer (Item #2644/The Stop Pin (Item #46) should be driven securely into the Seal Retainer.
- D. Cover the Housing Seal "O" Ring (Item #1A) with grease and put it in place on the skirt of the Housing Seal (Lam #1C).
- E. Press the Housing Seal (Item #1C) into the Retainer with the fingers, engaging the Stop Pin in the slot in the Housing Seal. Press down on the Housing Seal, compressing the Seal Springs. Release the pressure and make sure the Seal Springs push the Housing Seal back to its original position. This will insure an even pressure being maintained between the Seal halves.
- F. Cover the Retainer "O" Ring (Item #1E) with grease and put it in place on the O.D. of the Retainer.
- G. Push the Retainer, as assembled in Steps D thrû F, into the Housing far enough to allow the Snap Ring (Item #45) to be put in place.
- H. Using a large set of Tru-Arc pliers, place the Saal Snap Ring in place.
- 26. Using a lever, such as a pair of Channel Locks, rotate the pump Shaft several revolutions by hand, making sure it turns fairly free.

If the pump is to be in storage for any length of time, it should be completely filled with oil and all ports plugged. Just prior to being installed on a vehicle, the Shaft should again be rotated several revolutions by hand.

Sundstrand Hydro-Transmission Bulletin #9428 February, 1965





Phone 815/224-1850 · LA SALLE, ILLINOIS 61301 · TWX 910-642-3949

# IMPORTANT WARRANTY ANNOUNCEMENT


Sundstrand extends the warranty on all Heavy Duty Transmissions (Sundstrand Models 20 through 27) to 2 years from date of shipment from its plant in LaSalle, Illinois.

Effective with all transmissions shipped after December 31, 1966, Sundstrand now provides all Heavy Duty Transmissions are warranted to be free of defects in material and workmanship for a period of two years from date of shipment. This supersedes the time limitations stated in Warranty Bulletin 9545 dated September 1966. All remaining articles of the Warranty Bulletin continue in effect.

Rebuilt units will now carry a one year warranty period from date of shipment from the plant in LaSalle, Illinois.

For warranty consideration, model and serial numbers must be supplied to Sundstrand.

Bulletin 0566



## HEAVY DUTY TRANSMISSION START-UP PROCEDURE

Before installing a transmission on a machine, inspect the transmission for damage in shipping or handling. All tools, pans, cans, plugs, etc., must be clean prior to use on the system.

Never use drained oil.

- (1) After the units have been installed, remove the threaded plug in the charge pressure port from the side of the main pump housing (See Figure 1). Install a 600 PSI gauge with a short section of hose to this port. The threaded plug may be either 1/8 NPT or 7/16-20 straight thread.
- (2) Check all fittings to be sure they are tight.
- (3) Loosen the charge pump line at the inlet to the charge pump (See Figure 1).
- (4) Fill the pump case through the case drain opening with an approved oil (See last page for oils)
- (5) Fill the reservoir with an approved oil. When oil appears at the loosened hose at the charge pump inlet, tighten the hose and continue filling the reservoir. Leave reservoir cap loose so air will escape.
- NOTE: If gravity feed does not fill the line to the charge pump, it must be filled by hand.
- (6) The pump must be in neutral. It is recommended that the control linkage be left disconnected until after initial start-up.
- (7) With the coil wire removed or the rack closed, turn the engine over for fifteen seconds.
- (8) Start the engine maintaining as low an idle as possible for five minutes. During start-up, pressure surges will be seen on the 600 PSI gauge. While running at low idle, charge pressure must be above 100 PSI. If it is not, shut down and trouble shoot according to Bulletin 9454.

Cont. on Page 2

Cont. from Page 1

- (9) Increase engine speed to approximately 1000 RPM. Charge pressure on the 600 PSI gauge should be 180-220 PSI.
- (10) Shut down engine and connect linkage to displacement control.
- (11) Check fluid level in reservoir and add an approved oil if necessary.
- (12) Start engine and run at 1500 to 2000 RPM. Charge pressure should be 180-220 PSI.
- (13) Move the directional control handle slightly to the forward and reverse position. Charge pressure will drop to 150-190 PSI when pump is in stroke.
- (14) Should the charge pressure fall below 100 PSI during the start-up procedure discontinue start-up until trouble has been found. See trouble shooting Bulletin #9454.
- (15) Shut down engine, remove gauge and replace plug in gauge port. Check reservoir oil level and tighten oil fill cap.

Machine is now ready for operation.

HEAVY DUTY VARIABLE DISPLACEMENT PUMP




Figure I.

## RECOMMENDED OILS

Approved oils for Use in Sundstrand Hydrostatic Transmissions

Approval has been given for the following oils for use in Sundstrand Hydrostatic Transmissions:

For operating temperatures above 10°F.

- I. Mobilfluid 300 from the Mobil Oil Company.
- 2. Rykon Industrial Oil No. 21 or American Hydraulic Oil All Weather from the American Oil Company.
- 3. Hy-Tran from International Harvester.

NOTE: For "make-up" in the field when the above oils are not available Type A - Suffix A automatic transmission fluid (Mobilfluid 200 from the Mobil Oil Company) may be added.

These oils may be mixed in any ratio to fill a system as they are compatible.

For operating temperatures below 100F.

1. Mil-H-5606 Hydraulic Fluid.

NOVEMBER, 1966 BULLETIN 9429



Phone 815/224-1850 • LA SALLE, ILLINOIS 61301 • TWX 910-642-3949

HEAVY-DUTY TRANSMISSION (Sundstrand Models 20 Thru 27)

WARRANTY POLICY AND PROCEDURE

RELIABLE HYDROSTATIC TRANSMISSIONS FOR THE MOBILE EQUIPMENT INDUSTR

STANLEY M. PROCTOR CO.
Phone: (216) 771-0350

SS/L

## TECHNICAL PUBLICATIONS

An Operator's Manual and a Paris Catalog are packed and shipped with this machine for customer use. Additional technical publications are available for this machine, at a nominal cost, through your authorized international Construction Equipment distributor or dealer. This material includes Service Manuals and Technical Training Courses.

These additional publications are strongly recommended for the customer who performs his own maintenance and service on this equipment.

It is the policy of International Harvester Company to improve its products whenever it is possible and practical to do so. We reserve the right to make changes or add improvements at any time without incurring any obligation to make such changes on products sold previously.

UC-221 AND UC-263
ENGINES
AND
ATTACHMENTS
FORM
1 085 201 R1. Rev. 1

FEBRUARY, 1987

NOV-28-2001 00:09 SS/L 650 852 4274 P.02/23

# INTERNATIONAL ENGINES

# OPERATOR'S MANUAL

UC-221 AND UC-263
ENGINES
AND
ATTACHMENTS
FORM
1 085 201 R1. Rev. 1
FEBRUARY, 1987


## CONTENTS

	Pages
INTRODUCTION	3, 4
Ventilation for engines installed inside of buildings	4
Suggested engine and fuel tank arrangements	4
DESCRIPTION	5 to 8
DESCRIPTION	5
Operating controls and instruments	6 to 11
Operating controls and more within	• ••
OPERATION	9 to 22
Before starting a new engine	9.∕
Lubrication when shipped	····
Precautions	9,10
Liquefied petroleum gas or natural gas engines	1:07.11
Preparing the engine for each day's work	<u>-11</u> 11
Operating the engine	
Starting the engine	FP to 12
Operating the transmission	12
Stopping the engine	12,13
Top cylinder oiler	13
top cymider office and a second of the contract of the cymider of	- *
SCHEDULED MAINTENANCE	14 to 21
Scheduled	14, 15
Periodic	15
Lubrication	16,17
Lubrication specifications and capacities chart	17
Lubrication guide (engine)	18,19
Lubrication guide (transmission)	20
Lubrication guide (power take-off)	21
MAINTENANCE	22 to 51
Preparing for cold weather	22,23
Preparing for hot weather	23
Cooling system	23 to 28
Radiator type	23
Flo-matic type	23
Radiator cap	24
Cleaning the radiator core	
Thermostat	25 to 27 2 <b>7</b>
Water pump	27, 28
Belt	28, 29
Air cleaner (wet type)	29, 30
Cleaning the oil cup	29
Washing the air cleaner	29 <sub>f</sub> 30
Air cleaner (dry type)	30 to 32
Automatic dust unloader	30
Filter element service	30 to 32
Air intake cap	32 32
Crankcase breather	-
Lubricating oil filter	
Valve clearance adjustment	34
Oil level sight gauge	34, 35
Electrical system	35 to 41
Regulator	36
Generator	20
Cranking motor	36 36
Ignition coil	
Spark plugs	<u> </u>
Spark plug cables	<u> </u>
Storage battery	
Listricutor	


## **CONTENTS**

																		Pages
MAINTENANCE - Continued																		
																		39,40
7177 1 Ain amaro					•	•	•		•	•	•	•	•			1		39
										•	•	-	•	•	_	-	-	40
C (										•	•	•	•	•	•	-	•	41 to 43
Englacement (dasoline)						•	•		•	•	-	-	•					41
CLunaton				- +			•		• •	-	•	*	_	-				42
Engl - mechanical)						*	*			•	•	•	•	•	•	-	-	43
man (electric)							•			•	•	•	•	•	•	•	-	43
displies the filter screen							•			•	•	•	•	•	•	•	•	44,45
m -1 (liquefied petroleum	gas) .						-				•	•	•	•	•	•	•	44.45
A silvetime the comburator and It	egulate	OF	-			•	•			•	•	•	*	•	•	•	•	45
T-1 61+0+						•		- 1			•	•	•	•	•	•	•	45,46
1 -+ (matural stal												•	•	•	•	•	•	
· · · · · · · · · · · · · · · · · · ·	eouiat	COT	-				•			• •	•	•	•	•	•	•	-	46.47
ar limital warrawaar								•			-	-	•	•	_	-	-	47 to 49
— tala aff alestah								•		• •	-	-						49
m i siam alutah							•						_		-			49
a :							•	•			•	•	•	_	_			50 to 51
Preparing stored engine for serv	ice						٠	•	• •		•	٠	٠	•	٠	•	•	30 60 3.

## INTRODUCTION



Illust. 1 Right Front View of the UC-221 and UC-263
Engines with Various Attachments.




Illust. 2 Left Rear View of the UC-221 and UC-263 Engines with Various Attachments.

## INTRODUCTION


Instructions on operation, lubrication and maintenance for the basic engine and attachments are covered in this manual. Disregard any instructions on attachments that are not applicable to your engine.

Throughout this manual, the use of the terms "left," "right," "front" and "rear" must be understood to avoid confusion when following instructions. "Left" and "right" indicate the left and right sides of the engine when facing the engine from the flywheel end. The front of the engine is the fan drive pulley end.

When in need of parts, always specify the chassis and engine serial numbers. The engine serial number is stamped on the left side of the engine crankcase just below the distributor. (Illust. 3.) The chassis serial number is stamped on a name plate attached to the left side of the flywheel housing. (Illust. 4.)



Illust. 3 Engine Serial Number



illust. 4 Chassis Serial Number

Engine Serial Number	
C-221	
C-263	
Chassis Serial Number:	
UG-221	
UC-263	

# VENTILATION FOR ENGINES INSTALLED. INSIDE OF BUILDINGS

Engines installed inside buildings, sheds or cabs should be the open type; that is, with the engine hood and back panel removed to permit free circulation of fresh air around the engine, radiator, etc. Steps must be taken to carry the waste heat to the outside, or to change the air in the engine room rapidly.

The exhaust pipe should be arranged to provide the shortest possible length within the engine room. The part of the exhaust pipe inside the building should be surrounded with a light steel tube, sufficiently large to permit a two inch to four inch air space all around. This space should be ventilated to the outside. Another method of insulation is to cover the exhaust pipe completely with at least two inches of air-cell asbestos.

Ventilate the engine room thoroughly and install the engine so that air can flow freely through the radiator. An opening to the outside, in front of the radiator, is extremely desirable. Ducts should be provided between the radiator and the wall openings. On some installations, it may be necessary to provide a reverse-flow fan to blow the heated air out of the building.

Where the door or window area is restricted, galvanized ducts extending from the ceiling above the engine to the top of the building are recommended to carry off the hot air. Not less than two ducts, 24 x 24 inches in cross section, should be installed. At the same time, as many openings in the sides of the engine room as possible should be provided to let in cool outside air. Openings to a shaded side of the building are preferred.

# SUGGESTED ENGINE AND FUEL TANK ARRANGEMENT

- 1. Anchor the engine securely to a level solid foundation, preferably concrete.
- Mount the engine or driven equipment so that the belts may be removed or tightened.

## INTRODUCTION

- 3. Do not support a long exhaust pipe on the exhaust manifold; instead, use a flexible pipe at the engine and support the rigid pipe from the ceiling or floor.
- 4. Use long-sweep elbows in exhaust pipes.
- 5. For every 12 feet of exhaust pipe, enlarge the diameter of the pipe one standard pipe size.
- 6. Install the flexible exhaust piping so the belting may be adjusted without disconnecting any pipes or lines.
- 7. Install flexible fuel lines between the pipes to the fuel tank and the engine and a fuel shutoff valve at the tank.

## DESCRIPTION

SPECIFICATIONS AND CAPACITIES  Capacities (U.S. Measure)	Carburetor: Gasoline LPG Natural Gas Distributor:
Air cleaner oil cup (wettype) 2-3/4 pts  poling System: Radiator type	Point gap
The capacities which appear throughout this manual are specifically for these engines and their attachments.  Specifications  Engine  Cylinders	Torques (Foot-Pounds)  Lubricating oil filter center tube
Stroke: UC-221	Continued on next page.

## DESCRIPTION

#### Engine Speeds

Optional engine speeds are available. The high idle and full load governed speeds for which this engine is equipped and adjusted is stamped on the chassis serial number plate on the flywheel housing.

SS/L

## Dimensions and Weights (Approximate)

Length (overall less PTO):				50-5/64 in.
Height (over-all)				.38-1/2 in.
Width (over-all)	-			28 in.
Weight	•	•	•	12601bs
Weight	•	•	•	

#### Fuel (Gasoline)

These engines are shipped with the ignition timing set for maximum power on the average regular grade of gasoline of 89 Research octane number as domestically available in the U.S.A. For fuels of lower Research octane number, the timing may require retarding (approximately one degree retard from factory setting for each decrease of one octane number). Overseas fuels may, in many areas, be considerably lower in Research octane number than regular grade fuels obtainable in the U.S.A. Clear, unleaded fuels should never be used. Advancing the timing beyond the initial factory setting is not recommended and may only result in adverse effects. There is no particular advantage in using a fuel having a higher anti-knock value than the engine requires.

#### Fuel (LPG)

NOTE: It is recommended that LP Gas fuel meeting the Natural Gas Processor's Association (NGPA) specification for Propane HD5 be used if available.

## Specifications Subject to Change Without Notice

## OPERATING CONTROLS AND INSTRUMENTS

The operator must thoroughly familiarize himself with the instruments and controls provided for operation of this engine. There are important differences between various engines: therefore, regardless of previous experience with other machines, the operator should fully understand what each control is for and how to use it before starting to operate the engine.

Safety shut-off gauges have been pre-set at the factory. If any of these gauges fail to operate properly, consult your authorized International Engine Distributor or Dealer.


## Instruments (Hiust, 6 or 7)

This section describes the purpose or function of each instrument. For detailed information on correct operating indications or ranges, refer to "Instrument Check" on page 13.

#### Hourmeter

The hourmeter indicates the actual hours of engine operation. Its range is from zero to 10,000 hours. When the hourmeter reaches 10,000 hours, it automatically starts again at zero.

And the second s



#### Illust. 6 Instrument Panel (Regular.Gauges)-

- 1. PANEL, instrument.
- 3. HOURMETER.
- 4. INDICATOR, engine oil pressure.
- 6. BUTTON, choke control.
- 8. SWITCH, ignition and starter.
- 9. INDICATOR, heat.
- 10. AMMETER.
- 11. TACHOURMETER.


## DESCRIPTION

## Engine Oil Pressure Indicator

This instrument registers the pressure of the lubricating oil circulating through the engine.

## Safety Engine Oil Pressure Indicator

This indicator is part of the instrument panel (safety gauges) attachment. The safety engine oil pressure indicator shows the pressure of the lubricating oil circulating through the engine. If the oil pressure drops below minimum operating pressure, the engine will automatically stop.



Illust. 7 Instrument Panel (Safety Gouges).

- 1. PANEL, instrument.
- 3. HOURMETER.
- INDICATOR, safety engine oil pressure.
- 5. SWITCH, ignition relay.
- KNOB, governow control.
- 7. BUTTON, choke control
- 9. SWITCH, ignition and starter.
- 10. INDICATOR, safety heat.
- 11. SWITCH, safety control toggle.
- 12. AMMETER.
- 13. TACHOMETER.

#### Heat Indicator

The heat indicator shows the temperature of the coolant circulating in the engine.

#### Safety Heat Indicator

This indicator is part of the instrument panel (safety gauge) attachment. The safety heat indicator registers the temperature of the coolant circulating in the engine. If the temperature of the coolant reaches 195°F, the engine will automatically stop.


#### Ammeter

This instrument indicates the rate at which the battery is being charged or discharged.

#### Tachourmeter (Illust. 8)

The upper half of this indicator shows the engine rpm; the lower half of the indicator shows the indicated hours of engine operation.

This indicator has a correction factor to determine the actual hours of engine operation from the indicated hours. Refer to example following.



Illust. 8
Tachourmeter

#### EXAMPLE:

Engine rpm - 2000

Indicated hours - 100

To determine the actual hours of operation, multiply the indicated hours (100) by the correction factor (.83). The actual hours: 83 hours.

## DESCRIPTION

Controls (Illust. 6 or 7)

## Ignition and Storter Switch

This switch has four positions: 1. Switch to the left ("ON" position) for accessories; 2. "OFF" position; 3. "ON" position to the right to energize the electrical system; 4. switch all the way to the right ("ST" position) for cranking the engine.

## Ignition Relay Switch

This switch is part of the instrument panel (safety gauges) attachment. It is a push-button type switch.

## Governor Control Knob

This knob controls the engine speed.

To obtain a specified engine rpm, depress the button in the center of the control knob and pull out on the knob until the approximate engine rpm is reached. Release the button and the knob will automatically lock in place. For a finer adjustment rotate the knob in a counterclockwise direction (to increase engine rpm) or clockwise (to decrease engine rpm).

## Choke Control Button

The choke control button aids in starting a cold engine. On gasoline engines, the choke control button can be used to put the choke valve in intermediate positions.

On liquefied petroleum gas and natural gas engines, the choke control button puts the choke valve in two positions (all the way opened or all the way closed).

## Safety Control Toggle Switch


This switch is part of the instrument panel (safety gauges) attachment. The switch has an "OFF" and "ON" position. Before starting the engine, move the switch to the "OFF" position. When the engine has started and after the load is applied, move the switch to the "ON" position.

## Power Take-Off Clutch Lever (Illust. 9)

This lever is used to engage or disengage the engine from the load.

## Power Take-off Clutch Shaft Outer Bearing Housing Temperature Switch

This switch is part of the power take-off attachment. The switch is located at the bottom of the clutch shaft outer housing. If the temperature of the lubricant in the housing reaches 250°F, the engine will automatically stop.



Illust. 9
Power Take-Off Clutch Lever Positions
(Left Hand Lever Installation Shown).

## Transmission Gearshift Lever (Illust. 10).

The transmission gear shift lever is used to select the various gear ratios provided in the transmission.



11]ust. 10 Transmission Gearshift Lever.

## BEFORE STARTING A NEW ENGINE

This engine has been given predelivery and delivery service by your distributor or dealer.

As an added precaution, the following steps must be observed.

- 1. Check the cooling system level and fill if necessary. (Refer to "Filling the Cooling System" on page 25.)
- 2. Check the oil in the engine crankcase, the air cleaner oil up (wet type if equipped), power take-off (if equipped) and transmission (if equipped) to be sure they are filled to the correct levels with the proper grades of oil for the prevailing temperature. Refer to "LUBRICATION WHEN SHIPPED" on this page.
- 3. Service the battery as instructed on the tag attached to the battery. Connect the ground strap to the correct battery terminal. Connect the generator-to-regulator cable to the "F" terminal on the generator. Refer to the "Wiring Diagrams" on pages 39 and 40.

NOTE: Do not start the engine until the generator has been polarized to the battery.
(Refer to "Polarizing the Generator" on page 36.)

4. Remove the spark plugs and put about one teaspoonful of engine oil into each cylinder. Install and tighten the spark plugs (refer to "Torques" on page 5) and crank the engine to distribute the oil over the cylinder walls.

NOTE: The lubrication procedure above is necessary only in starting a new engine or one that has been idle for a long time. For the procedure in starting an engine that has been removed from storage, refer to "PRE-PARING STORED ENGINE FOR SERVICE" on page 50.

5. Operate a new engine with light loads only for the first 20 to 30 hours at wide open throttle.

## LUBRICATION WHEN SHIPPED

#### Engine

The crankcase was filled at the vactory with a break-in and preservative engine oil. This oil may be used on light and medium loads at temperatures below +80°F for the first 20 to 30 hours of operation. If the temperature is above +80°F, drain the oil from the crankcase. Refill the crankcase with the required amount of oil having the physical properties and proper viscosity grade suitable for the prevailing temperature. Refer to the "LUBRICATN SPECIFICATIONS AND CAPACITIES CHART" on page 17.

#### Air Cleaner

## Wet Type (If Equipped)

The oil in the air cleaner (wet type only) may be used in 0°F to +90°F temperature range until the normal change period occurs. If the prevailing air temperature is above +90°F or below 0°F, change to the proper viscosity of oil specified in the "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.

## Dry Type (If Equipped)

DO NOT OIL THE AIR CLEANER ELEMENT.

#### Power Take-Off

Some engine power take-offs have a compartment of engine oil for lubrication of the clutch shaft outer bearing. If your power take-off has this compartment, use this lubricant until the normal change period occurs.

#### Transmission

The lubricant in the transmission can be used until the normal change period occurs.

#### Export

The preceding information applies, except: The air cleaner is drained before shipment, and must be filled before operation. Refer to the "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.

#### PRECAUTIONS

#### General

Your engine is designed to operate on one of the following fuels: gasoline, liquefied petroleum or natural gas. Do not attempt to operate this unit on a fuel other than that for which it is equipped.

The power take-off clutch must be adjusted several times within the first 10 hours of operation. Refer to "Adjustment" on page 47 for the correct adjusting procedure.

Do not pour cold coolant into the radiator or expansion tank if the engine is very hot unless conditions make it absolutely necessary. Under such conditions, start the engine and let it idle while pouring the coolant slowly into the radiator or expansion tank. Tighten the cap securely.

Never operate the engine under load before it is thoroughly warmed up.

Never operate the engine at more than the rated governed speed shown on the serial number plate on the flywheel housing. Excessive speeds are harmful.

Do not attempt to adjust the governor. The governor is set at the factory. If the governor does not function properly, consult your authorized International Engine Distributor or Dealer for repair or replacement.



CAUTION: FOR PERSONAL PRO-TECTION, OBSERVE THE FOLLOW-ING SAFETY PRECAUTIONS.

Never operate an engine in an enclosed building unless the exhaust is properly ventilated. Refer to "VENTILATION FOR ENGINES INSTALLED INSIDE OF BUILDINGS" on page 4.

Because of fire hazards and insurance regulations, do not use gasoline for cleaning parts, especially when service is performed inside buildings. A less flammable fluid, such as a commercial solvent or kerosine, should be used.

Never attempt to clean or oil the engine while the engine is operating.

## Liquefied Petroleum Gas or Natural Gas Engines

CAUTION: SAFETY PRECAUTIONS IN THE HANDLING OF BUTANE-PROPANE CANNOT BE OVER-EM-PHASIZED. THERE ARE STATE, COUNTY OR CITY LAWS, ORDINANCES, AND FIRE REGULATIONS COVERING THE UTILIZA-TION OF LIQUEFIED PETROLEUM GAS OR NATURAL GAS. SUCH LAWS, ORDI-NANCES AND FIRE REGULATIONS ON THIS SUBJECT MUST BE ADHERED TO IN ADDITION TO THE SAFETY RULES GIVEN BELOW.

Where local rules are more stringent than these given, the local rules are to be given priority.

These rules apply to servicing any engine using liquefied petroleum gas (butane-propane) or natural gas for engine fuel regardless of the nature of the work to be performed.

Select a location for servicing these engines where there will be good air circulation. This is to avoid accumulation of gas-air mixtures in and about the engine caused by undetected leaks.

Such location must be as far as possible from steam cleaners, hot water cleaners, hot dip tanks, etc., and any other device operating with an open flame.

Shut off the main valves at the fuel tanks and allow the engine to run until all fuel in the system, from the tank to the engine, is exhausted. In the event the engine is inoperative, shut the valve at the tank. Vent the fuel system of liquefied petroleum or natural gas outside the building before moving the engine into the shop.

"DANGER" signs must be placed on both sides of the engine. There is to be no smoking in the vicinity. No work is to be performed on this engine or on others in a nearby zone involving open flames, such as cutting, welding, grinding, chiseling or any similar operation which may ord±±ce produce sparks. ・・・ なぐこと ふきりゃく・・

A fire extinguisher (dry powder or carbon dioxide, CO2) must be placed adjacent to the mechanic's working area, handy for immediate use. When liquefied petroleum gas ignites, it should be allowed to burn, if possible, until the source of fuel is shut off. Extinguishing the fire before this is accomplished can result in dangerous accumulations of gas which might cause a more serious flash or explosion.

After completing service work and before starting the engine, allow air to circulate around the engine to remove any possible gas accumulation.

Neveruse liquefied petroleum gas from the fuel tanks for cleaning parts. This is mentioned because inspections have revealed that operators have used it as a substitute for solvents and compressed air, not realizing the extreme danger of this practice.

Whenever the nature of service work requires any operation on the fuel system, the following must be observed:

- a. All threaded connections should be treated with an insoluble lubricant (Permatex or aviation gasket maker). Replace worn or defective fittings. The state of the s
- b. After connecting the fuel system, check it for leaks. Leaks are not permissible. Odorants, which are strong smelling compounds (an odor similar to spoiled cabbage), are added to liquefied petroleum gas as warning agents to indicate the leakage of even small quantities of gas.
- c. A lather of soap, brushed on with a soft brush, will indicate the presence of leaks, which are dangerous and wasteful. Neveruse an open flame to check for leakage.

Pay particular attention to short lengths of rubber hose used anywhere in the piping system to relieve stress and vibration.

Any necessary work on liquefied petroleum gas or natural gas fuel tanks must be performed by qualified concerns who normally service such containers and who are familiar with local regulations, inspections and tests after any repairs are made.

It is important to remember that all liquefied petroleum gas systems are pressurized. Be certain that the tank valves are tightly closed and all fuel has been exhuasted from the lines before starting any repair work on the fuel system.

## PREPARING THE ENGINE FOR EACH DAY'S WORK

## Fuel System (Gasoline)

Fill the fuel tank. Use a gasoline conforming to the specifications as shown on page 5. DO NOT USE DIRTY FUEL.

CAUTION: NEVER FILL THE FUEL
TANK WHEN NEAR AN OPEN FLAME
OR WHEN THE ENGINE IS OPERATING. KEEP THE FUNNEL OR HOSE NOZZLE, USED FOR POURING IN THE FUEL,
IN CONTACT WITH THE METAL OF THE
TANK TO AVOID THE POSSIBILITY OF AN
ELECTRIC SPARK IGNITING THE GAS. DO
NOT LIGHT MATCHES NEAR GASOLINE,
AS THE AIR WITHIN A RADIUS OF SEVERAL FEET IS PERMEATED WITH A
HIGHLY EXPLOSIVE VAPOR.

#### Cooling System

NOTE: Do not start the engine until the cooling system is filled with coolant.

Remove the radiator cap or the expansion tank filler cap and check to be sure the coolant comes to a level approximately one inch below the filler neck. Add coolant if necessary. Install the filler cap or the radiator cap and tighten it securely.

#### Lubrication

Check the air cleaner to be sure the oil is up to the "OIL LEVEL" bead marking on the inside of the oil cup.

Be sure that the oil level in the crankcase is up to the "FULL" mark on the crankcase oil level gauge. Refer to the "LUBRICATION GUIDE" on pages 18, 19, 20 and 21 for complete lubrication requirements.

#### OPERATING THE ENGINE

## Starting the Engine

Read and observe the "PRECAUTIONS" on pages 9 to 11.

- 1. Open the shut-off valve on the fuel supply line.
- 2. POWER TAKE-OFF (IF EQUIPPED): Place the clutch lever in the "Disengaged" position (Illust. 9).
- 3. TRANSMISSION CLUTCH (IF EQUIPPED): Disengage the clutch.
- 4. TRANSMISSION (IF EQUIPPED): Place the transmission gearshift lever (Illust. 10) into "neutral" (N). Release the clutch release shaft lever.
- 5. GOVERNOR CONTROL KNOB (IF EGHIP-PED): Move the knob until it is about one-quarter advanced.

NOTE: LIQUEFIED PETROLEUM AND NATU-RAL GAS ENGINES ONLY: Set the knob at onehalf advanced.

6. GASOLINE ENGINES ONLY: Pull the choke control button out part way. (In cold weather pull it out all the way.)

LIQUEFIED PETROLEUM GAS AND NATURAL GAS ENGINES ONLY: Pull the choke control button out all the way.

- 7. INSTRUMENT PANEL (SAFETY GAUGES) (IF EQUIPPED):
  - a. Move the safety control toggle switch to the "OFF" position.
  - b. Push in the ignition relay switch.
- 8. Turn the ignition and starter switch all the way to the right to the "ST" position.

NOTE: Never operate the cranking motor for more than 30 seconds at one time. If the engine does not start, allow the cranking motor to cool two or three minutes before cranking again.


- 9. If the engine will not start in cold or damp weather, remove and dry the spark plugs. Check the spark plug gap. Refer to "SPECIFICATIONS" on page 5. Reinstall and tighten the plugs. Refer to "Torques" on page 5 for the specified torque.
- 10. GASOLINE ENGINES ONLY: After the engine starts, push the choke control button in to a point where the engine runs without missing and, as the engine warms up, gradually push the choke all the way in.

् १०५७

## **OPERATION**

LIQUEFIED PETROLEUM GAS AND NATURAL GAS ENGINES ONLY: After the engine starts, allow warm-up periods as required to eliminate using the choke. After the engine warms up, push the choke control button all the way in.

- 11. GOVERNOR CONTROL KNOB (IF EQUIP-PED): Adjust the knob to meet the load requirements.
- 12. POWER TAKE-OFF (IF EQUIPPED): Place the power take-off clutch lever in the "engaged" position (Illust. 9).
- 13. TRANSMISSION CLUTCH (IF EQUIPPED): Disengage the clutch.
- 14. TRANSMISSION (IF EQUIPPED): Move the transmission gearshift lever to the correct position for the speed desired (Illust. 11). Slowly release the clutch release shaft lever to pick-up the load.



Illust. 11 Transmission Georshift Shift Pottern.

- 15. INSTRUMENT PANEL (SAFETY GAUGES) (IF EQUIPPED): Move the safety control toggle switch to the "ON" position.
- 16. Check all instruments for the proper readings. Refer to the "Instrument Check" on this page.

## Transmission Gear Ratios

SPEED	REDUCTION
lst.	6.4 to 1
2nd.	3.1 to 1
3rd.	1.7 to 1
4th.	1.0 to 1
Rev	7.8 to 1

## Instrument Check

Check all indicators (Illust. 6 or 7) immediately after starting, again upon reaching operating temperature and at frequent intervals during operation to assure proper care through prompt detection of irregularities. If any of the indicators do not register properly; stop the engine, and locate and correct the cause immediately. If unable to find the cause consult your authorized International Engine Distributor or Dealer.

#### Ammeter

The ammeter should indicate "charge" whenever the engine is operating at a speed faster than low idle speed. If it indicates "discharge" or a high rate of "charge" continuously while the engine is operating at this speed, investigate the cause immediately.

#### Heat Indicator

The heat indicator pointer must be in the "RUN" range, after the engine is warmed up, for the most efficient operation.

## Engine Oil Pressure Indicator

If the indicator pointer does not move into the "IDLE" range while idling or into the "RUN" range when the speed of the engine is increased, stop the engine and inspect the oil system to find the cause. If unable to find the cause, consult your authorized International Engine Distributor or Dealer.

## Stopping the Engine

- 1. POWER TAKE-OFF (IF EQUIPPED): Place the clutch lever in the "disengaged" position (Illust. 9).
- 2. TRANSMISSION CLUTCH (IF EQUIPPED): Disengage the clutch.
- 3. TRANSMISSION (IF EQUIPPED): Place the transmission gearshift lever in neutral (N). Engage the transmission clutch.
- 4. INSTRUMENT PANEL (SAFETY GAUGES) (IF EQUIPPED): Move the safety control toggle switch to the "OFF" position.
- GOVERNOR CONTROL KNOB (IF EQUIP-PED): Move the knob to the "low idle" position.

Operate the engine at low idle for a minimum of three minutes to avoid excessive loss of coolant due to "afterboil" or heat surge.

NOTE: Serious damage can result to the engine if the above step is neglected.

SS/L

6. Turn the ignition and starter switch to the "OFF" position.

#### Top Cylinder Oiler (If Equipped)

The Marvel Inverse Oiler is operated by vacuum in the intake manifold, but inversely to the vacuum.

When the vacuum in the manifold is high, such as when the engine is running at low idle (closed throttle) only a small amount of oil will feed. When the engine is placed under load (throttle opened), the manifold vacuum falls and the oiler automatically feeds more rapidly. The increase or decrease of the oil flow is in strict accordnance with the load demand on the engine.

Accelerating the engine without load will not affect oiler action. The engine must be pulling under load.

Avoid operating the oiler with the container empty, as this will cause the valve and seat to wear excessively. Use only the manufacturer's recommended oil.

## Adjustment (Illust. 12).

- 1. Thoroughly warm up engine and oiler. After reaching proper operating temperature, be sure choke is open.
- 2. Remove duct cap (A) on the top of the oiler.
- 3. Increase the engine speed to full load governed speed and apply the normal operating load.
- 4. Count the number of drops of oil per minute passing the vision glass (D).
- 5. If necessary, turn the adjusting knob (C) to the right or left until the count is about four drops per minute for each 10 horsepower at the flywheel (refer to chart).

Engine	Maximum Flywheel HP at 2400 RPM					
	Gasoline	LPG	Nat. Gas.			
UC-221	75	73	65			
UC-263	95	89	80			

- 6. Replace dust cap (A).
- 7. For accuracy, check oil drop count after about 10 hours of operation and readjust if necessary.

NOTE: Screw (B) is for factory calibration only and should not be opened on stationary engine applications.



Illust. 12 Top Cylinder Oiler.

- A. CAP, dust.
- C. KNOB, adjusting.
- B. SCREW. D. GLASS, vision.

Scheduled and periodic maintenance and inspections are very important functions which every owner and/or operator must follow to assure the maximum performance of the engine. To assure mechanical efficiency, it is necessary that this engine be systematically inspected and maintained at the intervals outlined below.

## **SCHEDULED**

Point	οf	Ins	pec	tion
-------	----	-----	-----	------

#### Remarks

## After Every 10 Hours of Operation

*Air cleaner intake cap	Remove and clean. Refer to "Air Cleaner Intake Cap" on page 32.
*Air cleaner oil cup (wet type)	Check to be sure the oil is up to the "OIL LEVEL" mark on the oil cup. Clean and refill the oil cup when 1/2 inch of dirt has accumulated in the cup. Refer to "Cleaning the Oil Cup" on page 29.  Check the coolant level in the radiator. Refer
Cooling system	to "Cooling System" on page 23.
Lubrication points	Refer to the "LUBRICATION GUIDE" on pages 18 and 21.

## After Every 50 Hours of Operation

#Air cleaner element (dry type)	Clean. Refer to "Filter Element Service" on pages 30 and 32.
Flexible rubber connections between air cleaner and intake manifold	Inspect for loose fit or damage. Apply two or three drops of oil to the Flo-matic
Flo-matic control linkage	control linkage. Check the tension. Refer to "BELT" on page 28.
Fan belt	Check and adjust if necessary. Refer to "Adjustment" on page 45.
Radiator core	Clean the core. Refer to "Cleaning the Radiator Core" on page 25.
Lubrication points	Refer to the "LUBRICATION GUIDE" on pages 20 and 21.

## After Every 125 Hours of Operation

Automatic dust unloader (dry type air cleaner only)	Empty. Refer to "Automatic Dust Unloader" on page 30.
##*Battery liquid level	Check. Refer to "Liquid Level" on page 36. Remove and clean. Check gap. Refer to "Spark Pluge" on page 35.
Lubrication points	Refer to the "LUBRICATION GUIDE" on pages 19, 20 and 21.

<sup>\*</sup>When unusual dust or dirt conditions are encountered during operation, it may be necessary to service these points more frequently.

<sup>\*\*</sup>This interval specified for clutch adjustment must be used only as a guide or reminder for checking the engagement. Experience will indicate if this adjustment can be checked less frequently.

<sup>\*\*\*</sup>When the ambient temperature is continuously +90°F or higher, the liquid level must be checked every 50 hours.

Point of Inspection

Remarks

## After Every 250 Hours of Operation

*Crankcase breather	Remove and clean. Refer to "Crankcase Breather" on page 32.
Distributor contact points	Check the gap. Refer to "Checking the Breaker Chamber and Breaker Points" on page 36.
Electric fuel pump	Clean the filter screen. Refer to "Cleaning the Filter Screen" on page 43.
Fuel pump sediment bowl (mechanical fuel pump)	Remove and clean. Refer to "Cleaning the Fuel Pump Filter" on page 42.
Lubrication points	Refer to the "LUBRICATION GUIDE" on pages 19 and 20.

#### After Every 500 Hours of Operation


Carburetor fuel screen (gasoline)	Remove and clean. Refer to "Carburetor" on page 40.
Cooling system	Clean. Refer to "Cleaning the Cooling System" on page 25.
Distributor cap	Remove and clean. Refer to "Distributor Cap" on page 36.
Engine valves	Check clearances. Refer to "Valve Clearance Adjustment" on page 34.
Lubrication points	Refer to "LUBRICATION GUIDE" on pages 19 and 21.

## After Every 1000 Hours of Operation

Refer to "LUBRICATION GUIDES" on pages 18, Lubrication points . 19, 20 and 21.

#### PERIODIC

Battery terminals	Clean the terminals. Refer to "Cleaning and Servicing the Battery" on page 36.
Fuel filter (LPG)	Change filter. Refer to page 36. Clean this screen whenever the oil pan is re-
Wiring	moved.  Check for worn, cracked or frayed insulation, broken wires, loose or corroded connections.



For information about the lubrication of a new engine, refer to "LUBRICATION WHEN SHIPPED" on page 9.

#### LUBRICATION

The life and performance of an engine depends on the care that it is given and proper lubrication is probably the most important maintenance service for your engine.

Thorough lubrication service performed at the scheduled intervals and according to an established routine will aid greatly in prolonging the life of the engine and in reducing operating expense.

The type of work being done, load and weather conditions are all factors to consider in the frequency of lubrication. The scheduled intervals of lubrication shown on the "LUBRICATION GUIDE" are approximate, being based on average operating conditions.

It may be necessary to lubricate after shorter working periods under severe operating conditions such as extremely dusty conditions, low engine temperatures, intermittent operation and excessively heavy loads with high oil temperatures. However, the time intervals between lubrication periods must never exceed those indicated in this manual.

## Selection of Lubricants

The selection of the proper type (specification) and grade (weight or viscosity) of lubricant is not guess work. Many tests have been made to determine the correct lubricants for this engine and its equipment. For detailed information regarding lubricants, refer to "LUBRICANT SPECIFICATIONS AND CAPACITIES" on this page.



## Lubricant Viscosities

During cold weather, base the selection of a crankcase lubricating oil viscosity on the lowest anticipated temperature for the day to make starting easier. For hot weather operation, base the selection on the highest anticipated temperature. Refer to "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.

When the temperature changes, even though the regular interval of lubrication has not been reached, the lubricants must be altered to agree with the temperature.

NOTE: It is not necessary to change the lubrication in the different compartments when the temperature falls into a different range during a working day. For example: Grade-30 oil may be used instead of Grade-10 oil in temperatures below +32°F if no starting difficulty is experienced; Grade-10 oil, that is specified for use in temperatures of +32°F to -10°F, may be used in temperatures as high as +40°F, except when operating under continuously heavy loads.

## Thinning the Crankcase Oil

In LPG or natural gas engines there may be a tendency for the oil in the crankcase, to gradwally become thicker. In such cases, it may be desirable to use a lighter grade oil or in cold weather to add one quart of kerosine to the crankcase between specified oil changes in order to maintain easy cranking.

## Precoutions

After changing engine oil, operate the engine at low idle, without load, for at least five to ten minutes. This will allow the oil to work into the bearings and onto the cylinder walls.

# LUBRICANT SPECIFICATIONS AND CAPACITIES

It is not the policy of the International Harvester Company to approve lubricants or to guarantee oil performance in service. The responsibility for the quality of the lubricant must remain with the supplier of the lubricant. When in doubt, consult your authorized International Engine Distributor or Dealer for information given in the latest service bulletin on crankcase lubricating oils or gear lubricants. The specified type and viscosity of lubricants recommended for use with this engine are shown in the "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.

LUBRICANT SPECIFICATIONS AND CAPACITIES CHART (U.S. MEASURE)

LUBRICANT KEY:

EO - Engine Oil

MPL - Multi-purpose Type Gear Lubricant

HTG - High Temperature Grease

		ANTICIPATED AIR TEMPERATURE				
Lubrication Point	Capacity	Above +32°F	+32°F to +10°F	+10°F to -10°F	-10°F to -20°F	Below -20 <sup>o</sup> F
Crankcase		EO - MIL-	L-2104B, DEF	-2101C (Gasoline or Service "MS"	e engines (Δ)	_
With Filter Drained With Filter Changed	8 qts. 9 qts.	Grade-30	Grade-10 or SAE-10W-30 or SAE-20W	Grade-10 or SAE-10W-30	8 qts. Grade-10 diluted w/ l qt. kerosine	MIL-L- 10295A
Air Cleaner: Wet Type	2-1/2 pts.			le lubricant as in	<del>-</del> '	
Power Take-Off	Fill as in- structed.	EO - MIL-L-2104B, Sup. 1, DEF-2101C, or Service "MS" Grade-30				IS''
ransmis-		MPL - IH B	-22 Grades 132	H EP, 134H EP	(*) or MIL-L.	- 2105B
Sliding Gear Synchromesh	5 pts. 7 pts.	Grade-90 Grade-80 (%)			MIL-L- 10324A	
All Lubrica- tion Fittings	Fill as in- structed.	HTG - MIL	-L-3545 or MII	G-3545A.		

<sup>(%) -</sup> A multi-grade 80-90 may be used at temperatures of -20°F to +90°F. A grade-140 may be used above +90°F.

<sup>(\*) -</sup> For specifications consult your authorized International Engine Distributor or Dealer.

 $<sup>(\</sup>Delta)$  - If an oil for service "MS" is used, it should have been performance tested in accordance with the "Engine Operating Test Sequences for MS Service" as published in the current hand book of the SAE (Society of Automotive Engineers, Inc.). These sequences are sometimes referred to as the "ASTM G-IV Test Sequences." Oil so tested should have their containers marked with a closely related qualifying phrase.

SS/L

Always use clean containers. Keep the lubricator clean. Wipe dirt from the fittings before installing fresh lubricant.

Occasionally apply a few drops of engine oil to the engine control linkage and flomatic control linkage.

Engine oil level gauge Hours Lubricant Point of Lubrication 8 1257 Point of Lubrication Lubricant Hours 0. and fill when 1/4 inch lated or when oil will of dirt has accumunot flow freely.

SCHEDULED MAINTENANCE with the engine stopped, gauge, Install the cap. Apply 8 to 10 drops of unscrew the cap. Add oil up to the "FULL" mark on the oil level and crankcase filter Generator

oil in each cup (two places).

8

cranking motor on engine. move the drive end hous-Remove cranking motor Reinstall plug. Install from the engine, Reing plug and saturate wick with engine oil. Cranking motor 얺

Delication

1000

**M**orterrese

LUBRICATION POINTS ON THE RIGHT SIDE

Install the drain plug the oil is still warm.

crankcase drain (pipe

gauge, remove the

an oil level sight

(On LPG or natural

plug) from the tee

after 250 hours of gas engines, drain

operation.)

engines equipped with

nil level gauge. (On

"FULL" mark on the

and refill to the

drain completely while


oil pan drain plug and

Remove the crankcase

Crankcase drain

G

# Breaker arm rubbing Solock block of high temperature grease back of the block. Distributor rotor Remove distributor cap and rotor. Apply two or three drops of oil to felt in the end of the rotor shaft. Distributor rotor shaft Remove plug and fill with oil. Use sealing Breaker arm pivot post, Apply one drop Hours Lubricant Point of Lubrication compound when reof Grade-10W. placing plugs. Distributor 8



Lubricating oil filter . Drain the filter and

"LUBRICATING OIL

FIL TER" in the

cedure, refer to

For the correct pro-

replace the element.

hours of operation.)

element after 500 replace the filter

natural gas engines,

Section, On LPG or "MAINTENANCE"

CEA-84740

MPL

-250

Point of Lubrication Lubricant Hours

 $\frac{50}{1}$ 

MPL.

the bottom of the filler be sure the level is at Remove the filler and level plug. Check to Transmission level .

opening. Install the filler and level plug.

LUBRICATION GUIDE

Hours Lubricant Point of Lubrication

flush the transmission while the lubricant is still warm. Drain and plug; also remove the filler and level plug Transmission drain Remove the drain


case. Install the drain plug. Fill to the bottom of the filler opening. Install the filler and level plug.


LUBRICATION POINTS FOR THE TRANSMISSION


20

Points of lubrication are individually explained under "LUBRICATION INSTRUCTIONS" below.

## ROCKFORD AND TWIN DISC








## TWIN DISC WITH OIL LUBRICATED OUTER BEARING

Single Plate Type



## LUBRICATION INSTRUCTIONS

Item No.	Description	Lubri- cant	Hours	Item No.	Description Outboard Bearing	Lubri- cant HTG	Hours 10	
1	l Clutch Throwout Bearing Over 10 engagements per day	HTG	10	,	Apply two or three strokes of the lubricator.			
	Less than 10 engage- ments per day	HTG	50	ó	Clutch Shaft Outer Bearing Filler and Level Plugs	EO	1 2 5	
2	Clutch Shaft Outer Bearing (On some clutches, the fitting is located on the opposite side.) Apply two or three strokes of the lubricator.	н <b>т</b> С	1 25		Open the filler cap indicated by solid arrows and remove the level plug indicated by dotted arrows and fill until oil runs out of level hole. Reinstall the plugs,			
3	Clutch Pilot Bearing Over 10 engagements per day Less than 10 engage- ments per day Apply two or three stroke of the lubricator Refer to NOTE.	HTG HTG	10 50	7	Clutch Shaft Outer Bearing Drain Plug Remove plug while lubricant is still warm. After allowing time for complete draining, reinstall plug and refill at filler.	EO	500	⊹ট ⊹ই
4	Clutch Lever Shaft Rockford or Borg and Beck Apply two orthree stroke of the lubricator.	* EO	125	8	Clutch Lever Shaft Apply two or three strokes of the lubricator.	нтС	.125	
	Twin Disc Apply five or six drops of oil in each cup.	EO			and the second s	with		

NOTE: On applications where the end of the output shaft is covered with a universal joint or flexible coupling, transfer the lubrication fitting from the end of the shaft to the cross-drilled location (indicated by dotted arrow). Use the pipe plug removed from the cross-drilled hole to close the opening in the end of the output shaft. This fitting is the only means of lubricating the clutch pilot bearing.

#### PREPARING FOR COLD WEATHER

In order to operate the engine in temperatures of +32°F or lower, observe the following instructions.

#### Fuel System

Use only a fuel conforming to the proper specifications as shown under fuel specifications on page 5.

GASOLINE ENGINES ONLY: Fill the fuel tank at the end of each day's work to prevent condensation of moisture in the tank.

#### Lubrication

Lubricate the engine completely with lubricants specified for operation below +32°F as outlined in the "LUBRICATION GUIDE" on pages 18, 19, 20 and 21.

## Cooling System

When the air temperature is consistently at the freezing point (+32°F) or lower, install antifreeze in the cooling system.

Before installing anti-freeze in the system, make the following check:

- Check the system for leaks.
- 2. Inspect all hoses and tighten all hose clamps. Install new hoses if necessary.
- 3. Drain and clean the system. Refer to "Draining the Cooling System" and "Cleaning the Cooling System" on pages 24 and 25.
  - 4. Check the operating condition of the thermostat. Refer to "Thermostat" on page 26.
  - 5. Check the condition and tension of the fan belt. Replace the belt if necessary. Refer to "BELT" on pages 28 and 29.
  - Be sure all drain valves are closed, and all connections securely tightened.
  - 7. Install the required amount of anti-freeze (refer to the following paragraph "Anti-Freeze Solutions") into the engine and fill the system with coolant as outlined under "Filling the Cooling System" on page 25.

8. Start the engine. After normal operating temperature has been reached, check the system to be sure there are no leaks.

#### Anti-Freeze Solutions

IH Premium anti-freeze (permanent type) is the recommended solution to be used in this engine. Do not use Menthanol or alcohol as an anti-freeze.

NOTE: Do not mix solution. Mixed solutions make it impossible to determine if the cooling system has adequate protection against freezing.

Check the solution frequently to be sure the cooling system has sufficient protection against freezing.

NOTE: When testing the solution be sure the system is at normal operating temperature. This is necessary to obtain an accurate reading.

The following table shows the percentage of anti-freeze solution required for the various temperatures.

Freezing Point (Fahrenheit)	USE IN COOLING SYSTEM		
	IH Premium (Ethylene Glycol-Permanent Type)		
+20° +10° -10° -20° -30° -40° -50° -60°	15% 25% 33-1/3% 40% 45% 50% 54% 58% 62% 65%		

#### Battery

When the air temperature drops to +32°F or lower, the efficiency of the battery decreases rapidly. At temperatures of -20°F or lower, do not try to start the engine unless the battery has been heated. Immersion in warm water to

within an inch or two of the top of the battery case is a satisfactory means of warming a battery.

It is especially important to keep the battery at full charge for cold weather operation. Check the specific gravity of the battery electrolyte at frequent intervals, and keep the battery as fully charged as possible. Add distilled water to the battery in freezing temperatures only when the engine is to operate for several hours to thoroughly mix the water and the electrolyte, or damage to the battery will result from the water freezing.

CAUTION: BATTERIES GIVE OFF HIGHLY INFLAMMABLE GAS. NEVER ALLOW SPARKS OR OPEN FLAME NEAR THE BATTERIES. AVOID SPILLING ANY ELECTROLYTE ON HANDS OR CLOTHING.

## PREPARING FOR HOT WEATHER

#### Lubrication

Lubricate the engine completely with the lubricants specified for operation above +32°F as outlined in the "LUBRICATION GUIDE" on pages 18, 19, 20 and 21.

#### Fuel System

GASOLINE ENGINES ONLY: Fill the fuel tank at the end of each day's work to prevent condensation of moisture in the tank.

#### Bottery

Inspect the battery frequently to be sure the electrolyte is at the correct level. (Refer to "Liquid Level" on page 36.)

#### Cooling System

To prevent overheating, these steps must be followed:

- 1. Clean and flush the internal parts of the cooling system. (Refer to "Cleaning the Cooling System" on page 26.) When filling the cooling system, follow the method described under "Filling the Cooling System" on page 25.
- 2. Insects and dirt must be cleaned from the external part of the radiator. (Refer to "Cleaning the Radiator Core" on page 25.)
- 3. Check the condition and tension of the fan belt. Replace the belt if necessary. Refer to "BELT" on page 28.
- 4. Check the operating condition of the thermostat. Refer to "Thermostat" on page 26.

## COOLING SYSTEM

The following maintenance procedures cover two types of cooling systems; the radiator type and the Flo-matic type. These procedures are the same for both types except as indicated.


## Radiator Type

The radiator type is a pressure-cooled system and will not operate properly unless the cooling system is tight. The filler cap must be properly tightened to the stop. The gasket surface of the cap must be in good condition. The system must not have loose connections or leaks. Unless these instructions are followed, pressure will not be maintained and loss of coolant and consequent overheating will result.

#### Flo-matic Type (Illust. 13)

The Flo-matic type cooling system automatically maintains the proper engine temperature under normal conditions of operation. A positive centrifugal pump circulates the coolant through the engine block, engine heads and expansion tank.

NOTE: This system is not a pressurized system and is equipped with a vented filler cap.



Illust. 13
Cooling System Circulation.

When the coolant in the cooling system begins to get warm, the double acting Flo-matic valves direct coolant from the engine through the expansion tank and back to the engine. (Solid line).

As the coolant temperature rises, the valves function in unison. One valve starts to open and the other valve starts to close to permit the flow of greater amounts of coolant through the heat exchanger. (Dotted line).

After the engine warm-up, the Flo-matic control maintains coolant temperature automatically by modulating flow to the heat exchanger circuit while sustaining a full flow through the engine cooling system.

#### Care of the Cooling System

To keep the cooling system free of rust and sludge during warm weather operation, add a cooling system conditioner that is compatible with aluminum. Instructions for its use are printed on each container.

#### Radiator Cap

A regulating pressure valve, built into the radiator cap, is designed to open at a pressure of approximately 6-1/2 to 8 pounds per square inch.

#### REMOVAL

CAUTION: THE PRESSURE TYPE
CAP IS PROVIDED WITH A SAFETY
STOP TO ALLOW THE PRESSURE
OR ANY STEAM TO ESCAPE WHILE THE
CAP IS BEING REMOVED, SHOULD THE
ENGINE RUN VERY HOT.

Turn the cap to the left (counterclockwise) to the safety stop until pressure is released; then press down on the cap and continue to turn until the cap is free to be removed.


NOTE: Do not attempt to repair or replace any of the regulating valve parts. If the valve is faulty, replace it with a new radiator cap of the same type.

#### Draining the Cooling System

Drain the cooling system immediately after stopping the engine while most of the sediment is in suspension.

## Radiator Type

- Remove the radiator cap.
- 2. Open the radiator drain valve (Illust. 14) and the crankcase drain valve (Illust. 15).



iliust. 14 Radiator Drain Vaive.

- 3. LIQUEFIED PETROLEUM GAS ENGINES: Open the water drain valve (2) (refer to Illust. 38).
- 4. Allow the system to drain completely. Be sure that the drain valves do not plug up during the draining.
- 5. Close all of the drain outlets.



Illust. 15 Crankcase Drain Valve

#### Flo-matic Type

Drain the cooling system immediately after stopping the engine while most of the sediment is in suspension.

1. Remove the expansion tank cap.

- 2. Open the flo-matic vent valve (Illust. 17) and the crankcase drain valve (Illust. 15). Open the drain valve on the underside of the water outlet tube and the drain valves on the heat exchanger.
- 3. LIQUEFIED PETROLEUM GAS ENGINES: Open the water drain valve (2) (refer to Illust. 38).
- 4. Allow the system to drain completely. Be sure the drain valves do not plug up during the draining.
- Close all of the drain outlets.

## Cleaning the Cooling System

Drain and thoroughly flush the cooling system twice a year or more often if necessary. The appearance of rust in the radiator, expansion tank or in the coolant is an indication that the inhibitor has become weakened and it is possible that some sludge has accumulated in the system. When this condition exists, proceed as follows:

- 1. Run the engine until it reaches normal operating temperature; then stop the engine and drain the cooling system (refer to "Draining the Cooling System" on page 24).
- 2. Close the drains. Fill the cooling system with clean coolant (refer to "Filling the Cooling System" on this page).
- 3. Add a flushing compound, that is compatible with aluminum, to the cooling system in accordance with the instructions furnished with the compound.
- 4. Start the engine and flush the system as directed by the instructions furnished with the compound.
- 5. After the system has been flushed and thoroughly cleaned of the compound, refill with clean coolant (refer to "Filling the Cooling System" on this page).

## Cleaning the Radiator Care

Blow out insects and dirt from the radiator core air passages, using air or water under pressure. Engine overheating is often caused by bent or clogged radiator fins. When 25 straightening bent fins, be careful not to injure the tubes or to break the bond between the fins and tubes.

## Filling the Cooling System

## Radiator Type

- Close the drain valves.
- Pour coolant into the radiator slowly until partly full.
- 3. Add a cooling system corrosion inhibitor (for warm weather operation) or IH anti-freeze (when the air temperature is consistently at the freezing point (+32°F) and lower) according to instructions printed on each container.

NOTE: Use only a corrosion inhibitor that is compatible with aluminum. Do not use inhibitors labeled as "acid neutralizers."

- 4. Continue to fill the radiator until the coolant reaches a level approximately one inch below the filler neck. Wait a few minutes to allow any air to escape, then add coolant if needed.
- 5. Install the radiator cap. Start and run the engine until the operating temperature is reached. Stop the engine, remove the radiator cap and recheck the level. Add coolant, if needed, to fill to the required one inch level below the filler neck. Install the radiator cap.

#### Flo-motic Type

- Close the drain valves.
- 2. Pour or run coolant into the expansion tank slowly until partly full.
- 3. Add a cooling system corrosion inhibitor (for warm weather operation) or IH anti-freeze (when the air temperature is consistently at the freezing point (+32°F) and lower) according to instructions printed on each container.
- NOTE: Use only a corrosion inhibitor that is compatible with aluminum. Do not use inhibitors labeled as "acid neutralizers."
- 4. Continue to fill the expansion tank until the coolant reaches a level approximately one inch below the bottom of the filler neck.
- 5. Open the vent valve (Illust. 17) to permit the escape of air. Close the vent valve, then add coolant if needed.
- 6. Install the expansion tank cap. Start and run the engine until operating temperature is reached. Stop the engine, remove the expansion tank cap and recheck the level. Add coolant if needed, to fill the required one inch level below the filler neck. Install the expansion tank cap.



# Adding Coolant to an overheated Cooling System

Use caution when removing the radiator or expansion tank cap when adding coolant. Do not pour cold coolant into the radiator or the expansion tank if the engine is very hot, unless conditions make it absolutely necessary. In this case, start the engine and let idle; then slowly pour the coolant into the radiator or the expansion tank.

# Thermostat (Radiator Type Only)

The thermostat is the nonadjustable type and is incorporated in the cooling system for the purpose of retarding or restricting circulation of coolant to achieve rapid engine warm-up. The thermostat operating range is +167°F to +172°F.

NOTE: Permanent type anti-freeze must be used with this thermostat.

Engine overheating and loss of coolant is sometimes due to an inoperative thermostat. When this condition exists, remove and check the thermostat. Refer to "Removing and Checking the Thermostat" on this page.

#### Removing and Checking the Thermostat (Illust. 16)


- 1. Remove the hood sheets and hood side doors (if equipped).
- 2. Drain the cooling system to a point below the housing (1).
- 3. Remove the cap screw with lock washer (3). Loosen the cap screw (4) and move the brace (5) down and away from the housing (1).
- 4. Loosen the clamp and remove the radiator inlet hose from the housing (1).
- 5. Unscrew the two cap screws (2) and remove the housing (1).
- Remove the thermostat and housing gasket.
   Discard the gasket.
- 7. Clean the thermostat. If the thermostat is coated with scale, it must be replaced. Scale will not allow the thermostat to function correctly.
- 8. Check the thermostat for correct operation. This can be done by submerging the thermostat and a thermometer in water and heating the water. (Refer to "NOTE" below.) Check the temperature of the water when the thermostat starts to open (approximately +167°F) and the temperature of the water when it is fully open (approximately +192°F).

NOTE: When placing the thermostat and the thermometer in the water, be sure they do not touch the side or bottom of the container at any time.

9. If the thermostat does not function as stated above, it must be replaced with a new one. Refer to "Installing the Thermostat" which follows.

# Installing the Thermostat (Illust. 16)

- 1. Clean the housing gasket surface on the cylinder head to assure proper sealing when reassembled.
- 2. Apply sealer to the gasket surface thermostat housing.
- 3. Install the new gasket and thermostat (valve end up) onto the cylinder head.
- 4. Position and secure the housing (1) to the cylinder head with the two cap screws (2) and lock washers.
- 5. Install the radiator inlet hose on the housing (1) and tighten the hose clamp. Refer to "TORQUES" on page 5 for specific torques.
- 6. With the cap screw (3) and lock washer connect the brace (5) to the housing (1). Tighten the cap screws (3 and 4) finger-tight.
- 7. Adjust the fan belt tension. Refer to "BELT" on page 28.



Illust. 16 Checking the Thermostat.

- 1. HOUSING, thermostat.
- 2. SCREW, cap.
- 3. SCREW, cap.
- 4. SCREW, cap.
- 5. BRACE, generator adjusting.

- 8. Fill the cooling system. Refer to "Filling the Cooling System" on page 25.
- 9. Operate the engine for correct thermostat performance and observe all cooling system hoses and points of connections for leaks. Correct all leaks, no matter how minor.
- 10. Install the hood sheets and hood side doors.


#### Water Pump

The water pump housing is packed with grease at the factory and requires no attention other

than replacing the bearings when they show excessive looseness or if a water leak develops. which indicates that a damaged or badly worn seal needs replacement.

# Flo-matic Valve

No adjustment can be made to the Vernatherm unit to increase or decrease operating temperatures. The following adjustments establish only the proper relationship of the Vernatherm control unit and the butterfly valves to provide full opening and complete closing of the by-pass and heat exchanger circuit.



1Hust. 17
Flo-matic By-Pass Control Valve.

# Flo-matic Valve Adjustment (Illust. 17)


- Drain the cooling system. (Refer to "Flomatic Type" under "Draining the Cooling System" on page 24.)
- 2. Remove the by-pass and heat exchanger hoses.
- Remove Vernatherm return spring.
- The purpose of the two set screws (A and B) on lever (C) is to prevent butterfly valves from binding and must just make contact with the stop as the valves reach full open and full closed positions. Adjust if required.
- 5. Remove the pin (D) holding the Vernatherm control lever in (toward Vernatherm control unit). The pin (D) must fall in place without binding. The by-pass port valve must be in full open position and the heat exchanger port valve must be fully closed. If correction is required, proceed as follows:
  - Loosen the screw (E) on the lever (F).
  - b. Position the lever (F) as outlined in Step 5.
  - Tighten the screw (E) (40-45 inch pounds).
  - d. Operate the valve assembly by hand, being sure all linkage operates freely.
  - e. Install the Vernatherm control return spring.
  - Install the by-pass and heat exchanger hoses.
  - 7. Fill the cooling system. (Refer to "Flomatic Type" under "Filling the Cooling System" on page 25.

NOTE: If the above adjustments have been made and the satisfactory temperatures are not maintained, consult your authorized International Engine Distributor or Dealer.

#### BELT

# Belt Tension (Illust. 18)

The tension is correct when the belt can be depressed, by the thumb (approx. 25 lb-load), approximately 3/8 inch midway between the two pulleys. If the belt is too tight or too loose adjust the belt.




lilust. 18 Correct Belt Tension.

Adjustment (Illust. 19) Adjust the belt as follows:

- Loosen the brace bolts (A and B) and the mounting bolts (C).
- Move the generator away or toward the engine until the tension on the belt is 3/8 inch midway between the pulleys (Illust. 18).

NOTE: Under no circumstances should apry bar be used on the generator to obtain belt tension as damage to the bearings will re-

 Tighten the mounting bolts (C) and the brace bolts (A and B).



Blast, 19 Adjusting the Fan Belt.

1.35

#### MAINTENANCE

# Removing the Fan Belt (Illust. 19)

Replace the belt if it becomes soaked with grease or is so badly worn that the correct belt tension cannot be maintained.

- 1. Loosen the brace bolts (A and B) and mounting bolts (C).
- Move the generator in toward the engine.
- 3. Slip the old belt over the fan blades and remove it.

# Installing the Fan Belt

- Work the new belt over the fan blades and over top of the fan pulley.
- 2. Slide the belt over the crankshaft pulley.
- Push in on the generator, if necessary, and slide the belt over the generator pulley.
- 4. Adjust the belt tension. Refer to "Adjust-ment" on page 28.

# AIR CLEANER (WET TYPE)

## Precoutions

Frequently inspect the flexible rubber hoses between the carburetor and the air cleaner. If they show any sign of deterioration, replace them.


All the joints between the air cleaner and the carburetor and between the manifold and the cylinders of the engine must be tight. All the gaskets must be in good condition and the bolts must be drawn up tight.

# Cleaning the Oil Cup (Illust. 20)

- Clean or wipe the outer surface of the body before removing the oil cup.
- Loosen the wing nut assembled to the oil cup clamp and, with a downward movement, separate the cup from the body.
- 3. Pour out the old oil and thoroughly clean the inside of the oil cup with kerosine.
- 4. Fill the cup to the "OIL LEVEL" mark with the proper grade of oil. Refer to "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.
- 5. Lift the cup into place on the body. Place the clamp around the cup and the body. Tighten the wing nut assembly thumb tight.

# Washing the Air Cleaner (Illust. 20)

- Loosen the air pipe hose clamp and disconnect the hose from the air cleaner.
- 2. Loosen the wing nut assembled to the oil cup clamp, grasp the oil cup at the sides and with a downward movement, separate the oil cup from the air cleaner body.
- Empty the oil from the cup, then clean the cup in kerosine.



Illust. 20 Air Cleaner Disassembled.

- 4. Remove and clean the air intake cap. Refer to "Air Intake Cap" on page 32.
- 5. Loosen the nut on each mounting bracket and remove the body.
- 6. Wash the body in kerosine or diesel fuel. Be sure to clean out the air intake pipe.

# Installing the Air Cleaner Complete (Illust. 20)

- 1. Install the air cleaner body into the mounting brackets and tighten the nuts.
- 2. Fill the cup to the "OIL LEVEL" mark with the proper grade of oil. Refer to "LUBRICANT SPECIFICATIONS AND CAPACITIES CHART" on page 17.

- 3. Lift the cup into place on the body. Place the clamp around the cup and the body. Tighten the wing nut assembly thumb tight.
- Install the air intake cap.
- 5. Install and secure the air pipe hose to the air cleaner with the hose clamp.

## AIR CLEANER (DRY TYPE)

The air cleaner is the "dry-type" with replaceable filter element and automatic dust unloader features. The element may be cleaned several times before requiring replacement (additional information can be found in the following text).

#### Precautions

As an added precaution against dirt getting into the engine, frequently inspect the flexible pipe connection between the carburetor and the air cleaner. If it shows any sign of leakage, correct it.

To eliminate strain on the pipe connection, be sure the pipe lines up.

All the joints between the air cleaner and the carburetor and between the manifold and the cylinder of the engine must be tight. All the gaskets must be in good condition and the bolts must be drawn up tight.

Never operate the engine unless the filter element is in place in the air cleaner body and/or the dust unloader is in place.

Never remove the element from the air cleaner body while the engine is running.

#### Automatic Dust Unloader

The dust unlaoder (6, Illust. 21) automatically allows the accumulated dirt in the air cleaner body to drop out when the weight of the dirt overcomes the vacuum that keeps the unloader lips closed. At the interval specified under "SCHEDULED MAINTENANCE" on page 14. stop the engine and squeeze the dust unloader lips to be sure they are not blocked.


22 to 2500

· ## # 57

#### Filter Element Service

The element can be cleaned by either of two methods; washing or compressed air.

Washing is the preferred method as it removes more dust and soot and restores the element to an almost new condition. The result being better performance and longer intervals between required element service. It is suggested that a spare element be available for use while the serviced element is drying. This will reduce engine down-time to only a few minutes and will allow sufficient time to service the restricted element properly. (Refer to "Washing" on page 31.)



Illust. 21 Air Cleaner Components (Dry Type).

- 1. CAP, air intake.
- 2. BODY, air cleaner.
- 3. ELEMENT, air cleaner.
- 4. RETAINER, air cleaner element.
- 5. CLAMP, dust unloader.
- 6. UNLOADER, dust.



NOTE: A filter element must be replaced after six washings.

Cleaning the element with compressed air is not considered an entirely satisfactory method. Some dust will remain in the element causing more frequent servicing of the element. Use this method only as a temporary measure until sufficient time is available to clean the element by "Washing." (Refer to "Compressed Air" on this page.)

NOTE: After cleaning, if an element is to be stored for later use, place it in a plastic bag and store in an element shipping container to protect against dirt and damage.

# Removal and Cleaning (Illust. 21)

- 1. Stop the engine. Wipe off any accumulation of dust from the element removal end of the body (2). Be careful not to dislodge dust from the dirty element into the clean air side or outlet of the air cleaner. (Any dust accidentally dislodged into the outlet or clean air side must be cleaned up before installing an element.)
- 2. Loosen the element lock nut and remove the lement retainer (4). Remove the element (3).

NOTE: Inspect the "clean air side" of the element (3) and body (2) for unusual accumulation of dust. Dust accumulation on the "clean air side" of the element usually means a rupture in the paper and element must be discarded.

#### Woshing

NOTE: Never wash elements in fuel oil, gas or solvent. DO NOT OIL ELEMENTS. Do not attempt to take elements apart.

1. Before washing, tap the side or end of the element against the palm of your hand to remove loose dust.

NOTE: Do not tap the element against a hard surface; this will damage the element.

- 2. Wash the element in clean, warm water (+70°F to +100°F). A small amount of non-sudsing detergent added to the water will facilitate the removal of soot.
- 3. Rinse the element in clear water (if a hose is used, do not exceed 40 psi). Shake the element carefully to remove excess water.


NOTE: Do not use compressed air to speed the drying of the element; the air pressure will rupture the wet element. 4. Lay the element on its side and allow it to air dry before reinstalling. Overnight drying is usually sufficient. When drying the element protect it from dirt and/or freezing.

NOTE: If no spare element is available, the wet element, after excess water has been shaken out, may be installed in the air cleaner and the engine operated at low idle for 10 minutes before operating.

 Inspect for damage. Refer to "Inspection" on page 32.

# Compressed Air

An element cleaning tool (IH Part No. 407 073 Rl, Illust. 22) for use with compressed air, is available from your authorized International Construction Equipment distributor or dealer, and will do a faster and more efficient job of removing dust than a regular air gun or nozzle.



Illust. 22
Using Element Cleaning Tool.

NOTE: Do not tap the element against a hard surface; this will damage the element.

- 1. Carefully tap side or end of the element against the paim of your hand to remove loose dust.
- 2. Direct clean, dry compressed air up and down the pleats on the "CLEAN SIDE" of the element. Always direct the compressed air opposite the normal operating air flow through the element.

NOTE: Air pressure at the nozzle must not exceed 100 psi. Keep a reasonable distance between the air nozzle and the element.

3. Inspect the element for damage. Refer to "Inspection" as outlined in the following test.

- 42-4

# MAINTENANCE

#### Inspection

- l. Inspect the filter element for leaks or damage by placing a bright light inside the element. Inspection of the element on the outside will disclose any holes where concentrated light shines through. The slightest rupture requires replacement of the filter element.
- Inspect the contact surfaces of the element and the air cleaner body. If faulty or damaged gasket or surfaces are noted, correct these conditions immediately.
- 3. Remove all dirt from the inside of the air cleaner body with a damp cloth. A small amount of non-sudsing detergent added to the water will remove the soot.
- 4. Check the condition of the dust unloader (6, Illust. 21). If found faulty or damaged, replace it.

#### Installation (lilust. 21)

1. Install the open end of the element (3) into the body (2). Install the element retainer (4) and tighten the thumb screw in the retainer so that the element is air-tight.

NOTE: Under no circumstances, should the engine be operated without the element in the air cleaner and the dust unloader in place.

- 2. Clean the air intake cap screen. Refer to "AIR INTAKE CAP" on this page.
- 3. After the element has been installed, but before resuming operation, inspect and tighten all air cleaner and air induction system connections.

## AIR INTAKE CAP (Illust, 20 or 21)

Keep the air intake cap screen clean and free of all restrictions. A twist and an upward pull will remove the cap. Use compressed air to clean the screen. If compressed air is not available, wash in clean hot water or preferably water containing a small amount of non-sudsing detergent.

## CRANKCASE BREATHER


The crankcase breather elements are located in the push rod chamber cover on the left hand side of the crankcase. Normally, the elements need to be cleaned only at the time of a major engine overhaul. However, it may become necessary to clean the elements more frequently when the engine is operating under severe conditions, such as extreme dust or excessively heavy loads.

To clean the elements, remove the push rod chamber cover from the engine. Wash the cover and elements in kerosine or diesel fuel oil; then dry thoroughly. Check the breather pipe to be sure it is not plugged or restricted. Reinstall the elements, the push rod chamber cover and the breather pipe, using a new breather pipe gasket.

# LUBRICATING OIL FILTER

# Changing the Filter Element (Illust. 23)

1. Drain the oil immediatly after stopping the engine, when complete circulation has been established and while most of the sediment is in suspension.



illust. 23
Exploded View of Oil Filter.

- 1. TUBE, center.
- 2. GASKET, center tube.
- 3. CASE, oil filter.
- 4. SPRING, element hold-down.
- GROMMET.
- RETAINER ASSEMBLY, element.
- 7. ELEMENT.
- 8. GASKET, oil filter
- 9. BASE, oil filter.
- 10. PLUG. drain.



- Remove both the crankcase oil pan drain plug and filter base drain plug (10). Allow the system to drain completely. Install the crankcase oil pan drain plug.
- 3. Clean the outside of the filter case (3) to prevent dirt from dropping into the base (9).
- 4. Unscrew the center tube (1).
- 5. Lift up and remove the center tube (1) and case (3).
- 6. Remove the old element (7).
- Wipe out the base (9) and case (3) with a cloth dampened with kerosine.
- 8. Install the new element (7) as follows:
  - a. Install the drain plug (10) in the filter base (9).
  - b. Install the new filter element (7).
  - Inspect the center tube (1) and make sure it is clean. Remove any dirt in the threaded center of the base.
  - d. Check that the case gasket (8) and center tube gasket (2) are in good condition. Replace with new ones if necessary. Refer to "Installing New Center Tube Gasker" on this
- 9. Fill the crankcase oil pan with new oil as instructed under the "LUBRICATION GUIDE" on pages 17 and 18.

# Installing New Center Tube Gosket (Illust. 23)

1. Reach up inside the filter case (3) and remove the element retainer assembly (6) from the center tube (1).

- 2. Remove the center tube (1) from the case (3) and replace the gasket (2) with a new one.
- Install the center tube (1) into the case (3).
- Slide the element retainer assembly (6) onto the center tube (1) and push it up into the case (3).

NOTE: The rubber grommet (5) in the element retainer assembly (6) serves as an oil seal. The grommet must be in place in the retainer assembly and in good condition. Replace it with a new one if necessary.

5. Install the new element (7), center tube (1) and case (3) onto the base (9). Carefully screw the center tube into the base and tighten securely (refer to "Torques" on page 5).

# HAND CRANKING

The starting crank is used for timing, adjustments and for starting the engine.



CAUTION: WHEN HAND CRANKING THE ENGINE FOR ADJUSTMENT PURPOSES, DISCONNECT THE COIL-TO-DISTRIBUTOR CABLE (A, ILLUST. 30) FROM THE COIL TO PREVENT AC-CIDENTAL STARTING OF THE ENGINE.

When starting the engine, crank with quick, upward, half strokes until the engine starts.



CAUTION: THE OPERATOR MUST STAND IN A POSITION THAT WILL ELIMINATE ANY POSSIBILITY OF BEING STRUCK BY THE STARTING CRANK IF THERE IS A REVERSAL IN THE DIREC-TION OF ENGINE ROTATION. DO NOT "SPIN" THE CRANK.



# VALVE CLEARANCE ADJUSTMENT

The numbers in Illust. 24 are cylinder numbers. The exhaust valves are identified by the letter (E), and the intake valves by the letter (I). For valve clearance dimensions (lash), refer to "Specifications" on page 5. BE ACCURATE - USE A FEELER GAUGE WHEN ADJUSTING VALVE CLEARANCE.

# NOTE: DO NOT ADJUST VALVES WITH THE ENGINE RUNNING.

- 1. Disconnect the coil-to-distributor cable.
- 2. Remove the valve cover.
- 3.. Turn crankshaft clockwise (viewed from front) until No. 1 piston is on the compression stroke and the timing pointer on the crankcase front cover aligns with the "TC" mark on the fan drive pulley.

NOTE: Be sure the No. 1 piston is on the compression stroke by turning both push rods by hand. The valves are closed when the push rods are loose and can be turned easily.

- 4. Adjust the cylinder Nos. 1, 2 and 4 intake (I) valves, and the Nos. 1, 3 and 5 exhaust (E) valves. Refer to Illust. 24 and 25. Turn the adjusting screw in or out to get correct clearance; then tighten lock nut. Adjust and lock each valve before proceeding to the next.
- 5. Turn the crankshaft one complete revolution, and again align the "TC" mark with the timing pointer.
- Adjust the cylinder Nos. 3, 5 and 6 intake
   valves, and the Nos. 2, 4 and 6 exhaust
- (E) valves.
- 7. Install the gasket and valve cover. The gasket must provide an oil-tight seal.
- 8. Connect the coil-to-distributor cable.




illust. 25
Adjusting the Valve Clearance.

# OIL LEVEL SIGHT GAUGE (Illust. 24)

To set the oil level sight gauge after changing the crankcase oil, proceed as follows:

- 1. Operate the engine until it is thoroughly warmed up.
- Pull the governor control knob out until the normal operating engine rpm is reached.
- 3. Slide the marker on the level sight gauge up or down so that it is even with the level of the oil in the gauge.



NOTE: To insure an accurate oil level sight gauge reading, the balance line connections and gauge fittings must be kept tight. An air leak, particularly at the upper side of the level gauge column or the balance line fittings, will result in a false level sight reading. Tighten all fittings periodically.

To check for possible air leaks, remove the oil filler cap and note the reaction of the oil column in the level sight gauge will change considerable. If the oil column falls more than 1/8 to 1/4 inch maximum, an air leak exists. Oil trapped in the balance line will also result in incorrect readings.

When there is no trapped oil in the balance line and no leak exists above the oil column, there is only a slight change, if any, in the oil column with the oil filler cap on or off.

# ELECTRICAL SYSTEM

#### Precautions




CAUTION: BEFORE WORKING ON ANY PART OF THE ELECTRICAL SYSTEM, DISCONNECT THE BAT-TERY GROUND CABLE UNTIL ALI. ELEC-TEICAL WORK HAS BEEN COMPLETED.

Repair or replace all broken wires immediately. All terminals must be clean and securely fastened; never paint connections.

BE CERTAIN the ground polarity is correct when:

- Installing a new battery.
- Connecting a battery charger.
- Using a booster.



Illust. 26 Oil Level Sight Gauge.

NEVER use a fast charger as a booster to start the engine.

NEVER unhook a battery terminal while the engine is running.

The generator can be operated for short periods on an open circuit if the "F" terminal wire on the generator frame is disconnected. When reconnecting this wire, the generator must be polarized.

# Regulator

-The regulator is adjusted and sealed by the manufacturer. If the regulator fails to operate properly, consult your authorized International Engine Distributor or Dealer.

#### Generator


If the generator fails to operate properly, consult your authorized International Engine distributor or dealer.

Lubricate the generator at the interval shown on the "LUBRICATION GUIDE" on page 18.

#### Polarizing the Generator

If the generator or the regulator has been removed or the wires disconnected, polarize the generator. After the wires have been reconnected, but before the engine is started, proceed as follows: Place one end of the jumper wire (A) on the "BAT" terminal of the regulator and, with the other end, wipe across (flash) the "GEN" terminal of the regulator (Illust 27).

NOTE: Never place a jumper wire (A) between the "BAT" terminal and the "F" terminal on the regulator.



Illust. 27
Polarizing the Generator.

#### Cranking Motor

If the cranking motor fails to operate properly, consult your authorized International Engine distributor or dealer.

Lubricate the cranking motor at the interval shown on the "LUBRICATION GUIDE" on page 18.

#### Ignition Cail

The ignition coil does not require special service other than to keep all terminals and connections clean and tight.

#### Spark Plugs

For the recommended spark plugs, consult your authorized International Engine Distributor or Dealer.

USE ONLY A COMPLETE SET OF THE SAME TYPE OF SPARK PLUGS.

NOTE: Before removing a spark plug from the cylinder head, remove all dirt around the base of the plug.

Use a spark plug wrench to remove the plugs. After the plugs have been removed, remove each spark plug gasket. Do not re-use these gaskets.

If the plugs are greasy or oily when removed, wash them with a petroleum solvent and dry them thoroughly. After drying the plugs, hard deposits can best be removed with an abrasive or by the use of a sand-blasting machine. DO NOT USE A WIRE BRUSH; wire brushing the spark plug electrodes will simply load the firing bore with electrically conductive metal particles from the brush and can cause misfiring when the plugs are reinstalled.


When cleaning spark plugs with a conventional sand-blasting machine, THE PLUG SHOULD NOT BE EXPOSED TO THE SAND BLAST FOR MORE THAN THREE OR FOUR SECONDS. If longer exposure is needed to clean the plug, the insulator will be damaged, rendering the plug either inoperative or very undependable. Use compressed air to remove any sand from inside the plug shell. Before setting the gap on a used plug, file the center electrode until it is flat.

If the center electrode is shorter than the shell skirt before or after filing or if the procelain is chipped, scratched or broken, replace the plug.

When adjusting the spark plug gap, bend the outer electrode only. Never bend the center electrode as this will damage the insulator. If the gap between the electrodes is too great



(refer to "Specifications" on page 5) due to improper setting or burning off the ends, the engine will misfire and will be hard to start.



11lust. 28 Checking Spark Plug Gap.

# Ignition Requirements When Using Natural Gas

Ignition requirements are greatly increased on engine using straight natural gas as fuel. Because of the dry nature of the fuel, spark plugs run hotter and have a tendency to burn more rapidly. If missing or pre-ignition occurs when the engine is operating at low speeds and with heavy loads, reset the spark plug gap, as shown in "Specifications" on page 5. Inspect spark plugs regularly and maintain this gap setting.

# Spark Plug Cables

If the spark plug cables are removed for any reason, note the position of each cable on the distributor (Illust. 30).

A minimum clearance of 1/4 inch between the spark plug cables and the cylinder head is recommended. By maintaining this clearance, shorting out the spark plugs will be prevented and the cable will be away from the heat of the cylinder head. If the cable touches the cylinder head, the heat will soon cause the rubber to become soft and will ruin the cable.

#### Storage Battery

Complete instructions for dry-charged batteries are included with the battery.



CAUTION: BATTERIES GIVE OFF HIGHLY INFLAMMABLE GAS. NEVER ALLOW SPARKS OR OPEN FLAME

NEAR THE BATTERIES. AVOID SPILLING ANY ELECTROLYTE ON HANDS OR CLOTHING.

# Battery Installation

Never allow the battery to stand on the concrete, ground or a metal support unless proper insulation is provided. A wooden platform or board is sufficient insulation. Be sure the battery is fastened securely to avoid damage from vibration.

NOTE: If tightened excessively, the battery case could warp or break.

# Cleaning and Servicing the Battery

If the top of the battery is dirty, it may be cleaned with a brush dipped in ammonia or soda solution. The vent plugs must be tightened to prevent any solution from getting into the battery cells. After the foaming stops, flush off the battery with clean water. Brighten the terminal contact surfaces with steel wool or a stiff brush.

Battery cable terminals must be kept clean and tight.

Check that the vent holes in the filler caps are not clogged. Replace unserviceable cables.

#### Liquid Level

The electrolyte in each cell should be above the plates at all times to prevent battery failure. Check the level of the electrolyte. When the electrolyte is below this level, pure distilled water should be added. Never use hydrant water or any water which has been in a metal container. Acid or electrolyte should never be added except by a skilled batteryman. Under no circumstances add any special battery "dopes." solutions or powders.

It is especially important to keep the battery at full charge for cold weather operation. Add distilled water to the battery in freezing temperatures only when the engine is to operate for several hours to thoroughly mix the water and the electrolyte, or damage to the battery will result from the water freezing.

#### Distributor

#### Distributor Cop

Remove the distributor cap and examine the inside. If any dust, moisture, or oil deposits are present, thoroughly clean and wipe dry. To assure long life of the distributor, care must be


taken to keep the ventilator flats, at the inside edge of the distributor cap, open at all times. Keep the distributor rotor clean.

If the terminal nipples are removed, be sure the distributor cap terminals and coil terminal are clean and dry. The distributor is equipped with these nipples to prevent any external electrical leakage when the engine is operating under adverse conditions.

# Checking the Breaker Chamber and Breaker Points

It is important that the breaker chamber be kept clean because oil on the breaker points will cause rapid burning. Remove the distributor cap, distributor rotor, and the breaker cover for breaker chamber inspection. Care must be taken, when removing the breaker cover, to prevent dirt from entering the breaker chamber. Be sure the chamber is clean and the breaker points are in good condition and have the proper opening.

Check the condition of the breaker points for build-up or lip formation. If present, the points must be dressed before the point opening can be checked or set. NEVER USE EMERY CLOTH OR SANDPAPER TO CLEAN THE POINTS. 1F THE POINTS ARE WORN EXCESSIVELY, RE-PLACE BOTH POINTS. Check the opening between the breaker points with a feeler gauge when the rubbing block is on the high part of the cam. (Illust. 29.) (Refer to "Specifications" on page 5.) If the gap is not correct, adjust it by loosening the screw holding the adjustable point. Move the point toward or away from the breaker arm until the gauge slips snugly into the opening. After the adjustment has been made, tighten the screw.



Illust. 29
Adjusting Breaker Points.

Install the distributor cap to the housing with the tang in the cap in line with the slot in the distributor housing.

NOTE: If the cap is incorrectly positioned on the housing, it will usually result in a broken rotor when attempting to start the engine.


# Ignition Timing

1. Be sure that the distributor cap is properly located on the distributor housing and that both bail clips are in place.


NOTE: If the distributor cap is incorrectly positioned on the distributor housing usually result in a broken rotor when tempting to start the engine.

The firing order is 1, 5, 3, 6, 2, 4 (Illust: 30) and the spark plug cables must be assembled in the distributor cap in this order in a counterclockwise rotation.

#### Continued on page 41.




Spark Plug Wiring,




Illust. 31 Timing Pointer and Timing Marks on the Fan Drive Pulley.





Illust. 32 Wiring Diagram for Engines Equipped with Regular Gauges.

<del></del>	Description	No.	Description
1. l	AMMETER.	19.	CABLE, "G" on regulator to "A" on
2.			generator (yellow).
1	solenoid (red).	20.	GENERATOR.
3.	CABLE, "R" on solenoid to resistor	21.	
	(pink).	22	generator. REGULATOR, voltage.
4.	CABLE, "S" on solenoid to "SOL" on	11	l
	ignition and starter switch (light green).	23.	- "
5.	SOLENOID.	24.	
6. ]	CONNECTOR, cranking motor to "M"	25.	
_	on solenoid.	20.	ignition and starter switch.
7.	MOTOR, cranking.	37	HOURMETER, electric.
8.		21.	CABLE, hourmeter to ground.
9.	BATTERY.	20.	PUMP, electric fuel.
10.		11	
11.	DISTRIBUTOR.	30.	and starter switch.
12.	CABLE, minus (-) on coil to distributor		HARNESS, cranking motor cable
	(red).	}	(consists of Ref. No's, 2 and 4).
	RESISTOR, ignition coil.		HARNESS, ignition cable
14.			(consists of Ref. No's. 3 and 14).
1	and starter switch (orange).		• • • •
15.		1	HARNESS, regulator cable
16.	··· · · · · · · · · · · ·	1	(consists of Ref. No's. 17 and 18).
	(red).		HARNESS, generator to regulator
17.	CABLE, "B" on regulator to minus (-)	1	(consists of Ref. No's, 19 and 21).
}	on ammeter (violet).	1	
18.	CABLE, "L" on regulator to "BAT" on ignition and starter switch (grey).		



Illust. 33 Wiring Diagram for Engines Equipped with Safety Gauges.

Ref. No.		Ref.	
	Description	No.	Description
1. INI	DICATOR, safety oil pressure.	21.	CABLE, "F" on regulator to "F" on
2.   BL 3.   CA	OCK, junction. ABLE, "B" on regulator to minus (-)	22.	generator.  CABLE, "G" on regulator to "A" on generator (yellow).
	n ammeter (violet).	23.	REGIII.A TOR, voltage.
5. CA	METER.  ABLE, plug (+) on ammeter to "B" on colenoid (red).	24.	CABLE, "L" on regulator to "BAT" on ignition and starter switch (grey).
6. CA	ABLE. "R" on solenoid to resistor		PANEL, instrument.
	pink).	26.	SWITCH, ignition and starter.
7. CA	BLE, "S" on solenoid to "SOL" on	27.	CABLE, "BAT" on relay to "IGN" on
🗓	gnition and starter switch (light		ignition and starter switch.
	reen).	28.	
8.   ငင်	ONNECTOR, cranking motor to "M"	29.	
0.   0.	on solenoid.	30.	NOT USED.
	LENOID.	31.	RELAY, automatic shut-off.
	OTOR, cranking.	32,	CABLE, safety control toggle switch to
11. CA	ABLE, cranking motor to battery.		"SWITCH" on relay.
12. BA	ATTERY.	33.	INDICATOR, safety heat.
	ABLE, battery to ground.	34.	CABLE, Heat indicator to junction
14 DT	STRIBUTOR.	11	block.
15. CA	ABLE, minus (-) on coil to distributor (red).	35.	CABLE, safety control to toggle switch to junction block.
	ESISTOR, ignition coil.	36.	CABLE, safety oil pressure indicator
17. CA	ABLE, resistor to "COIL/MAG" on	11	to junction block.
11.	relay (orange).	37.	SWITCH, safety control toggle.
	OIL.	38.	CABLE, hourmeter connector cable to
19. C	ABLE, plus (+) on coil to resistor (red).		"ACC" on ignition and starter
20. G	ENERATOR.		switch.

Rei.	Description	Rei. No.	Description
39. 40.	CABLE, fuel pump to "ACC" on ignition and starter switch.  PUMP, electric fuel.  CABLE, hourmeter connector.  HOURMETER, electric.  CABLE, hourmeter connector.  CABLE, hourmeter connector cable to ground screw.  CABLE, power take-off temperature switch to junction block.	46.	SWITCH, power take-off clutch shaft outer bearing housing temperature.  HARNESS, generator to regulator (consists of Ref. No's. 21 and 22).  HARNESS, cranking motor cable (consists of Ref. No's. 5 and 7).  HARNESS, ignition cable (consists of Ref. No's. 6 and 17).  HARNESS, regulator cable (consists of Ref. No's. 3 and 24).

-2. Connect a timing light to the No. 1 spark plug.

NOTE: Follow the manufacturer's instructions on the use of the timing light.

- 3. Slowly crank the engine until the "TC" or "DC" on the fan drive pulley is in line with the pointer on the crankcase front cover (Illust. 31). White chalk or paint will highlight the timing mark for easier recognition.
- 4. Start the engine and check the timing light operation.
- Rotate the throttle stop screw on the carburetor to reduce the idle speed of the engine to approximately 500 rpm for timing purposes.
- 6. Direct the light to the timing location on the fan drive pulley. Each light flash should be fast and accurate, and the timing marks should be readily seen.
- 7. Loosen the manual advance arm locking plate bolt on the distributor housing. Rotate the distributor housing until the timing mark is in alignment with the pointer (when the timing light flashes).
- 8. Tighten the manual advance arm locking plate bolt. Recheck to be certain that tightening the bolt did not disturb the timing setting.
- 9. Advance the governor control knob to the high idle position. At high idle, the timing light should flash on when the timing pointer and the 30 degree advance mark are in alignment.
- 10. Stop the engine. Disconnect the timing light.

#### FUEL SYSTEM (GASOLINE)

#### General

When excessive fuel consumption or inefficient engine performance is encountered, be careful in determining the exact cause before assuming the carburetor to be at fault. Consider engine compression, ignition timing, defective


wiring, improperly gapped or fouled plugs, fuel pump. These are all factors in obtaining maximum fuel economy and must be within the limits specified by the manufacturer.

Due to the technical knowledge and skill required and the special equipment needed to make the necessary tests and corrections, we recommend the work be done by your authorized International Engine Distributor or Dealer.

Use clean fuel. The presence of dirt and water will disturb the functioning of the carburetor.

## Carburetor

At the interval shown under "SCHEDULED MAINTENANCE" on page 14, disconnect the fuel supply lines at the carburetor and unscrew the fuel line fitting from the carburetor (Illust. 34). Clean the screen and reinstallit. Reconnect the fuel supply line.



Illust. 34
Removing the Fuel Line Screen.

The flange nuts which hold the carburetor to the intake manifold must be checked periodically for tightness.

Occasionally check the cover screws which fasten the fuel bowl to the fuel bowl cover. They should be kept tight to avoid any air leakage past the fuel bowl cover gasket.

#### Corburator Adjustments

NOTE: The manifold is equipped with a heat control valve controlled by a spring thermostat. No adjustment is required but be sure the valve opens freely by moving the heat control weight back and forth. (Illust. 34.)

The engine and carburetor are correctly set when shipped from the factory. If this setting has been disturbed for any reason, proceed as follows:

Start the engine and allow it to operate until thoroughly warm before making any adjustments.

#### Adjusting the idle adjusting screw (Illust, 35)


Close the idle adjusting screw to its seat by turning to the right (or in); then open one turn. Operate the engine at fast idling speed (without any load) until thoroughly warm.

While the engine is running at fast idle speed, it is advisable to screw in the throttle stop screw a few turns to prevent the engine from stopping when the throttle is closed. Now close the throttle by pushing the engine speed control knob all the way in. The engine will then be idling at a fairly high speed and the throttle stop screw can be backed out a little at a time until the desired idle speed is obtained. If the engine misses or rolls while backing out the throttle stop screw, the idle adjusting screw may be adjusted either in or out until the engine operates smoothly.

NOTE: Turning the adjusting screw in makes the idle mixture leaner. Speed up the engine for a few seconds; then recheck the idle adjustment. A slight adjustment in or out will give the smoothest idle.

#### Main fuel adjustment (Illust. 35)

The carburetor is equipped with a main fuel adjustment screw which can be used to reduce the amount of fuel going into the engine when under light load conditions. However, when heavy work is to be performed in which the FULL POWER of the engine IS REQUIRED, the fuel adjusting screw should be set five turns off its seat. The



Illust. 35
Gasoline Carburetor.

fuel adjusting screw seat in the gasoline carburetor has been calibrated to provide a fullpower misture and should not be restricted by the use of the adjusting needle when the full power of the engine is required.

After adjusting the main fuel adjustment on the carburetor, recheck the idling speed as described under "Adjusting the Idle Adjusting Screw." If the engine is not receiving the correct mixture of fuel, it may be that the main jet adjusting screw has loosened. If necessary tighten the adjusting screw packing nut securely.

#### Fuel Pump and Filter

The fuel pump and filter are an integral unit. The sediment bowl and filter element are provided to prevent the entry of foreign materials into the carburetor and, thus, cause engine failure.


Do not attempt to disassemble the fuel pump diaphragm. If a sufficient amount of fuel is not being delivered to the carburetor, make a careful check for the cause. Usually the cause will be from such sources as bent, leaky or clogged fuel lines, loose fuel bowl, dirty ceramic filter or fuel bowl. If servicing these parts does not correct the problem, consult your authorized International Engine Distributor or Dealer.



# Cleaning the Fuel Pump Filter (Illust. 36)

Disassemble and clean the filter as follows:

- Loosen the screw (5) at the bottom of the bowl (6) to relieve the tension on the retainer(3).
- Remove the bowl (6) from the filter head (1). Remove the filter (2) and the spring (4) from the bowl. Separate the spring from the filter. The old filter should not be re-used. Dump out the gasoline in the bowl.
- 3. Remove the bowl gasket from the filter head. This gasket should not be re-used.
- Wash the bowl (6) and the spring (4) in a commercial carburetor cleaning solvent.
- Thoroughly dry these parts using compressed air.
- 6. Install the spring (4) in the bowl. Install a new ceramic filter (2) so the spring fits in the recess in the bottom of the filter.
- Place a new bowl gasket in the filter head (1). Position the bowl (6) to the filter head. Be sure the bowl and the gasket make an air-tight eal at the filter head. Tighten the retainer crew (5) finger-tight.



Illust. 36 Fuel Pump and Filter.

- 1. HEAD, filter.
- 2. FILTER.
- 3. RETAINER, bowl (with screw).
- 4. SPRING, filter.
- SCREW (part of retainer).
- 6. BOWL.


# Fuel Pump (Electric)

Engines operating on gasoline and equipped with a hydraulic pump have an electric fuel pump bracket mounted on the right hand front cover of the engine.

The electric fuel pump operates immediately when the ignition switch is turned to the right to the "ON" position.

# Cleaning the Filter Screen (Illust. 37)

Using a wrench on the hex head underneath the cover (14), rotate and release the cover from the body (1).



Electric Fuel Pump Components.

- 1. BODY, pump.
- Z. NUT.
- 3. TUBE, pump to carburetor
- 4. ELBOW.
- 5. CLIP.
- 6. CABLE.
- 7. PLUNGER, pump.
- 8. SPRING, plunger.
- 9. GASKET, spring cup.
- 10. CUP, plunger.
- 11. SCREW.
- 12. SCREEN, filter.
- 13. GASKET, cover.
- 14. COVER.
- 15. BRACKET, mounting.

- Remove the gasket (13) from the body. If this gasket has taken a "set" or if it has become brittle or cracked, replace it with a new gasket.
- Carefully remove the screen (12) from the cup (10). If the screen is damaged, replace it with a new screen. If the screen is not damaged, clean the screen by using compressed air or by washing in a commercial solvent or clean kerosine.
- 4. Use compressed air to thoroughly clean the magnet on the inside of the cover (14).
- 5. Install the gasket (13) in place on the inside of the cover (14). Center the screen (12) over the magnet on the inside of the cover. Install the cover on the pump body (1), being sure the inside diameter of the screen (12) does not bind on the outside diameter of the plunger cup (10).
- 6. Apply a 5/8 inch wrench on the cover hex head. Turn the cover (14) until the bayonet fittings on the body (1) are fully engaged in the cover slots.

# FUEL SYSTEM (LIQUEFIED PETROLEUM GAS)

#### General

When excessive fuel consumption or inefficient engine performance is encountered, be careful in determining the exact cause before assuming the carburetor to be at fault. Consider engine compression, ignition timing, defective wiring, imporperly gapped or fouled plugs, distributor contact points, condenser, coil and fuel filter. These are all factors in obtaining maximum fuel economy and must be within the limits specified by the manufacturer.

Due to the technical knowledge and skill required and the special equipment needed to make the necessary tests and corrections, we recommend that the work be done by your authorized International Engine Distributor or Dealer.

# Carburetor and Regulator

The regulator controls the flow of fuel to the carburetor.

The carburetor is used to mix accurately the correct proportion of fuel with air to satisfy the speed and load demand of the engine.


There are three fuel adjustments. adjustments were correctly set at the factory and should require no alteration. However, if these adjustments have been disturbed in some manner, they can be correctly reset by the following instructions.

# Adjusting the Carburetor and Regulator (Illust. 38)

- With the engine stopped, open the supply valve from the fuel supply tank.
- Open the adjusting screw(1) on the regulator (7) 1-1/2 turns.
- Open the screw (3) on the carburetor (6) four turns.
- Open the screw (4) 1-1/4 turns.

NOTE: All three screws (1, 3 and 4) provide a leaner fuel mixture when turned in (clockwise) and a richer fuel mixture when turned out (counterclockwise).

- 5. Set the engine throttle control about open.
- Close the choke valve and start the engine.
- When the engine starts; leave the choke closed and the throttle as set; then adjust the screw (4) for the highest rpm and lock the screw in position.



illust. 38 Engine Equipped to Use Liquefied Petroleum Gas.


- 1. SCREW, idle adjusting.
- VALVE, water drain.
   SCREW. load adjusting.
- 4. SCREW, starting adjusting.
- 5. FILTER, fuel.
- CARBURETOR.
- REGULATOR, fuel.

- Open the choke valve, reduce the engine speed to idle and adjust the screw (1) for best idle operation. If the engine fails to respond when changing from starting to running position, open or close the screw (3) until the condition is overcome.
- With the choke valve open and the engine throttle set to just under governed speed, adjust as follows:

Turn the screw (3) in (clockwise) until the engine loses speed; then out (counterclockwise) approximately 1/4 turn. These adjustments should give the approximate best performance and minimum gas consumption.

10. Adjust the screw (1) to give the best idle after the engine is warmed up and readjust throttle for the proper idle speed.

Fuel Filter (Illust. 39)



Illust. 39 Fuel Filter (Liquefied Petroleum Gos).

- 1. TOP, filter.
- 2. GASKET, filter top.
- 4. ELEMENT, filter.
- 5. BOWL, filter.
- GASKET, filter bowl.
- 8. BOLT, filter bowl.



CAUTION: THE PRECAUTIONS OUT-LINED ON PAGES 10 AND 11 MUST BE CLOSELY FOLLOWED TO AVOID INJURY AND DAMAGE WHEN CHANGING THE FUEL FILTER.

The fuel filter element must be changed when it becomes clogged sufficiently to restrict the flow of fuel. A clogged filter element causes a pressure drop within the filter with consequent vaporization of the fuel which may cause freezing at the filter and engine starvation for fuel. Remove the filter as follows:

- Close the valve on the supply line.
- Hold the bowl (5) and unscrew the bolt (8).
- Lower and remove the bowl (5) from the top (1). Remove and discard the old element (4).
- 4. Wipe out the bowl (5) with a cloth dampened in kerosine. Thoroughly clean the bolt (8) to remove any restrictions in the drilled passages.
- Check the condition of the gasket (2). If there are any signs of wear or damage; replace it.
- Install the gasket (2) in the top (1). Place the new element (4) in the bowl (5).
- Secure the bowl (5) to the top (1) with the bolt (8) and gasket (6). Tighten the bolt.

# FUEL SYSTEM (NATURAL GAS)

#### General

When excessive fuel consumption or inefficient engine performance is encountered, be careful in determining the exact cause before assuming the carburetor to be at fault. Consider engine compression, ignition timing, defective wiring, improperly gapped or fouled plugs, distributor contact points, condenser, coil and fuel pump. These are all factors in obtaining maximum fuel economy and must be within the limits specified by the manufacturer.

Due to the technical knowledge and skill required and the special equipment needed to make the necessary tests and corrections, we recommend that the work be done by your authorized International Engine Distributor or Dealer.

# Carburetor and Regulator

The regulator controls the flow of fuel to the carburetor.


The carburetor is used to mix accurately the correct proportion of fuel with air to satisfy the speed and load demand of the engine.

There are three fuel adjustments. These adjustments were correctly set at the factory and should require no alteration. However, if these adjustments have been disturbed in some manner, they can be correctly reset by the following instructions.

# Adjusting the Carburetor and Regulator (11lust. 40)

- With the engine stopped, open the supply valve from the fuel supply tank.
- Open the adjusting screw(1) on the regulator (7) 2 turns.
- Open the screw (3) on the carburetor (6)
   1-1/2 turns.
- 4. Open the screw (4) 1-1/2 turns.

NOTE: All three screws (1, 3 and 4) provide a leaner fuel mixture when turned in (clockwise) and a richer fuel mixture when turned out (counterclockwise).



illust. 40 Engine Equipped to Use Natural Gas.

- 1. SCREW, Idle adjusting. 6. CARBURETOR.
- 3. SCREW, load adjusting. 7. REGULATOR, screw, starting fuel.
- 4. SCREW, starting adjusting.
- 8. PLUG, drain.
- 5. Set the engine throttle control about 1/3 open.
- 6. Close the choke valve and start the engine.
- 7. When the engine starts; leave the choke closed and the throttle as set; then adjust the screw (4) for the highest rpm and lock the screw in position.
- 8. Open the choke valve, reduce the engine speed to idle and adjust the screw (1) for best idle operation. If the engine fails to respond when changing from starting to running position, open or close the screw (3) until the condition is overcome.

9. With the choke valve open and the engine throttle set to just under governed speed, adjust as follows:



Turn the screw (3) in (clockwise) until the engine loses speed; then out (counterclockwise) approximately 1/4 turn. These adjustments should give the approximate best performance and minimum gas consumption.

10. Adjust the screw (1) to give the best idle after the engine is warmed up and readjust throttle for the proper idle speed.

1225 (VI) 11.79712 4(835511

4416a2


# MECHANICAL GOVERNOR

With the engine stopped, adjust the carburetor connecting rod as follows:

- 1. Disconnect the clevis (4) from the lever (5).
- 2. Place the levers (1 and 6) in the wide open throttle position.
- 3. Adjust the length of the rod (2) so that the hole in the clevis (4) is in line with the hole in the lever (5). Adjust the clevis one additional turn longer.
- 4. Connect the clevis to the lever with the pin (5).
- 5. Start and operate the engine until normal operating temperature is reached.
- 6. Pull the rod (10) back against the stop.
- 7. Loosen the nut (9).
- 8. Turn the adjuster (3) in or out to produce the required governor fast idle speed which is stamped on the nameplate attached to the left side side of the flywheel housing.

NOTE: Move the adjuster out (toward the rear) to increase engine speed and in (toward the front) to decrease engine speed.

9. Check the governor action by suddenly moving the rod (10) back against the stop. If the governor surges more than twice, turn in on the screw (8) just enough to stop excessive surging. Lock the screw with the jam nut.



Illust. 41 Governor Adjustment.

- LEVER, carburetor throttle.
- ROD, governor to carburetor.
- ADJUSTER, governor spring:
- CLEVIS.
- PIN, clevis.

- LEVER, governor control.
- GOVERNOR.
- SPRING, bumper.
- NUT, governor spring adjuster lock. 9.
- ROD, governor spring retainer. 10.

# POWER TAKE-OFF CLUTCH

10

This over-center type clutch is designed to require a minimum of attention. Overlubrication is as detrimental to the clutch as under lubrication. It is important to follow the lubrication instructions as given in "LUBRICATION GUIDE" on page 20.

#### Adjustment

Adjustment is required when adiminished effort is required to "engage" the clutch.


Rapid wear of the clutch facings will result if slippage takes place while the engine is under heavy load.

NOTE: New clutch facings have a series of high spots or feather edges which must be worn away before the lining is capable of transmitting its full torque capacity. Hence, clutch adjustment will be required several times within the first 10 hours of operation. These adjustments will avoid rapid clutch facing wear due to slippage and will allow the clutch to handle full engine power.

Adjust the clutch as follows:


- 1. Remove the clutch instruction plate.
- Disengage the clutch and slowly crank the engine (refer to "HAND CRANKING" on page 33) until the adjusting points appear in the center of the opening.

- 3. TWIN DISC CLUTCH (11-1/2 INCH): Depress the lock pin (A) and hold the power take-off shaft to keep the clutch from turning. Insert a pry bar in the notch in the adjusting yoke (B) and turn the yoke clockwise one notch at a time (Illust. 42).
- 4. ROCKFORD CLUTCH (8 INCH): Loosen the adjusting ring lock screw (A) with an offset screwdriver to free the lock (B). Hold the power take-off shaft to keep the clutch from turning and insert a pry bar into a notch in the adjusting ring (C) for leverage. Turn the ring a notch at a time in a counterclockwise direction (Illust. 44).




Illust. 42
Adjusting the Twin Disc 11½ inch Over-Center Clutch.


3. TWIN DISC CLUTCH (8 AND 10 INCH): Pull out the adjusting yoke lock pin so it is disengaged from the floating plate. Hold the powertake-off shaft and turn the adjusting yoke clockwise (right); move it one notch or possibly two notches until the clutch hand lever requires a distinct pressure to engage (flust. 43).




Illust, 44
Adjusting the Rockford 8 inch Over-Center Clutch.

4. ROCKFORD CLUTCH (10 AND 11-1/2 INCH): Loosen the adjusting ring lock screw "A" with an offset screwdriver to free the lock "B." Hold the power take-off shaft to keep the clutch from turning and insert a pry bar into a notch in the adjusting ring "C" for leverage. Turn the ring a notch at a time in a counterclockwise direction (Illust. 45).






Illust. 43
Adjusting the Twin Disc 8 and 10 inch Over-Center Clutch.




11lust. 45
Adjusting the Rackford 10 and 11½ Inch Over-Center Clutch.


5. Be sure the clutch lever is in the "disengaged" position. To determine the correct amount of hand-pull effort for your engine refer to Illust. 46 or 47 for the IH power take-off number on your engine.



Illust. 46
Rockford Instruction Plate.



Must. 47
Twin-Disc Instruction Plate.



Illust, 48
Method of Checking Clutch Adjustment.

6. Engage the spring scale hook on the clutch lever as shown in Illust. 48 Refer to the chart on this page for the correct amount of handpull effort.

NOTE: These figures, shown in the charts below, are based on the clutch lever originally furnished with the power take-off.

## ROCKFORD

IH Power Take-Off Part Number	Pounds of Effort	
319 500 R91 319 503 R91 319 519 R91 319 524 R91	50 70 75 75	

#### TWIN-DISC

IH Power Take-Off	Pounds of
Part Number	Effort
321 052 R91	80-90
321 054 R91	60-65
321 056 R91	70-80
321 057 R91	70-80
346 882 R91	110-120

- 7. ROCKFORD CLUTCH: Tighten the adjusting ring lock screw.
- 7. TWIN-DISC CLUTCH: Secure the adjusting lock pin.
- 8. Install the clutch instruction plate.

# TRANSMISSION CLUTCH

This clutch is a non-adjustable, dry type and automatically compensates for clutch facing wear.

# STORING THE ENGINE

# Gasoline Engines

When the engine is not to be used for a period of time, it must be stored in a dry and protected place. Leaving equipment outdoors, exposed to the elements, will result in materially shortening its life.

The following procedure must be followed when the engine is place in storage for 30 days or more and the lubrication procedures repeated every six months.

We recommend that caution be taken in starting an engine that has been in storage. Refer to the procedure shown under "PREPARING STORED ENGINE FOR SERVICE" on this page.

- Thoroughly wash or clean the engine.
- 2. Run the engine long enough to warm the oil in the crankcase. Drain the crankcase, change the lubricating oil filter element (as described on page 32) and fill the crankcase. (Refer to the "LUBRICATION GUIDE" on page 17, for the correct viscosity of oil used for the prevailing temperature.)
- Completely lubricate the rest of the engine as outlined in the "LUBRICATION GUIDE" on pages 18, 19, 20 and 21.
- 4. Drain the fuel from the fuel tank and carburetor and clean out the fuel pump filter. (Refer to "Cleaning the Fuel Filter" on page 43).

NOTE: Present-day grades of gasoline have a tendency to form gum; therefore, it is necessary that the gasoline tank and carburetor be completely drained of fuel when the engine is to be out of service for more than two weeks. These gum deposits can be dissolved with a mixture of one part alcohol and one part benzol, or with acetone.

- 5. Remove the spark plugs and pour one tablespoonful of Grade-50 lubricating oil into each cylinder. Crank the engine two or three times to distribute the oil over the cylinder walls; then reinstall the spark plugs.
- 6. Remove the valve housing cover and flush the valves, rocker arms and push rods with Grade-50 lubricating oil. (If any evidence of rust is found, remove it before lubricating.) Use a paint brush to coat the inside of the valve cover with Grade-50 lubricating oil. Install the valve housing cover.
- 7. Drain and clean the cooling system (refer to page 25). Install a "RADIATOR DRAINED" tag.
- 8. Remove the crankcase breather pipe from the valve cover and plug up the hole.
- Completely service the air cleaner as outlined under "AIR CLEANER" on pages 29 and 30.
- 10. Remove the air cleaner intake cap and store it in a clean dry place. Cover or plug the exhaust pipe and the air cleaner pipe.
- 11. Remove the battery and store it in a cool, dry place above freezing (+32°F). The battery must be fully charged at the time of storage. Check the battery liquid level at least once a month for water level and specific gravity. (Re-

fer to "Liquid Level" on page 37.) Never allow the battery to run down below 3/4 full charge while in storage.

# Liquefied Petroleum and Natural Gas Engines

Follow the same procedure used for preparing the gasoline engines for storage, except as follows:

1. If the fuel lines are going to be disconnected from the engine; close the supply valve on the fuel line. Run the engine until it stops from lack of fuel, and proceed as follows:

LIQUEFIED PETROLEUM GAS ENGINES-Disconnect the fuel line at the fuel inlet (flust. 38). Plug the fuel inlet. Cover the end of the fuel inlet line.

NATURAL GAS ENGINES: Disconnect the fuel line at the fuel inlet (Illust. 40). Plug the fuel inlet. Cover the end of the fuel inlet line.

2. Drain the fuel regulators of water as follows:

LIQUEFIED PETROLEUM GAS ENGINES: Open the valve(Z. Illust. 38) and allow any accumulation of water to drain completely. Close the valve.

NATURAL GAS ENGINES: Remove the drain plug (headless, slotted) (8, Illust. 40) and drain off any accumulation of water. Install the plug.

 Replace the fuel filter element on liquefied petroleum gas engines. (Refer to page 45.)

# PREPARING STORED ENGINE FOR SERVICE

- 1. Install a fully charged battery and be:sure the proper connections are made. (Refer to the wiring diagrams on pages 39 or 40.)
- 2. Remove the spark plugs and pour a mixture of one-half gasoline and one-half light lubricating oil into each cylinder; one ounce (two tablespoonfuls) per cylinder is enough.
- 3. Remove the valve housing cover and flush the valve and valve operating mechanism with the same mixture.
- 4. Crank the engine rapidly until the excess oil has been blown out of the spark plug holes. This operation will loosen any tight piston rings and wash old, gummy oil from valves and pistons.




- 5. Drain and flush out the crankcase with kerosine or flushing oil and fill with the specified lubricating oil. (Refer to the "LUBRICATION GUIDE" on page 18.) Be sure a new element has been installed in the lubricating oil filter.
- Remove the exhaust pipe, crankcase breather and the air cleaner opening plugs and/or covers.
- 7. Install the exhaust pipe.
- 8. Clean the crankcase breather (refer to "CRANKCASE BREATHER" on page 33). Install the crankcase breather.
- 9. AIR CLEANER (WET TYPE): Remove and clean the oil cup. Refer to "Cleaning the Oil Cup" on page 29.
- 10. Install the air intake cap.
- 11. Install the spark plugs after cleaning and setting the gaps (refer to "Spark Plugs" on page 36).
- 12. Be sure the cooling system drains are closed and fill the cooling system. Check for eaks and loose connections. Remove the RADIATOR DRAINED" tag.
- 13. If the fuel lines have been disconnected from the engine, remove the plugs from the fuel inlet. Remove the covers from the fuel

inlet lines. Reconnect the fuel inlet lines being sure the connections are tight.

LIQUEFIED PETROLEUM GAS ENGINES: Check that a new fuel filter element has been installed as outlined on page 45.

- 14. Fill the fuel tank or tanks.
- 15. Start the engine and let it run slowly; observe if any valves are sticking. If so, pour a small quantity of kerosine on the valve stems until loose.



- 16. Install the valve housing cover. Tighten the valve cover bolts (refer to "Torques" on page 5).
- 17. After the engine has been run long enough to clean the excess oil out of the cylinders, the spark plugs should be removed and checked for oil fouling. If fouled, clean and reinstall them in the engine.

NOTE: When installing the spark plugs, refer to "Torques" on page 5 for the specified torque.

# PARTS CATALOG

INTERNATIONAL ENGINES

UC-221 AND UC-263
ENGINE
AND
ATTACHMENTS

FORM

PU-520

September, 1965

(Supersedes PU-52, PU-52A, and PU-52B)

INTERNATIONAL HARVESTER COMPANY 401 NORTH MICHIGAN AVENUE CHICAGO, ILLINOIS 60611, U.S.A. SS/L

Due to a continuous program of research and development, some procedures, specifications and parts may be altered in a constant effort to improve machines.

Periodic revisions may be made to this publication and mailed automatically to distributors. It is recommended that customers contact their distributor or dealer for information on the latest revision.

(THIS CATALOG INCLUDES REVISIONS 1, 2 AND 3)

# UC-221 AND UC-263 ENGINE AND **ATTACHMENTS**

FORM

September, 1965

(Supersedes PU-52, PU-52A, and PU-52B)

# The Importance of ADEQUATE PARTS and SERVICE

The wise purchaser of a new machine gives consideration to the following factors:

- 1. Original quality
- 2. Availability of service parts
- 3. Availability of adequate service facilities

In many cases the machine becomes the only means of performing certain tasks that must be done in a limited period of time. Wear is to be expected and under extreme conditions even breakage of parts may occur. However, the user can still be assured of getting his work done on time if service parts and adequate service facilities are available.

Foresighted International Harvester distributors and dealers make every effort to provide good service and maintain a completely adequate stock of service parts.

When in need of parts, always give your authorized International Engine distributor or dealer your Chassis and Engine serial numbers. We suggest that you write these serial numbers in the spaces provided below, for ready reference when parts are required.

Chassis	Serial	No	(Stamped on plate on left side of flywheel housing)
Engine	Serial	Νо	(Stamped on left side of engine crankcase just below the distributor)

# INSTRUCTIONS FOR ORDERING PARTS

- (a) All parts orders should be sent to parts depot when so instructed. Give complete address, state the county and railroad station (when shipping point is different than post office), also whether shipment is to go by parcel post, express, truck, or freight.
- (b) When ordering parts, give the IH part number, including suffix or prefix letters. To facilitate identification of these parts, "Complete Serial Numbers" (including letters and numerals) assigned to machines, if any, should be furnished.
- (c) Parts should be ordered on the standard parts order blank. The parts should be arranged in sequence by part numbers to facilitate service on orders at the parts depot.
- (d) Claims for shortage or error in the handling of an order for parts must be made upon receipt of goods.

It is the policy of International Harvester Company to improve its products whenever it is possible and practical to do so.

We reserve the right to make changes or add improvements in the design or construction of parts at any time without incurring the obligation to install such changes on products previously delivered.

4000

# INTRODUCTION



This catalog contains a list of service parts for the UC-221 and UC-263 engines and attachments. The UC-221 has a 3-9/16 x 3-11/16 inch six-cylinder carbureted engine and the UC-263 has a 3-9/16 x 4.390 six-cylinder carbureted engine.

SS/L

Following is a brief summary of the system used in compiling this catalog. It is to your advantage to carefully study this summary.

This catalog is printed in a double column page format, and is divided into four sections---Introductory Pages, Indexes to Units, Illustrations and Parts Lists, and Numerical Index.

(1) INDEXES. Two types of indexes are used. The index to units alphabetically lists all of the units by page number. The numerical index at the back of the catalog lists all part numbers (excluding standard fasteners) giving the page number where the part is listed.

NOTE - Refer frequently to the Index to Units to save time in locating the proper unit.

(2) ILLUSTRATIONS. Parts in this catalog are illustrated by the "exploded view" method. Individual parts in each illustration are shown where they belong in relation to one another. Reference numbers only are shown in each illustration. These numbers correspond with numbers in the Reference Number column in the accompanying list of parts. Parts in illustrations without reference numbers are the same as duplicate parts with reference numbers.

<u>CAUTION</u>: Reference numbers should not be used when ordering parts. Always use IH part numbers or description when ordering.

(3) METHOD OF LISTING. The parts list of each classification is divided into units. Parts are listed in order according to reference number shown in the illustration, followed by a full description based upon the "noun first" method---i.e., the noun name of the parts is listed first then the modifying descriptive information which serves to specifically identify the item. For example: SHAFT w/two PLUGS ASSEMBLY, valve lever. Parts not shown in illustrations appear at end of list in alphabetical sequence by noun name. Parts listed will work on all units covered in this catalog unless a serial number or other qualifying designation is given for purpose of identification.

Throughout this catalog the term "Front" indicates the radiator end. Whenever the terms "Right" or "Left" are used it should be understood to mean from a rear position looking toward the radiator end.

MANUFACTURERS PART NUMBERS ARE LISTED IN BRACKETS FOLLOWING THE DESCRIPTION OF THE PART.

(4) NUMBER REQUIRED. In this new double-column catalog format the single "No. Req'd." column is eliminated and the quantity used of each item is shown in parenthesis (4) following the description of the item. Where no quantity is indicated it should be understood to mean that only one (1) is required.

In many parts lists it is possible to include more than one assembly or attachment. The assemblies or attachments are listed at the beginning of the parts lists with the letters A. B. C. etc., preceding the part number of the assembly or attachment. The number required information is shown in parenthesis following the description of the parts. When letters (A. B. C. etc., ) are shown without a quantity it should be understood to mean only one (1) is required. Parts without letters after the description indicate the part is used for all assemblies or attachments listed in the heading.

- (5) ASSEMBLIES AND ATTACHMENTS. Wherever possible the component parts of assemblies or attachments are shown in the "exploded views" by use of boxes, brackets or arrows. Component parts of assemblies or attachments are listed by one of the following methods.
  - (a) The listings are fully covered by descriptions for simple assemblies and attachments.
  - (b) When four or more parts are contained in the assemblies or attachments the listing of components immediately follows the description with the wording "(Composed of-)."
  - (c) Assemblies or attachments consisting of many parts shows the assembly or attachment number at the beginning of the unit list, followed by the listing of the components.

Exceptions to the above methods are explained by footnotes in the text.

Individual parts of an assembly which are not available for service are marked with a symbol . In some instances, such parts are listed with a notation giving the information which is to be used for ordering.

(6) MISCELLANEOUS PARTS. Standard bolts, screws, nuts, etc. --- are not identified by a reference number. These parts are known as COMMON HARDWARE items and appear in abbreviated nomenclature and are shown indented under the major items with which they are used. They should be ordered as listed, since they are not component parts of the pieces they attach. Hardware parts identified with part numbers have



# INTRODUCTION - Continued

reen designed for a specific usage. Standard rdware parts should not be substituted for em.

WARNING: Attaching parts especially made for their location should never be substituted with regular standard parts.

SS/L

The following rules are established to govern the listing of attaching parts:

The part number for Common Hardware items is eliminated. However, Design Hardware items will continue to be listed by part number and description.

All Carriage, Machine and Plow BOLTS:
NUTS; Cap, Machine and Set SCREWS, will be
considered furnished with National Course
Thread unless otherwise specified. The number
of threads per inch will be eliminated.

A 1222 A

All NUTS will be considered 'hex." unless otherwise specified.

All WASHERS will be considered "Plain" unless otherwise specified. The "ID", "OD" and "No." identity will be eliminated. The inside dimension will be listed first, followed by the outide diameter and the thickness.

All <u>lock WASHERS</u> will be considered "Medium" type unless specified as "Light" or "Heavy."

All cotter PINS will be considered "Extended-Prong" type unless otherwise specified.

All groove PINS will be considered "Standard Groove" unless otherwise specified.

All common RIVETS will be considered "Annealed" unless otherwise specified.

All countersunk-head tubular RIVETS will be considered "Copper-Plated Steel" unless otherwise specified.

All oval-head tubular RIVETS will be considered "Brass."

Standard bolts used in International Harvester Products are manufactured under standards known as Unified National Coarse Thread (U. N. C. and Unified National Fine Thread (U. N. F.) with the number of threads per inch for various diameters as follows:

Diameter of Bolt	No. of Threads per inch (U.N.C.)	No. of Threads per inch (U.N.F.)	
1/4" 5/16" 3/8" 7/16" 1/2" 9/16" 5/8" 3/4" 7/8" 1-1/8" 1-1/4" 1-3/8" 1-1/2"	20 18 16 14 13 12 11 10 9 8 7 7	28 24 20 20 18 18 16 14 14 12 12 12 12	

(7) ABBREVIATIONS. The abbreviations used in this catalog are explained in the list of abbreviations on page 3.

#### (8) SERIAL NUMBERS.

海水 经分指的计划 建氯化 人口机 计自动编制 人

Models	Starting Engine Serial Number	Starting Chassis Serial Number	
UC-221	C-221 6093	UC-221 501	
UC-263	C-263 6682	UC-263 501	

The chassis serial numbers for these units are stamped on a name plate on the left side of the flywheel housing.




# LIST OF ABBREVIATIONS

LIST OF ABB	REVIATIONS
A period after the abbreviation is used only when th	
adjadjustable	lbpound, pounds
alaluminum	lentil-hdlentil head LHleft hand
astalloy steel	lkglocking
ampampere, amperes anlannealed	LP Gas Liquefied Petroleum Gas
approxapproximately	lublubrication
assyassembly	mach
attattachment	medmedium
bd-hdbinding head	MI malleable iron
b-hd button head	NC
brgbearing	NF National Fine (thread)
brsbrass	ninickel
brz bronze	ni-pltd-stlnickel plated steel
cd-pltd	No. Zumber NPT National pipe thread
cd-pltd-stl	NPT National pipe thread
C-Z cadmium or zinc plated	OC outside circumference OD outside diameter
cr-pltd	O/S oversize
cr-pltd-stl	O/S oversize ov-hd oval head
CIcast iron	oz
csk countersunk csk-hd countersunk head	parkerized-stl parkerized steel
cl-rec-hd	pkgparkerned steel
com	pltdplated
cone-pt	ptpoint
cont	PTOpower take-off
copcopper	rd-endround end
cplcopper plated	rd-hdround head
cot cotter	rd-ptround point
c-pincotter pin	regregular
crescorrosion-resistant-steel (stainless)	RH right hand RPM revolutions per minute
cr-rec-hd cross recess head	SAE Society of Automotive Engineers
crecorrosion resisting	sfsemi-finished
crgcarriage cup-ptcup point	sitslotted
cylcylinder, cylinders	slt-hdslotted head
degdegree	slt-bd-hd slotted binding head
dia diameter	slt-fil-hdslotted fillister head
dld drilled	slt-f-hdslotted flat head
dld-f/c-pin	slt-hex-hdslotted hexagon head
dld-f/lkg-wire drilled for locking wire	slt-pan-hd
dog-ptdog point	slt-rd-hdslotted round head
extexternal	slt-truss-hdslotted truss head
f/for	sq
femfemale fil-hdfillister head	sq-nk square neck
fil-hd fillister head fin-nk filn neck	std standard
f-csk-hd flat countersunk head	std-hdstandard head
f-fil-hd	stlsteel
f-hdflat head	strstraight
f-ptflat point	Tteeth
flexflexible	tap. tapping thd thread
fltdfluted	thd
ft foot, feet	UNF
ga gauge hd head	U/S undersize
hdlsheadless	unfinunfinished
hex. hexagon	wb-hdwagon box head
hex-hd hexagon head	w/
hex-soc-hdhexagon socket head	w/brzwith bronze
hphorsepower	w/hex. with hexagon
hvheavy	w/owithout
hydhydraulic	znzine
IDinside diameter	zn-ctzinc coated
in inch, inches intinternal	zn-pltdzinc plated
int	STATES OF AMERICA


148

77.4

()



Right front view of the UC-221 and UC-263
Engine with Hood and Dash, Radiator Grille, Front and Rear Support and Air Cleaner Attachments.



Left front view of the UC-221 and UC-263
Engine with Hood and Dash, Front and Rear Support,
Fan, Fan Guard, Instrument Panel, Power Take-off,
Engine Controls and Air Cleaner Attachments.

SS/L

# INDEX TO UNITS

	INDEX T	O UNITS	
DESCRIPTION	Page	DESCRIPTION	Page
COOLING SYSTEM		Damper, vibration (UC-263)	14
Pump, water	38	Engines, service	6A, 6B
Package, field service (water pump)	38	Flywheel	14
Thermostat	38	Gasket sets: Engine	42 42
ELECTRICAL SYSTEM		Gauge, oil level	1.1
Battery and Cables	65	Gear, idler	Co. October
Belt, fan	48	Governor (IH)	22
		Governor, meeting	
Cable, battery	65	Head, cylinder	16
Cables, ignition	4.0	Manifold, intake and exhaust	18
Battery	43 44		_ / _
Magneto	43	Pistons	8, 9 14
_		· · · ·	
Distributor	43, 45	Rods, connecting	8, 9
Fan, generator	48	Sleeves	
Generator (Delco-Remy)		Service Engines	6A, 6B
(used with Hydraulic Pump)	49	Valves	
(not used with Hydraulic Pump).	50	FUEL SYSTEM	
Magneto	62, 6 <del>4</del>	1022 31312	
Motor, cranking	46	Carburetor	
	43	Combination Natural Gas	36
Plugs, spark	43	Gasoline	
Magneto	44	Liquefied Petroleum Gas	
Pulley, Generator	48	(Ensign)	28
		Natural Gas	35
Regulator, voltage	52, 53 43	Filter, fuel (Liquefied Petroleum	
Resistor	43	Gas) (Ensign)	36
Wiring, electric		Fuel pipe and connections	دهنده زبل الري اساد ا
Battery	54, 58, 60		36
Magneto	56	Gasoline	•
		Liquefied Petroleum Gas	رىنى <b>4.4</b> 6 سا
		Natural Gas	35
ENGINE		The last and the state of the s	36-
Arms, rocker	16	Package, carburetor gasket	1 1
Arms, Focker	10	•	İ
Bearings	_	Regulator, fuel	
Camshaft	7 8	Liquefied Petroleum Gas (Ensign)	30
Connecting rod	14	Natural Gas, Combination	
Oranghatt		Natural Gas and Gasoline	
Carnshaft	7	(Ensign)	32
Cover	12	MISCELLANEOUS	
Crankcase front		MISCELLANEOUS	
Crankcase and related parts	11	Gasket sets	42
Crankshaft	14	Product graphics	42

NOV-27-2001 16:41 SS/L 650 852 5865 P.09/26

MEMORANDA

MEMORANDA

्र १ । ३ में ब्रिक्ट विकास

and the state of t

PRINTED IN UNITED STATES OF AMERICA (Rev. No. 1 10-166) PRINTED IN UNITED STATES OF AMERICA

-7**A**-ENGINE


Ö

ENGINE

-7A-

CAMSHAFT AND RELATED PARTS

CAMSHAFT AND RELATED PARTS - CONTINUED



REF.	LH. PART	DESCRIPTION	NEF.	i. H. PART Number	DESCRIPTION SERVER PROPERTY	
1	16 026 DB	NUT, camshaft gear	7	70 259 RZ	BEARING, camebaft front (will work for 367 514 R1) (also listed with Grankcase and	
Σ	16 025 D	LOCK, camshaft gear nut			Related Parts")	
3 3	312 500 R1 367 240 R1	GEAR, camshaft (*) GEAR, camshaft (not *)	8	70 260 RI	BEARING, camshaft intermediate front (also listed with "Crankcase and Related Parts")	
4	70 425 R1	BOLT, camshaft thrust plate (2)	9	70 261 R2	BEARING, camshaft intermediate rear (also listed with "Crankcase and Related Parts")	
5	35 650 HA	PLATE, camshaft thrust	10	70 Z62 R1	BEARING, camshaft rear (also listed with "Crankcase and Related Parts")	
6	127 559	KEY, camshaft gear (Woodruff No. 90)	11	367 229 R1	CAMSHAFT	

CONNECTING RODS, SLEEVES AND PISTONS C-221 501 to 43020 C-263 501 to 56635

ENGINE

-8-

181

## -8-ENGINE

REF.	I. H. PART Number	DESCRIPTION
NO.	NUMBER	

CONNECTING RODS, SLEEVES AND PISTONS - CONTINUED C-221 501 to 43020 C-263 501 to 56635

7		SLEEVE, cylinder (order sleeve assembly cylinder w/piston and rings) (6)
8		PISTON (order sleeve assembly cylinder with piston and rings) (6)
9	367 638 R92	SLEEVE w/FISTON and RINGS ASSY, cylinder (UC-221) (gasoline standard altitude) (6)
2	367 640 R9Z	and the second s
<b>9</b> 1 54 0 1	367 637 R92	SLEEVE SET, cylinder (consists of six SLEEVES w/PISTONS and RINGS, 367 638 R92) (UC-ZZI) (gasoline standard altitude)
9	367 639 R9Z	SLEEVE SET, cylinder (consists of six SLEEVES w/PISTONS and RINGS, 367 640 R92) (UC-263) (gasoline standard altitude)
9	371 091 R92	SLEEVE w/PISTON and RINGS ASSY. cylinder (UC-221) (L. P. gas and natural

	371 094 R94	PEFF AR MALIGION OF METAL THE TANK AND THE T
		(UC-263) (L.P. gas and natural gas) (6)
	371 Q89 R9Z	SLEEVE SET. crankcase (consists of six
		SLEEVES w/PISTONS and RINGS.
		371 091 R9Z) (UC-221) (L.P. gas and
		natural gas)
,	371 090 R92	SLEEVE SET, crankcase (consists of six
		SLEEVE w/PISTONS and RINGS,
		371 092 R9Z) (UC-263) (L.F. gas and
		natural gas)
	371 829 R92	SLEEVE SET, crankcase (consists of six
•		SLEEVES w/PISTONS and RINGS,
		372 082 R92) (UC-ZZI) (gasoline-high

371 092 R92 SLEEVE w/PISTON and RINGS ASSY, cylinder

gae) (6)

	altitude)
372 082 R92	SLEEVES w/PISTONS and RINGS ASSY (UC-221) (gasoline-high altitude) (6)
	SLEEVE SET, crankcase (consists of six
371 833 R92	SLEEVES w/PISTONS and RINGS.
	372 084 R9Z) (UC-263) (gasoline-high altitude

9	372 084 R9Z	SLEEVES w/PISTONS and RINGS ASSY, cylinder (UC-263) (gasoline-high altitude) (6)
10	364 913 R1	BUSHING, piston pin (6)
11 11	367 408 R11 36 <b>7 6</b> 32 R11	BEARING, connecting rod (2 halves) (std) (6) BEARING, connecting rod (2 halves) (. 00Z"
11	376 666 R11	undersize) (6) BEARING, connecting rod (2 halves) (.010"
11	376 668 R11	undersize) (6) BEARING, connecting rod (2 halves) (.020" undersize) (6)
11	367 631 R11	BEARING, connecting rod (2 halves) (.030" undersize) (6)
11	367 630 R91	BEARING SET, connecting rod (Consists of six BEARING, 367 408 R11) (standard)
11	377 285 R91	BEARING SET. connecting rod (Consists of six BEARING, 367 632 RII) (.002" under size)
11	376 665 R91	BEARING SET. connecting rod (Consists of six BEARING, 376 666 R11) (.010" under-
ł 1	376 667 R91	size) BEARING SET, connecting rod (Consists of six BEARING, 376 668 R11) (.020" under-
11	372 443 R91	size) BEARING SET. connecting rod (Consists of six BEARING, 367 631 R!!) (.030" under-
		size)

5 10	24	9
13		10

MEF.	I.H.PART NUMBER	DESCRIPTION
1	38 <b>9 747</b> RI	RING, piston barrel compression (top groove (3/32" chrome thick wall) (6)
2	389 751 RI	RING, piston taper face compression (second groove) (3/32" plain) (6)
3	388 355 R1	RING, piston oil regulating (third groove) (1/4" Perfion) (6)
4	367 649 R92	RING SET, piston (replacement) (consists of six chrome compression rings, six plain compression and six oil regulating rings) (6)
5	19 517 D	RING, piston pin retainer (12)
6	70 014 R1	PIN, piston (standard) (6) C-221 501 to 34717 (6) C-263 501 to 36027
6	278 271 Ri	PIN, piston (standard) (6) C-221 34718 Up (6) C-263 36028 Up
6	70 Q15 R1	PIN. piston (.005" oversize) (6) C-221 501 to 34717 (6) C-263 501 to 36027
6	278 326 R1	PIN, piston (.005" oversize) (6) C-221 34718 Up

(6) C-263 36028 Up

367 406 R12 ROD w/two BOLT5, 316 366 R1 and BUSHING, 364 913 R1, connecting (6) BOLT. connecting rod (12)


12

13

Ô

-9-ENGINE

CONNECTING RODS, SLEEVES AND PISTONS C-221 43021 Up C-263 56636 Up



REF. NO.	I. H. PART NUMBER	O S # CRIPTION	
i	389 747 Rt	RING, piston barrel compression (top groove) (3/32" chrome thick wall) (6)	
2	389 751 RI	RING, piston taper face compression (second groove) (3/32" plain) (6)	
3	388 355 R1	RING. piston oil regulating (third groove) (1/4" perflon) (6)	
4	367 6 <del>49</del> R92	RING SET. piston (replacement) (consists of six Chrome compression rings, six plain compression and six oil regulating rings)	
5	19 <b>517</b> D	RING, piston pin retainer (12)	
6	70 014 R1	PIN, piston (standard) (6) C-221 501 to 34717 (6) C-263 501 to 36027	
6	278 271 R1	PIN, paston (standard) (6) C-221 34718 up (6) C-263 36028 up	
6	70 015 R1	PIN, piston (.005" oversize) (6) C-221 901 to 34717 (6) C-263 501 to 36027	
6	278 326 R1	PIN, piston (.005" oversize) (6) C-221 34718 up (6) C-263 36028 up	

PRINTED IN UNITED STATES OF AMERICA

I, H. PART NUMRER

### ENGINE

DESCRIPTION

7		SLEEVE, cylinder (order sleeve assembly cylinder w/piston and rings) (6)
8		PISTON (order sleeve assembly cylinder w/Piston and rings) (6)
9	378 601 R94	SLEEVE w/PISTON and RING ASSY. cylinder (UC-Z21) (gasoline standard altitude) (6)
<b>9</b>	378 604 R95	SLEEVE w/FISTON and RINGS ASSY, cylinder (UC-263) (gasoline standard altimate) (6)
9	378 600 R94	SLEEVE SET, cylinder (consists of six sleeves w/PISTONS and RENGS; 378 601 R93) (UC-Z21) (gasoline standard altitude)
9	378 603 R95	SLEEVE SET, cylinder (consists of six sleeves w/PISTONS and RINGS, 378 604 R94) (UC-263) (gasoline standard slutude)
9	380 647 R94	SLEEVE w/PISTON and RING ASSY, cylinder (UC-221) (L.P. gas. natural gas, and gasoline high altitude) (6)
9	380 649 R95	SLEEVE w/PISTON and RING ASSY, cylinder (HC-263) (L.P. gas, natural gas and gas- oline-high altitude) (6)
9	380 646 R94	SLEEVE SET, crankcase (consists of six SLEEVES w/PISTONS and RINGS. 380 647 R94) (UC-221) (L.P. gas, natural gas and gasoline-high altitude)
9	380 648 R95	SAE and gastine-right transits of six SLEEVES. w/PISTONS and RINGS, 380 649 R95) (UC-263) (L.P. gas, natural gas and gasoline-high altitude)
10	364 913 R1	BUSHING, piston pin (6)
11	367 408 R11	BEARING, connecting rod (Z halves) (stand- ard) (6)
11	367 632 R11	BEARING, connecting rod (2 halves) (.002" undersize) (6)
11	376 666 R11	BEARING, connecting rod (Z halves) (.010" undersize) (6)
11	376 668 R11	BEARING, connecting rod (2 halves) (.020" undersize) (6)
11	367 631 R11	BEARING. connecting rod (2 halves) (.030" undersize) (6)
11	367 630 R91	BEARING SET, connecting rod (Consists of six BEARING, 367 408 R11) (standard)
11	377 Z85 R91	BEARING SET. connecting rod (Consists of six BEARING, 367 632 RII) (.002" undersize)
11	376 665 R91	BEARING SET. connecting rod (Consists of six BEARING, 376 666 R11) (.010" undersize)
11	376 <b>667 R</b> 91	sixe)
11	37Z 443 R91	Six BEARING, 367 631 RII) (.030 " under 812
12	367 406 RZ1	364 913 R1. connecting (9)
1,3	316 366 R1	BOLT, connecting rod (12)

PRINTED IN UNITED STATES OF AMERICA


Ö

ENGINE

ENGINE

CRANKCASE AND RELATED PARTS - CONTINUES

CRANKCASE AND RELATED PARTS - CONTINUED



# . -11-ENGINE

	ENGINE			ENGINE ENGINE		
REF.	I. H. PART NUMBER	BESCRIPT!	5 N	REF. NO.	I. H. PART NUMBER	DÉSCRIPTION
	CASE AND RELA	ATED PARTS - CONTINUED		CRAN	KCASE AND REL	ATED PARTS — CONTINUED
ı	70 129 R1	PLUG, core hole (Z)		16	315 849 R1	ELEMENT, breather pips (used with COVER, 315 970 R91) (2)
Ż	36 <b>7</b> 512 R95	CRANKCASE ASSEMBLY (Composed of - 1 ADAPTER	367 513 R1	17	375 612 R91	SCREW w/WASHER, 1/4 x 1/2", slt-rd-hd mach (16)
		10 BOLT 1 BEARING 1 BEARING	70 133 R1 70 259 R2 70 260 R1	18	315 970 R91	COVER, w/two ELEMENT, 315 849 R1, valve push rod (will work for 69 734 R11)
		1 BEARING 1 BEARING	70 261 R2 70 262 R1	19	369 982 R1	GASKET, valve push rod cover
		§1 CAP	,	20	393 180 R91	SEAL, crankshaft rear oil PLUG. rear bearing cap (will work for
		SI CAP		21	310 665 R1	1 738 Y) (2)
		\$1 CAP				
		i COCK §1 CRANKCASE 2 DOWEL	103 647 371 699 RZ	22		CAP, crankshaft rear bearing (not furnished separately) (order Cranksas Assembly)
		2 PIN 2 PLUG 6 PLUG	141 285 126 045 70 128 R1	23		CAP, crankshaft intermediate rear bearing (not furnished separately) (order frankcase Assembly)
		Z PLUG	70 129 R1 444 852	24	58 516 H	WASHER, bearing cap bolt (10)
		3 PLUG 2 RING	371 315 R1	25	70 133 R1	BOLT, crankshaft bearing cap (10)
		1 TUBE 10 WASHER	378 102 R1 58 516 H )	26		CAP, crankshaft intermediate front bearing (not furnished separately) (order
3	70 128 R.1	PLUG, core hole (6)				Crankcase Assembly)
4	312 051 R91	GAUGE, oil level (for E	[ ] DOI FO #3050	27		CAP, crankshaft front bearing (not furnished separately) (order Crankcase Assembly)
4	368 986 R91	GAUGE, oil level (for d	63 501 to \$6635 listributor ignition)	28	141 285	PIN, 1/2 x 1-1/4" dowel, crankcase front plate and cover (2)
4	387 347 R91	C-2 C-2 GAUGE, oil level (for c	21 501 to 43020 63 501 to 56635 light-ibutor ignition)		318 441 R91	ATTACHMENT. flywheel housing (see NOTES   and 3)
4	301 341 N71	C-2	ZI 43021 UP 63 56636 Up			(Consists of - 2 DOWEL 371 699 R2 1 HOUSING 304 440 R2 1 SEAL 367 225 R1 )
5	312 052 R1	C-2	63 501 to 56635		70 259 RŽ	BEARING, camehaft front (will work for 367 514 R1) illustrated with "Camehaft and
5	368 965 RZ	TUBE, oil filler (for d C-Z C-Z TUBE, oil filler (for d	21 501 to 43020 63 501 to 56635		70 260 R1	Related Parts") BEARING, camshaft intermediate front (illustrated with "Camshaft and Related
5	378 10Z RI	C-2	21 43021 Up 63 56636 Up		70 Z61 R2	Parts")  BEARING, camshaft intermediate rear (illustrated with "Camshaft and Related Parts")
6	103 647	COCK, 1/4" drain (typ			70 <b>26</b> 2 R1	BEARING, camshaft rear (illustrated with "Camshaft and Related Parts")
7	3 <b>67</b> 513 R1	ADAPTER, distributor	mounting		356 243 R1	COVER, fuel pump pad (*)
8		NOT USED			46 923 D	DOWEL, engine rear support (1/2" dia) (part
9 9	371 699 R2 376 353 R1		support (Z) support (.030" oversize)			dowel is required order 371 699 RZ) (2)
10	304 440 R2	(2) HOUSING, flywheel (p: 318 441 R91)	art of Attachment		371 699 RZ	DOWEL, engine rear support 7/16" (part of ATTACHMENT. 318 441 R91)-(2) 2/2 x 2-1/4" hex-hd cap SCREW (4) 1/2" NUT (4)
11		SCREW, 1/2 x 1-1/4"	hex-hd. cap (2)		126 045	. 17 ° 24 DTD#: 3/8" se-sec (2)
12		WASHER, 1/2" lock (	5)		444 852	PLUG. 1/8" hox-soc-hd GI (crankcase drain)
13	367 ZZ5 R1	SEAL, engine rear su (part of Attachment, 1/2" NUT (4) 5/16 x 5/8" hex-hd 1/2 x 2-1/4" hex-h	318 441 K71)		444 853 444 854	(optional with 444 852 and 444 854) PLUG, 1/8" hex-soc-hd MI (crankcase drain) (optional with 444 852 and 444 854) PLUG, 1/8" hex-soc-hd slt (crankcase drain) (optional with 444 852 and 444 853)
		11/32 x 11/16" x .	065" WASHER (2)			
14	368 429 RZ 375 61Z R9	PIPE, breather SCREW w/WASHED (2)	R, 1/4 x 1/2" slt-rd-hd			# - Also Listed Under "Elsetric Wiring" (or Magneto Ignition.  * - Used with hydraulic pump-  § - Not Furnished Separately
	3 <b>6</b> 9 981 RI	GASKET, breather pi	pe			NOTE 1 - Factory Application - Order On
15		ELEMENT, breather				NOTE 3 - Field Application - Order Through Regular Service Parts Channels.
16	369 442 R1	COVER, 69 734 R11	)		NIW-	Regular Service Parts Chamicas.


-12-

ENGINE

10

# MEMORANDA

CRANKCASE FRONT COVER AND IDLER GEAR



NEF.	I.H.PART NUMBER	DESCRIFTION
1	372 499 R11	COVER w/POINTER, 367 572 R1 crankcase front (not *) 1/2 x 3" hex-hd cap SCREW (6) 1/2" lock WASHER (6)
1	31Z 505 RZI	COVER w/POINTER, 367 572 R1 crankcase front (*)
	16 081 RI	BOLT, 1/2 x 3-1/8" (6) 1/2NF NUT (3) 1/2 x 1-1/4" hex-hd cap SCREW 1/2" lock WASHER
Z	367 572 RI	FOINTER, timing
3	357 67Z R91	OIL SEAL, crankshaft (used w/DAMPER, 372 203 ft2)
3	317 549 R91	OIL SEAL, crankshaft (used w/PULLEY, 371 574 RZ or DAMPER, 338 952 R91)
4	367 580 R11 141 150	SHAFT w/PIN, 141 150, idler gear PIN, 3/16 x 7/16" dowel 1/2 x 2-1/4" hex-hd. cap SCREW 1/2" lock WASHER
5	367 578 R1	BUSHING, idler gear
6	367 577 R11	GEAR w/BUSHING, 367 578 R1, idler
<b>7</b>	312 506 R1 367 574 R1	GASKET, crankcase front cover (*) GASKET, crankcase front cover (not *)
8 8	316 155 R11 367 524 R1	PLATE, crankcase front (*) PLATE, crankcase front (not *) 3/8 x 1/8" hex-hd. cap SCREW (6) 3/8" lock WASHER (6)
9	316 156 R1	GASKET, crankcase front plate (*)
9	367 570 RI	GASKET, crankcase front plate (not *)
	278 269 R1	COVER, governor gear (*) 5/16 x 5/8" hex-hd cap \$CREW (5) 5/16" lock WASHER (5)
	278 270 R1	GASKET, governor gear cover (*)
		(*) - Used with Hydraulic Pump.

SS/L

650 852 5865

P.16/26

-13-

**MEMORANDĀ** 

MEMORANDA



\_\_\_\_\_


ENGINE

Ö

ENGINE

CRANKSHAFT, FLYWHEEL, BEARINGS, STUB SHAFT AND STARTING CRANK - CONTINUES





REF. NO.	1. H. FART NUMBER	DESCRIPTION
1	19 466 R1	BOLT, flywheel to crankshaft (Used with ATTACHMENTS, 305 189 R91, 312 571 R9) and 305 190 R91) (6)
1	9 409 049	BOLT, flywheel to grankshaft (Used with flywheel ATTACHMENT, 312 729 R91)
2	372 568 R1	GEAR, flywheel ring (159T)
3	31Z 563 R11	FLYWHEEL w/GEAR, 372 568 R1 (Used with flywheel ATTACHMENT, 312 571 R91)
3	312 728 R11	FLYWHEEL W/GEAR, 372 365 RI (Used With
3	318 053 R91	FLYWHEEL w/GEAR. 372 568 R1 (Used with flywheel ATTACHMENT, 318 051 R91)
3	372 567 R91	FLYWHEEL w/GEAR, 372 568 R1 (Used with flywheel ATTACHMENT, 305 189 R91)
3	372 569 R91	FLYWHEEL W/GEAR, 372 568 R1 (Used with ATTACHMENT, 305 190 R91)
4	367 Z68 R91	CRANKSHAFT ASSY (standard) (UC-221) C-221 501 to 35093
		(Composed of -
		I BEARING SET 367 630 R91
		1 BEARING SET 367 275 R91
		§ 1 CRANKSHAFT 1 FIN 82 970 R1 )
4	38 <b>2</b> 355 R91	CRANKSHAFT ASSY (standard) (UC-221) C-221 35094 up
		(Composed of -
		BEARING SET 367 630 K71
		1 BEARING SET 382 357 R91
		§ : CRANKSHAFT
		1 PIN 82 970 R1 )
4	367 Z69 R91	CRANKSHAFT ASSY (standard) (UC-263) C-263 501 to 36693
		(Composed of -
		1 BEARING SET 367 630 R91
		1 BEARING SET 382 357 R91
		§ 1 CRANKSHAFT
		1 PIN 82 970 RI )

HEF.	I. H. PART HUMBER	ORSCRIPTION
4	382 356 R91	CRANKSHAFT ASSY (standard) (UC-263) C-263 36694 Up
		(Composed of -
		BEARING SET 367 630 R91
		1 BEARING SET 382 357 R91
		§ 1 CRANKSHAFT
		1 PIN 82 970 RI )
4	367 270 R92	PACKAGE, crankshaft w/BEARINGS, field service (renewal) (undersize) (UC-221) (Consists of six connecting rod BEARINGS, four crankshaft BEARINGS, CRANKSHAFT and FIN, 82 970 R1)
4	367 271 R9Z	PACKAGE, crankshaft w/BEARINGS, field service (renewal) (underdize) (UC-263) (Consists of six connecting rod BEARINGS, four crankshaft BEARINGS, CRANKSHAFT and PIN, 82 970 R1)
5	367 272 RI	GEAR, crankshaft
6	71 763 R2	SLINGER, crankshaft oil
7	371 574 R2	PULLEY, fan drive (will work for 368 511 R1) (UC-221)
7	338 <b>952</b> R91	DAMPER (standard on UC-263) (Furnished as required for the UC-221, in place of PULLEY, 371 574 R2)
8	70 109 R1	WASHER, starting crank nut
9	35 667 H	NUT, crankshaft
10	271 705 R91	CRANK W/PIN, 15 204 D, starting
11	15 204 D	PIN, starting crank
12	117 984	KEY, 5/16 x 1-3/8" (Woodruff No. 23) (damper and pulley)
13	103 462	KEY, 3/16 x 1" (Woodruff No. 13) (grank- shaft gear)

PRINTED IN UNITED STATES OF AMERICA

# ENGINE

L		<b></b>	
140.	I, H, PART NUMBER	BESC	RIPTION
			THE SHAFT AND

# 

# **ENGINE**

1					
e7.	I.H. PART NUMBER	DESCRIPTION	NO.	HUMBER	SESCRIFTION
PANK	SHAFT, FLYWH ING CRANK — C	EEL, BEARINGS, STUB SHAFT AND	CRAN STAR	KSHAFT, FLYW TING CRANK — (	EHHL, BEARINGS, STUB SHAFT AND CONTINUED
		BEARING, crankshaft front (2 halves) (stand-	19	382 <b>358</b> R91	BEARING SET, crankshaft (. 030" undersize) C-Z21 35094 Up
<u>.</u>	<b>30.</b>	ard) BEARING, crankshaft front (2 halves) (.002"			C-263 36694 Up
	367 200 K41	undersize)		31Z 729 R91	ATTACHMENT, flywheel (for use with light duty power take-off ATTACHMENTS.
	376 670 R91	BEARING, crankshaft from (2 halves) (.010" undersize)			273 020 R91 and 273 021 R91 and with o
	376 683 R91	undersize) BEARING, crankshaft front (2 halves) (.020" undersize)			(Rockford or Twin-Disc) (UC-221) (864
	367 288 R91	BEARING, crankshaft front (2 haives) (.030" undersize)	7; *	. 305 189 R91	9 409 049 and one FLYWHEEL, 312 728 R11 ATTACHMENT, flywheel (for user with light duty power take-off ATTACHMENTS,
	367 279 R91	BEARING, crankshaft intermediate front		Sugar January Company	273 017 R91 and 273 018 R91 and with 10
	367 303 R91				clutch (Rockford or Twin-Disc) (UC-203)
		EERING, crankshall intermediate front  BEARING, crankshall intermediate front	no in the	14	BOLT. 19 466 R1 and one FLY WHEEL.
	376 673 R91	(a. L. L. L. ) / OIOH undareize)		. D. 602 2	大型 <b>的程序</b> 对于2000年
	376 686 R91	(2 halves) (.crankshaft intermediate front (2 halves) (.020" undersize)		318 051 R91	ATTACHMENT, flywheel (for use with Funk Model TRG-D16A-T9 Torque Converter)
,	367 Z91 R91	BEARING, crankshaft intermediate front (2 halves) (.030" undersize)			(see NOTES 1 and 3) (Consists of
		BEARING, crankshaft intermediate rear			1- BUSHING 318-049-RI
,	367 282 R91	/dard) /2 halves)			8 SPACER 318 050 RI
		C-221 501 to 35093 C-263 501 to 36693			1 FLYWHEEL 318 053 R91 )
		BEARING, crankshaft intermediate rear		312 571 R91	A TOTA CHINE NT flowbeel (for use with 12"
	332 <b>26</b> 7 R91	(standard) (2 halves)			clutch and controls ATTACHMENT,
		C-221 35094 Up C-263 36694 Up			MENT. 312 838 R91 oz 312 839 K91)
	367 306 R91	REARING, crankshaft intermediate			(see NOTES 1 and 3) (Consists of six BOLT, 19 466 R1, one
ı	207 200 E71	(.002" undersize) (Z halves) C-221 501 to 35093			FLYWHEEL, 312 563 R91 and one
		C-263 501 to 36693			SPACER, 312 562 RZ)
6	332 273 R91	BEARING, crankshaft intermediate (.002" undersize) (2 halves)		305 190 R91	ATTACHMENT, flywheel (for use with
		C-221 35094 Up			11-1/2" single plate overcenter drive ring type clutch (Rockford or Twin-Disc)
		C-Z63 36694 Up BEARING, crankshaft intermediate rear			/ive_241 /see NOTES 1 and 3) (Consists of
5	332 276 R91	(3 % a)) / 010" ntmdersize)			six BOLTS, 19 466 R1 and one FLYWHEEI 372 569 R91)
6	332 279 R91	DEADING erankshaft intermediate rear			
_		(2 halves) (.020" undersize) BEARING, crankshaft intermediate (2 halves)		318 <b>04</b> 9 R1	BUSHING, torque converter pilot (use with ATTACHMENT, 318 051 R91)
6	367 294 R91	(,030" under#i#e)			
		C-221 501 to 35093 C-263 501 to 36693		312 562 RZ	SPACER, cranking motor (used with ATTACHMENTS, 318 051 R91 and
6	332 270 R91	BEARING, crankshaft intermediate (2 halves)			317 <b>571 R911</b>
		(.030" undersize) C-ZZ1 35094 Up			3/8 x 2" hex-hd cap SCREW (3) 3/8" lock WASHER (3)
		C-263 36694 Up			
7	367 285 R91	BEARING, crankshaft rear (Z halves)		318 050 R1	SPACER, mounting strap (used with ATTACHMENT, 318 051 R91) (SF
		(standard)			
7	367 309 R91	( AAZU wedersite)		<u> </u>	
7	376 679 R91	BEARING, crankshaft rear (2 harves)	MO		DESCRIPTION OF THE PROPERTY OF
17	376 692 R91	BEARING, crankshatt rear (2 haives)			
17	367. Z97 R91	(.020" undersizs) BEARING. crankshaft rear (2 halves) (.030" undersize)	Dif	ECT CONNECTE	D STUB SHAFT ATTACHMENT
10	82 970 R1	PIN, flywheel to crankshaft dowel		305 698 R9	1 ATTACHMENT, stub shaft (direct connecte
18		DEARING SET, crapkshaft		203 U30 Ec7	(see NOTES 1 and 3)
19	367 Z75 R9	C-221 501 to 35075	20	29 308 D	KEY, belt pulley
		C-263 501 to 36693	21	305 699 R9	SHAFT W/DOWEL, 305 700 RI, atto
19	382 357 R9	C-221 35094 Up G-263 36694 Up		18 646 RI	Lock) (6)
			22	305 700 R	DOWEL, stub shaft
19	382 359 R9 382 360 R9		_		NOTE 1 - Factory Application - Order On
19 19	382 361 R9	BEARING SET, crankshaft (.020" undersize)			Machine Order Form.  NOTS 3 - Field Application - Order Through
19	372 444 R9	Camazai aut do 30433			NOTE 3 - Field Application - Older and Regular Service Parts Channels
		C-263 501 to 36693			

-16-


ENGINE

Ĭ

ENGINE

CYLINDER HEAD AND RELATED PARTS

CYLINDER HEAD AND RELATED PARTS - CONTINUES



REF. NO.	I, H, PART NUMBER	DESCRIFT	LION	REF. NO.	i. fl. part Number		DESCRIPTI	0 N
1	168 144 R1	BOLT, valve cover (3)		8	373 423 R21	HEAD A	SSY, cylinder	
_			(3)					1 501 to 43020
Z	370 208 R1	STIFFENER, valve co						3 501 to 56 <b>635</b>
3	164 420 R1	GROMMET, valve cove	±r (3)				posed of -	
	/		m// 1			§ 1	HEAD	
4	378 617 R91	COVER w/PLUG, 103				12	GUIDE	237 Z48 R.I
	103 866	PLUG, 1/4" sq-hd :	pipe			1	PLUG	70 128 R1
_		1.11.11				<u>,</u>	PLUG	126 045
5	369 983 R1	GASKET, valve cover				1	PLUG	103 874
						- (-6	SEAT	126 373 R1 )
6	69 500 R1	DOWEL, valve lever a				5/16	x 1/2" hex-hd c	ap SCREW:{2}.
		No. 2. No. 4 and No.	6 bracket (3)	_				
_	-0 . *0	DI 116		8	382 098 R92	HEAD w	/VALVE ASSY.	
7	70 128 RI	PLUG, core hole						1 43021 up 3 56636 up
_	( 004	TIDAD AGOV1:1	((1)1- F					2 20020 45
8	372 615 R94	HEAD ASSY, cylinder	(MITT MOLK FOL				posed of - SEAL	866 834 R1
		367 189 R93)	21 50! to 43020			12		000 034 VI
						1	HEAD w/	102 //6 803
			163 501 to 56635				GUIDES	383 665 R92
		(Composed of -				Z4	KEY	41 339 D
		I HEAD	373 423 R2I			1	PLUG	70 128 R.I
		24 KEY	41 339 D			6	RETAINER	151 167 R3
		6 RETAINER	151 167 R3			6	ROTOCOLL	375 604 R91
		6 ROTO-COIL				12	SPRIN <b>G</b>	367 19Z R1
		12 SEAL	866 834 R1			6	VALVE	234 276 R1
		12 SPRING	367 192 RI			6	VALVE	372 699 RZ )
		6 VALVE	234 275 RI					
		6 VALVE	372 699 RZ )			§ - Not I	Jurnished Separa	ately

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

REF.

NO.

R

10

11

12

12

13

14

15

16

17

18

18

19

19

19

20

21

21

23

24

25

26

27

28

29

30

31

32

DESCRIPTION

-17-

ENGINE

CYLINDER HEAD AND RELATED PARTS - CONTINUED

383 665 R92

75 524 R3

164 436 R91

164 418 RZ

234 275 R1

234 276 R1

237 248 R1

367 192 RI

151 167 R3

866 834 R1

41 339 D

367 191 R1

372 699 R3

126 373 R1

126 Z31 R1

83 488 RZ 237 248 R1

375 604 R91

76 950 R2

109 544 RI

164 422 R1

164 432 R91

133 093 R1

16 067 DA

35 619 H 76 953 R3

17 Z44 R1

19 790 RI

164 423 R11

58 516 H

69 722 R1

164 425 R1

Section 1

-17-

# rî i

### ENGINE

REF, NO.	I, H, PART NUMBER	DESCRIPTION	

### CYLINDER HEAD AND RELATED PARTS - CONTINUED

33	367 190 R1	BOLT, cylinder head (long) (7)
	444 782	PLUG, 3/8" sq-sec pipe
	444 664	PLUG, 1/2" sq-soc pipe
	111 024 R1	SEAL, intake valve stem (used with VALVE, 127 201 R1) (6)

	33
)	
.r ( <b>2</b> )	
d	
ie:	

F	IEAD w/GUIDES ASSY, cylinder C-221 43021 Up C-263 56636 Up	33
	(Composed of - § 1 HEAD 12 GUIDE 237 248 R1 1 PLUG 70 128 R1 6 SEAT 126 373 R1 ) 5/16 x 1/2" hex-hd cap SCREW (2)	
7	FAPPET, valve (12)	
3	ROD, valve push (12)	
(	SASKET, cylinder head	
•	VALVE, intake (together with 866 834 R1 will work for 127 201 R1) (6) C-221 501 to 43020 (6) C-263 501 to 56635	
	VALVE, intake (6) C-221 43021 Up (6) C-263 56636 Up	
	GUIDE, intake valve stem (6)	
	SPRING, valve (12)	
	RETAINER, valve spring (6)	
	SEAL, valve stem (12)	
	KEY, valve spring retainer (24)	
	VALVE, exhaust (gasoline) (6)	
	VALVĒ, exhaust (Stellite faced) (L.P. gas) (see NOTĒ) (6)	
	SEAT, exhaust valve (6)	
	SEAT, exhaust valve (.015" oversize) (6) SEAT, exhaust valve (.030" oversize) (6)	
	GUIDE, exhaust valve stem (6)	
i.	ROTOCOIL, exhaust valve (gasoline) (6)	
	RETAINER, valve spring (L.F. gas and natural gas) (6)	
	PLUG, rocker arm (2)	
	BRACKET, valve lever shaft front and rear (2)	
ı	LEVER w/SCREW, 16 067 DA and NUT, 133 093 R1, valve (12)	
	NUT, valve lever adjusting screw (12)	
	SCREW, valve lever adjusting (12)	
	SPRING, valve lever (6)	
	5HAFT, valve lever (2) PiN, 5/16 x 1-1/4" roll (optional with 19 790 R1) (2) PIN, 5/16 x 1-1/4" roll (optional with 17 244 R1) (2)	
1	BRACKET w/DOWEL, 69 500 R1, valve lever shaft intermediate No. 2, No. 4 and No. 6 (3)	
	WASHER, cylinder head bolt (15)	
	BOLT, cylinder head (short) (8)	
	BRACKET, valve lever shaft, intermediate No. 3 and No. 5 (2)	

§ - Not Furnished Separately. NOTE: Also Available For Service On Gasoline Engines If Desired.


-18-ENGINE


# 

# ENGINE

-18-

	'	
•		
•		





IPA-52144 A

MO.	i. H. Part Number	DESCRIPTION
1	69 752 R1	GASKET, intake and exhaust manifold
Z	368 550 R11	MANIFOLD w/PLUG, 103 317, exhaust 3/16 x 1/2" taper groove PIN 3/8 x 3" hex-hd. cap SCREW (4) 3/8 x 1-1/4" hex-hd. cap SCREW (6) 3/8 x 1-1/2" hex-hd. cap SCREW (2) 13/32 x 7/8" x 7 ga. WASHER (8)
3	85 868 R1	GASKET, intake to exhaust manifold
4	98 573 HA	PILOT, intake manifold (2) C-221 501 to 43020 (2) C-263 501 to 56635

REF. NO.	I. H. PART NUMBER	DESCRIPTION
INTAI	KE AND EXHAUS	T MANIFOLDS — CONTINUED
4	138 733 R1	PILOT, intake manifold (2) C-221 43021 Up (2) C-263 56636 Up
5	85 700 R1	VALVE, manifold heat control
6	69 443 R1	BUSHING, manifold heat control (2)
7	82 959 R1	SHAFT, manifold heat control valve
8	85 699 R1	WEIGHT, manifold heat control
9	318 445 R91	MANIFOLD ASSEMBLY, intake (*) (*) (*) (*) (*) (*) (*) (*) (*) (*)
		(Composed of -  2 BUSHING 69 443 R1 -  1 PLUG 445 671  1 PIN 141 159  1 SHAFT 82 959 R1  1 SFRING 82 958 R2  2 STUD 57 714 D  1 VALVE 85 700 R1  1 WEIGHT 85 699 R1)
9	367 261 R11	MANIFOLD ASSEMBLY, intake (not *) (Composed of -  2 BUSHING 69 443 R1  1 PLUG 445 671  1 FIN 141 159  1 SHAFT 82 959 R1  1 SPRING 82 958 R2  2 STUD 57 714 D  1 VALVE 85 700 R1  1 WEIGHT 85 699 R1 }
10	277 016 R1	STUD, carburetor (liquefied petroleum gas) (natural gas) (combination natural gas and gasoline) (2)
10	12 215 D	STUD, carburetor (2)
10	57 714 D	STUD, carburetor (part of carburetor adapter attachment) 312 057 R91) (2)
11	82 <b>958</b> R2	SPRING, thermostat heat control valve
12	141 159	PIN, 3/16 x 1" dowel
13		PIPE, exhaust (2" standard black steel pipe 13" long obtain locally)
14	371 098 RI	COVER, exhaust manifold (L.P. gas) (natural gas) (combination natural gas and gasoline) 3/8" NUT (4) 3/8 x 3-1/8" hex-hd. cap SCREW (4)
15	371 097 R11	MANIFOLD w/PLUG, intake (L.F. gas) (combination natural gas and gasoline)
	445 671	PLUG, 1/8" sq-hd C.I. PIPE (optional with 445 864)
	445 864 107 317	PLUG, 1/8" sq-hd. (optional with 445 671) PLUG, exhaust manifold drain hole
		(*) - For Use With Heavy Duty Magneto.  NOTE 1 - Factory Application - Order On
		Machine Order Form.  NOTE 3 - Field Application - Order Through

Machine Order Form.

NOTE 3 - Field Application - Order Through
Regular Service Parts Channels.

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

8

P.22/26

-19-

MEMORANDA

Ü


MEMORANDA

ñ

-20-ENGINE

GOVERNOR AND RELATED PARTS (L.H.) (for use with distributor ignition)

GOVERNOR AND RELATED PARTS - Continued (I.H.) (for use with distributor ignition)



REF. NO.	t. H. PART NUMBER	DEE	CRIPTION	NO.	(, H, PART NUMBER	OESCRIFT:	он -
1	368 335 R1	ROD, governor to	carburetor otter PIN 221 501 to 48022	6	367 660 R1	ADJUSTER, governor as 1/2NF jam NUT	oring
			263 501 to 77319	7	367 740 R1	RETAINER, governor sp	ring
1	306 013 Rt	ROD, governor to 1/4" NUT (3) 1/4" lock WAS	HER (2) 221 48023 Up	8	3 <b>7</b> 2 709 R2	SPRING, governor (2400 w/GOVERNOR ASSY, 3 376 589 R92) (1500 to 1 w/GOVERNOR ASSY, 6	72 708 R93 or 800 RPM when used
			263 77320 Up	8	367 739 R <b>2</b>	SPRING, governor (2000 (furnished as part of A)	to 2200 RPM) ITACHMENT,
Z	104 036	FORK, governor 1/4" NUT	to carburetor rod			612 3Z1 C91)	
		1,1 1101	221 501 to 48022 263 501 to 77319	9	367 656 R12	LEVER, w/ROCKSHAFT	
2	276 835 R91	JOINT, 1/4" ball		10	361 123 R91	OIL SEAL, governor roo	ckshaft
-		1/4" WASHER	221 48023 Up	11	369 593 R1	BEARING, governor	
			263 77320 Up	12	369 594 R1	BEARING, governor (2)	
3		PIN. 1/4 x 51/64	" rod end (governor to	13	172 530	PLUG, 11/16" type No.	
		1/16 x 7/16" o		14	376 590 R11	HOUSING ASSY, govern ASSY, 376 589 R9Z (Composed of -	
						2 BEARING 1 BEARING	369 594 R1 369 593 R1
4	367 659 R1	ROD, governor s	pring retainer			§ 1 HOUSING 1 PLUG	172 530
5	367 74Z RI		-hd cap SCREW (Z)			l OIL SÉA <b>L</b> § - Not Furnished Separ	361 123 R91)
		5/16" lock WA	ASHER (2)			8 - Mot Latintaged Sebar	decry.

DESCRIPTION

DESCRIPTION

# ENGINE



I. H. PART NUMBER

## ENGINE

GOVERNOR AND RELATED PARTS - CONTINUED (I.H.) (for use with distributor ignition)			SOVERNOR AND RELATED PARTS - Continued (I.H.) (for use with distributor ignition)		
14	367 651 R21	HOUSING ASSY, governor (used w/GOVERNOR ASSY, 372 708 R93) (Composed of -	376 589 R9Z	GOVERNOR ASSY (Units equipped w/Hydrauti Pump) (2400 RPM) 221 501 Up	
		2 BEARING 369 594 R1 1 BEARING 369 593 R1 § 1 HOUSING		263 501 Up (Units not equipped w/Hydraulic Pump) 221 48023 Up 263 77320 Up	
		1 PLUG 172 530 1 OIL SEAL 361 123 R91)		(Composed of -	
		3/8 x 1-1/2" hex-hd cap SCREW (3)		1 BEARING 393 405 RI	
		3/8" lock WASHER (3) 1/4NF x 1-1/2" slt-rd-hd mach 5CREW		GEAR	
		1/4NF jam NUT		w/WEIGHT 368 939 R93 1 HOUSING 376 590 R11	
15	367 669 R1	GASKET, governor housing		1 LEVER 367 656 R12	
16	367 653 R1	FORK, governor thrust		1 SCREW 368,938 R1 1 SLEEVE 387 878 R1	
17	368 938 R1	SCREW, governor thrust fork set		1 5PRING 374 795 RI )	
18	43 481 D	BALL BEARING, governor thrust C-221 501 to 19944	612 320 C91	ATTACHMENT, 612 319 C91)	
	374 794 R91	C-263 501 to 19080 BALL BEARING, governor thrust		(Composed of - 1 BEARING 393 405 R91	
18	3/4 / 74 14.71	C-221 19945 to 39301		I FORK 367 653 RI I GEAR AND	
18	393 405 R1	C-Z63 19081 to 53Z76 BALL BEARING, governor thrust		WEIGHT 378 128 R9Z	
10	373 103 KI	G-221 39302 Up	•	1 HOUSING 376 590 R11 1 LEVER 367 656 R12	
		C-263 53277 Up		1 SCREW SET 368 938 R1	
				1 SLEEVE 387 878 R1 1 SPRING 374 795 R1)	
19	251 460 R1	RING. governor sleeve stop C-ZZ1 501 to 39301		•	
		C-263 501 to 53276	612 319 C91	ATTACHMENT, mechanical governor (Consist of GOVERNOR ASSY, 612 320 C91)	
20	367 741 R1	WEIGHT, governor (2)		(w/ or w/o Hydraulic Pump) (1500 to 1800	
	17 053 R1	PIN, 1/4 x 3/8" Espa roll (2)		RPM) (10% regulation wide open throttle) (5% regulation 3/4 load) (See NOTES 1 and 3.	
21	367 668 R2	SLEEVE, governor thrust	612 321 C91	ATTACHMENT, mechanical governor (Consta	
	201 000 11-	C-221 501 to 39301		of SPRING, 367 739 R2) (w/ or w/o Hydraulic Pump) (2000 to 2200	
21	387 878 R1	C-263 501 to 53276 SLEEVE, governor thrust		RPM) (10% regulation wide open throttle)	
	34, 2.0 2	C-221 3930Z Up C-263 53277 Up		(5% regulation 3/4 load) (See NOTES 1 and 3	
		C-200 33211 Op	19 983 R1	NUT, nylon (Used on Gasoline engines equipped w/Hydraulic Pump)	
22	369 477 R1 367 726 R1	RING, snap CARRIER, governor weight		•	
23 24	281 907 Ci	RING, governor shaft bearing snap	376 591 R1	TUBE, governor lubrication (Use on Gasoline engines equipped w/Hydraulic Pump)	
25 26	ST 552 367 666 R1	BALL BEARING, governor shaft RETAINER, governor bearing	386 010 R91	PACKAGE, governor field service	
27	367 665 R1	SHAFT, governor		(Composed of -  1 BEARING 369 593 R1	
28	452 560	KEY, governor gear (Woodruff No. 211)		2 BEARING 369 594 RI	
29	367 664 R1	GEAR, governor		1 BEARING ST 552 1 BEARING 393 405 R91	
		7/16" lock NUT (Type LLJ)		1 FORK 367 653 R1	
30	368 939 R93	GEAR w/WEIGHT ASSY, governor (Part of		l GASKET 367 669 R1 l LEVER 367 656 R12	
		GOVERNOR ASSY, 372 708 R93 and 376 589 R92)		1 FLUG 172 530	
30	378 128 R92	GEAR w/WEIGHT ASSY, governor (Part of		2 PIN 17 053 R1 1 RING 281 907 C1	
		GOVERNOR ASSY, 612 320 C91)		1 SCREW 368 938 R1	
31	374 795 R1	\$₽RING, bump¢°		1 SLEEVE 387 878 RI 1 SPRING 374 795 R1	
				t SEAL 361 123 R91 2 WEIGHT 367 741 R1)	
	32 468 H	BODY, elbow (Used on Gasoline engines equipped w/Hydraulic Pump			
			444 852	PLUG, 1/8 Auto hex-soc-hd drain (optional w/444 853 or 444 854) (Used w/GOVERNOR	
	372 708 R93	GOVERNOR ASSY (order 376 589 R92) (2400 RPM) (Units not equipped w/Hydraulic		455V 376 589 R92)	
		Pump)	444 854	PLUG, 1/8" Auto hex-soc-hd drain (optional w/444 852 or 444 853) (Used w/GOVERNOR	
		ZZI 501 to 480ZZ 263 50! to 77319		Δ¢¢V 376 589 R9Z1	
		(Composed of -	444 853	PLUG, 1/8" Auto hex-soc-hd drain (optional w/444 852 or 444 854) (Used w/GOVERNOR	
		1 BEARING 393 405 R		ASSY, 376 589 R92)	
		1 GEAR			
		w/WEIGHT 368 939 R93 1 HOUSING 367 651 R21			
		1 LEVER 367 656 R12		NOTE 1 - Factory Application Order On Machine Order Form.	
		1 SCREW 368 938 R1 1 SLEEVE 387 878 R1		NOTE 3 - Field Application - Order Through	
		1 SPRING 374 795 Rt )		Regular Service Parts Channels.	

ENGINE



# -22-ENGINE

	1 H 1 mm 1	REF. NO.	I. H. PART NUMBER	DESCRIPTION
MECHANICAL GOVE (Novi)	RNOR	MECH/	ANIÇAL GOVERI	NOR — Continués
<u></u>	8 9 10			FOR USE WITH MAGNETO IGNITION - Continued C-221 501 to 43020
2 \ \	5 7			C-263 501 to 56635
$ar{f}$		D		Service parts for mechanical governor  For use with medium duty magnete ignition Gasoline 2400 RPM - 5% regulation
1 7 3 1 1		E		Service parts for mechanical governor For use with heavy duty magneto ignition Gasoline
1 7 9 B	13			1200 RPM to 1600 RPM - 10% regulation
22	14 15 16	<b>F</b>	e e	Service parts for mechanical governor  For use with heavy duty magneto ignition  Gasoline  2400 RPM - 5% regulation
	15	,		FOR USE WITH DISTRIBUTOR IGNITION
IPA-60665	17	G		Service parts for mechanical governor  Not used with hydraulic pump  Gasoline
REF. I.H. PART	DESCRIPTION			1800 RPM to 2400 RPM - 10% regulation Natural gas, LPG and combination gas-gasoline 1800 RPM to 2200 RPM - 10% regulation
NO. NUMBER				2400 RPM - 5% and 10% regulation
	Parts without letters after the description indicate the part is used for all mechanica! governors listed below: Letters A through M are used to identify separate mechanica!	н		Service parts for mechanical governor For use with hydraulic pump Gasoline 1800 RPM to 2400 RPM - 10% regulation
	governors.	3		Service parts for mechanical governor Not used with hydraulic pump
	FOR USE WITH MAGNETO IGNITION  G-221 501 to 43020  G-263 501 to 56635			Gasoline 1200 RPM to 1600 RPM - 10% regulatio 1800 RPM - 5% regulation Natural gas, LPG and combination gas- gasoline
A	Service parts for mechanical governor For use with medium duty magneto ignition on gasoline, natural gas, LPG and			1200 RPM and 1400 RPM-10% regulation 1600 RPM - 5% and 10% regulation 1800 RPM - 5% regulation
	combination gas - gasoline  For use with heavy duty magneto igntion on natural gas, LPG and combination gas - gasoline Gasoline	К		Service parts for mechanical governor For use with hydraulic pump Gasoline 1200 RPM to 1600 RPM-10% regulation
	1800 RPM to 2400 RPM - 10% regulation Natural gas, 1PG and combination gas-			1800 RPM - 5% regulation
	gasoline 1800 RPM to 2200 RPM - 10% regulation 2400 RPM - 5% and 10% regulation	L		Service parts for mechanical governor  Not used with hydraulic pump Gasoline 2400 RPM - 5% regulation
 B	Service parts for mechanical governor For use with heavy duty magneto ignition on gasoline	М		Service parts for mechanical governor Use with hydraulic pump Gasoline
	1800 RPM to 2400 RPM - 10% regulation	,	313 998 R1	2400 RPM - 5% regulation COUFLING (56418)
С	Service parts for mechanical governor For use with medium duty magneto ignition on gasoline, natural gas, LPG and	1 Z	443 013	PIN. 1/8 x 5/8" groove (2)
	combination gas - gasoline For use with heavy duty magneto ignition	3	277 161 RI	FORK (50023)
	on natural gas, LPG and combination gas- gasoline	4	277 162 R1	SPRING, bumper (50306)  LEVER w/BUSHING (56424 A)
	1200 RPM to 1600 RPM - 10% regulation 1800 RPM - 5% regulation	5	313 996 R91 103 883	PLUG. 1/9" headless sltd pipe (2)
	Natural gas, LPG and combination gas- gasoline 1200 RPM and 1400 RPM - 10% regula-	7	313 984 R91	BODY w/two PLUG. 103 883 and SCREW.
	tion 1600 RPM - 5% and 10% regulation	8	367 669 R1	313 988 R1 (56433A) GASKET, governor housing
	1800 RPM - 5% regulation	9	452 560	KEY, 1/16 x 3/8" Woodruff

),

- 1973 \_ 180 **9**<sup>7</sup> 08

# ű

### ENGINE

		<u></u>
REF.	I. H. PART	DESCRIPTION
NO.	NUMBER	

MECHANICAL GOVERNOR - CONTINUED (Novi)

10		CENTRIFUGAL UNIT (Not Furnished Separately) 3/8NF NUT 3/8" lock WASHER
11	313 989 R91	LEVER (56427A)
12	313 992 RI	SPRING, governor (56436)
13	313 990 R1	PLUNGER, spring (56428)
14	313 991 RI	SCREW, adjusting (53933-B)
15.		NUT. 1/4"NF (3)
16	313 995 Rl	LEVER, manual (56422)
17	277 169 R1	WASHER, manual lever (50129)
18	277 170 R1	CLIP, lever shaft (50130)
19		NUT. 3/8" NF
20	313 988 RI	SCREW, adjusting (56419)
Z1		WASHER, 3/8" lock
2 <b>Z</b>	313 994 R1	SCREW, stop (52703-1)
	313 983 R91	BODY ASSY

313 983 R91	BODY ASSY	
	(Composed of -	
	1 BODY	313 984 R91
	i CLIP	277 170 R1
		277 161 R1
	ı fork	
	1 LEVER	313 989 R91
	1 LEVER	313 995 R1
	l LEVER	
	W/BUSHING	3 13 996 R91
	2 PIN	443 013
	PLUNGER	313 990 RI
		313 991 R1
	1 SCREW	
	1 SCREW	313 994 Kl
	1 SPRING	313 992 R1
	SPRING	277 162 RI
		277 169 R1 )
	ı WASHER	211 107 101 /

109 415	BALL, joint governor connecting rod (2)
,0,	1/4NF NUT (Z)
	1/4" lock WASHER (4)

29 901 D CONNECTOR, governor lubrication tube (in governor) (Mechanical Governor H and M)

272 497 R1 COVER, magneto mounting (Mechanicai Governor C, H, J. K, L and M) 3/8 x 7/8" hex-hd cap SCREW 3/8 x 1-1/4" hex-hd cap SCREW 13/32 x 13/16" x 16 ga. WASHER 3/8" lock WASHER

313 492 R1 ELBOW, governor lubrication tube (Mechanical Governor H and M)

310 840 R91 GOVERNOR ASSY (56385-A) (Mechanical Governor A. B. G and H)

(Composed of - 313 983 R91

§ 1 CENTRIFUGAL

UNIT

1 COUPLING 313 998 R1

1 KEY 452 560 )

3/8 x 1-1/4" hex-hd cap 5 CREW (3)

3/8" lock WASHER (3)

338 343 R92 GOVERNOR ASSY (Mechanical Governor C, E, J and K) (\*)

3/8 x 1-1/4 hex-hd cap SCREW (3)

3/8" lock WASHER (3)

# ENGINE

REF.	I, H, PART	DESCRIPTION
NO.	NUMBER	

MECHANICAL GOVERNOR - CONTINUED (Novi)

338 344 R91	GOVERNOR ASSY (Mechanical Governor D. F. L and M) (*) 3/8 x 1-1/4" hex-hd cap SCREW (3) 3/8" lock WASHER (3)
19 984 R1	NUT, governor lubrication tube (2 for Mechan- ical Governor H and M)
306 013 R1	ROD, governor connecting
312 066 RI	ROD, governor connecting (Mechanical Governor B, E and F)
995 061 R1	SCREW, No. 8 x 1/4" pan-hd slt tapping TUBE, governor lubrication (13" long, copper 1/4" OD #) (Mechanical Governor H and M)

§ - Not Furnished Separately.

\* - Service Parts Will Be Furnished In The
Next Revision Of This Catalog.

(#) - Fart Number and Frice Covers One Foot
Of Tubing. Furnished Only In 50 Foot
Rolls.


PRINTED IN UNITED STATES OF AMERICA

-24-


# Ĉ

# FUEL SYSTEM

### FUEL PIPE AND CONNECTIONS (Not used with Hydraulic Pump)



FUEL FUMP (Not used with Hydraulic Pump)



## FUEL SYSTEM

REF.	L.H. PART	525CRIFT; ON
NO.	NUMBER	

FUEL PIPE AND CONNECTIONS - CONTINUED (Not used with Hydrawic Pump)

ı	372 498 R1	PIPE, fuel	
2	19 885 R1	NUT, coupling (2)	
3	84 838 R93	PUMP ASSEMBLY, fuel (for components see list of parts under details of "Fuel Pump")	
4	Z4 847 H	ELBOW (at fuel pump)	
5	172 915 RI	CLIP, fuel pipe	
6		CARBURETOR ASSEMBLY (for companents see list of parts under details of "Carburetor	•")

	_
·	- 18 18 18 1

DESCRIPTION

FUEL PUMP — Continued (Not used with Hydraulic Pump)

I. H. PART NUMBER

NEF.

	84 838 R93	PUMP ASSEMBLY. fuel
1	90 623 R1	LEVER, cam
Z	612 293 C1	GASKET, pump to crankcase
3 4		WASHER, 5/16" lock (2) SCREW, 5/16 x 1" hex-hd. CAP (2)
5	90 610 R91	SCREW, w/WASHER
6		Not Furnished Separately. (order 84 838 R93)
7 8	90 625 R91 90 626 R1	DIAPHRAGM DIAPHRAGM, air dome
9	109 317 RI	COVER, filter and valve housing
10	967 640 R21	ELEMENT, filter, glazed ceramic
17	109 313 R11	BOWL, w/GASKET, 90 600 Rt
1.2	109 315 R91	
13	90 606 R1	SPRING. filter
14 15	90 600 R1 121 759 R91	HOUSING, valve
16	90 611 R91	SCREW, w/WASHER, valve housing to filter cover
17 18	90 598 R1 90 619 R1	PLUG, cam lever shaft scal PIN, spring cam lever pin retainer
19	90 603 R1	SPRING, cam iever return
20	90 618 R1 109 318 R1	PIN, cam lever WASHER, filter bowl retainer


-25-

MEMORANDĀ

-25-MEMORANDA

# -26-FUEL SYSTEM

CARBURETOR (Gasoline)



MEF. MO.	I, H, PART Humber	DESCRIPTION
(X) -	KEY TO UNITS	•
Α.	367 <b>258 R9</b> 2	CARBURETOR ASSEMBLY, 1-1/4" I.H. updraft (order 374 325 R91) (UC-ZZ1)
В -	367 <b>259 R92</b>	CARBURETOR ASSEMBLY, 1-3/8" I.H. updraft (order 379 813 R92) (UC-263)
C -	374 325 R92	CARBURETOR ASSEMBLY, 1-1/4" I.H. updraft (will work for 367 258 R91) (UC-221)
D <b>-</b>	372 723 R92	CARBURETOR ASSEMBLY, 1-3/8" I.H. updraft (will work for order 379 813 R92) (UC-263) 3/8"NF NUT (2) 3/8" lock WASHER (2)

REF.	I. H. PART NUMBER	DESCRIPTION
CARB (Gaso	URETOR - Conti line)	HUWD
E -	379 813 R9 <b>2</b>	CARBURETOR ASSEMBLY, 1-3/8" I.H. updraft (will work for 372 723 R92) (UC-263)
•	the description the unit for whi	units correspond with those shown following of the parts in the list below and identifies ich the part is used. Items without letters iption indicates the part is used for all units.
1	368 139 R91	SHAFT and LEVER w/PiN, 18 609 R1, and RETAINER. 24 484 D, throttle 3/32 x 11/16" Esna roll PIN
Z		SCREW, throttle shaft adjusting
3	25 494 D	SPRING, idle throttle adjustment retainer
4	47 392 D	SCREW, throttle butter fly (2)
5 5	370 862 R1 54 489 D	BUTTERFLY, throttle (Units A, B and C) BUTTERFLY, throttle (Units D and E)
7	379 598 RI	SEAL, throttle shaft dust (Units D and E)
8	47 390 D	BUSMING, throttle shaft
9	368 142 RI	PLUG, idle passage
10	362 528 RI	SCREW, idle adjusting
11	351 959 R1	SPRING, idle adjustment screw retainer
12	31 336 D	GASKET, carburetor (not furnished as part of carburetor ASSEMBLY)
13	368 147 RZ1	BODY ASSEMBLY, throttle (Units A, B and (Composed of - Z BUSHING 47 390 D I FIN 45 110 D I PLUG 57 956 D I SEAL 379 598 RI ) BODY ASSEMBLY, throttel (Units D and E) (Composed of - Z BUSHING 47 390 D
		1 FIN 45 110 D 1 PLUG 57 956 D
14	57 OE 6 A	I SEAL 379 598 R1 )
15	57 956 D 47 390 D	PLUG, throttle shaft expansion  BUSHING, throttle shaft
16	18 377 D	GASKET, strainer screen retainer
17	29 902 DX	RETAINER, strainer screen
18	32 596 D	CLAMP, starting shutter control No. 10NF x 5/8" fil-hd. mach, SCREW (cd. or zn-pltd.) No. 10NF NUT (cd. or zn-pltd.) No. 10 lock WASHER (cd. or zn-pltd)
19	368 146 RII	BRACKET w/CLAMP, 32 596 D, starting shutter control
20	45 110 D	PIN, throttle stop
21	368 143 R1	VENTURI, double (Units B and C)
21 21	368 148 R1 372 722 R1	VENTURI. double (Unit A) VENTURI. double (Unit D)
21	47 407 R93	VENTURI, single (Unit E)
22 23	25 948 D 47 396 DAX	GASKET, needle valve cage  10 CAGE w/GASKET, 25 948 D, needle valve
23 24	47 394 D	
-T	*( )7* D	SUPPORT, float lever pivot No. 4 x 5/16" slt-rd-hd mach SCREW

-27-

## FUEL SYSTEM

-27-


H		fuel system			FUEL SYSTEM
:F.	1. H. PART NUMBER	DESCRIPTION	REF.	I. H. FART NUMBER	DESCRIPTION
	RETOR - CONTINUE	:D	CARBI (Gabo)	URETOR = Contin line)	idEa
	_		46	24 687 DA	NUT, fuel adjusting screw packing
6 7	47 398 DX F	PIVOT, float lever FLOAT and LEVER BASKET, fuel bowl	47 47	47 404 DA 374 327 R1	SCREW, fuel adjusting (Units A and B) SCREW, fuel adjusting (Units C, D and E) (*)
9	49 798 <b>D7</b> 5 J	ET, idle metering No. 75	48	381 955 R1	GASKET, shut-off valve (Unit E)
9 9 9	35 404 D64 T	BLEED, main àir (No. 55) (Unit A) BLEED, main air (No. 54) (Unit B) BLEED, main air (No. 52) (Units C, D and E)	49	384 818 R91	VALVE ASSY, fuel shut-off solenoid (Unit E) (Composed of - 1 GASKET 381 955 R1 1 NEEDLE 384 822 R91
0	251 583 R1	GASKET, metering nozzle			1. O-RING 384-820 R1
1 1 1 1	370 863 R1	NOZZLE, metering (Unit A) NOZZLE, metering (Unit B) NOZZLE, metering (Units C and D) NOZZLE, metering (Unit E)		387 454 R92	1 SPRING 384 821 R1 ) PACKAGE, carburetor gasket (Units C. D and E)
32	•	BOWL ASSEMBLY, fuel (Unit A)  (Composed of		387 455 R92	1 GASKET 31 336 D 1 GASKET 18-317 D 1 GASKET 18-317 D 1 GASKET 25 948 D 1 GASKET 47 388 D 1 GASKET 251 583 R1 1 GASKET 381 955 R1 1 "O" RING 384-820 R1 1 PACKAGE 60 947 D 1 PACKAGE 60 947 D 1 PACKING 24 70 DA 1 SEAL 45 149 DA 1 SEAL 379 598 R1 ) PACKAGE, Carburetor overhaul field service (Units C and D) (Consists of - 1 BALL 52 791 R1 2 BUSHING 47 390 D
3 Z	372 720 R12	BOWL w/PIN, 351 588 R1. RETAINER, 45 148 D and SEAL, 45 149 DA, fuel (Units C. D and E) 1/4 x 7/8" hex-hd cap SCREW 1/4" lock WASHER PLUG, 1/8" sq-hd. stl. pipe (cd. or zn-pltd)			1 CAGE 47 369 DAX40 1 INSTRUCTIONS,
33	357 002 R1Z	SHUTTER, starting No. 6 x 1/4" sit-rd-hd mach SCREW (cd or zn-pitd) (2) No. 6 lock WASHER (cd. or zn-pitd) (2)			1 RETAINER 45 146 D 2 SCREW 47 392 D 1 SCREW 362 528 R1 1 SCREW 374 327 R1 1 SHAFT W/LEVER 368 139 R91
34 35	45 149 DA 45 148 D	SEAL, butterfly dust RETAINER, dust seal		458 DO	1 SPRING 46 059 D 1 SPRING 351 959 R1 )
36	352 642 R91	SHAFT w/LEVER starting shutter		387 458 R97	(Consists of -
37	363 881 R1	RETAINER, starting shutter lever switch No. 10NF x 5/8" fil-hd, mach, SCREW (cd. or zn-pld.)			1 BUSHING 47 390 D 1 CAGE 47,396 DAX40 1 FLOAT 47398 D 68
38 39	64 283 DBX 32 592 D	SWIVEL w/RETAINER, 363 881 R1. starting shutter lever WASHER, starting shutter lever swivel			1 PIVOT 47.395 D 1 PLUG 57:956 D 44 1 BETAINER 29.902 DX
40 41	52 791 R1 46 059 D	BALL, friction soring SPRING, starting shutter friction			1 RETAINER 45 180 COT 1 SCREW 47 392 D 1 SCREW 362 528 R1
42	351 588 RI	PIN, starting shutter stop (optional			1 SCREW 374 327 Rt
42	142 484	with 142 484) PIN, starting shutter stop (optional with 351 588 R1)			1 SHAFT 368 139 R91 1 SPRING 351 959 R1
43	60 947 D	PACKAGE, drip hole filler replacement		-4	1 SPRING 46 059 D ) RETAINER, dust seal (Units A. B. and C)
44 44	56 611 DA 355 003 RI	SEAT, fuel adjustment screw046" (Unit F SEAT, fuel adjustment screw051" (Unit E	• •	368 137 RI 312 066 RI	ROD, governor connecting (Units A and B)
44	374 331 R1	SEAT, fuel adjustment screws .050" (Unit D	, )	312 065 R	
44 44	374 330 R1 380 500 R1	SEAT, fuel adjustment screw 063" (Unit E	)		C-221 501 to 43020 C-263 501 to 56635
45 45	24 703 DA 67 266 DX	PACKING, fuel adjusting screw - (optional with 67 266 DX) (*) PACKING, fuel adjusting screw (optional with 24 703 DA) (*)			* - Used only on Carburetors w/o fuel shut- off.

## -28-FUEL SYSTEM

## FUEL SYSTEM

CARBURETOR (American Bosch Arma Corp.) (Liquefied Petroleum Gas and Natural Gas)

CARBURETOR - Continued
(American Bosch Arma Corp.) (Liquefied Petroleum Gas and
Natural Gas)



		The state of the s			
REF.	LH. PART	DESCRIPTION	REF.	1. H. PART NUMBER	DESCRIPTION
MO.	HUMBER				7 m 1 m 1
			_	112 EO4 D1	DIAPHRAGM, economizer (7070)
	309 592 R91	CARBURETOR ASSEMBLY (Model No. 1-1/4"	\$	113 504 RI	DIAPHRAGM ASSEMBLY, economizer (8324)
	307 376 4671	v Cl (Fraim V C 9174) (Service Parts Will	4	359 621 R91	DIAPHRAGM ABSEMBLY, CO.
		be furnished in next revision of this catalog)			
		be turnished in dear levision of the	5	373 189 RI	SCREW, economizer bleed (not part of
		(order CARBURETOR, 371 088 R92)	•	21.	350 418 R91\ (7939-44)
	371 088 R92	CARBURETOR ASSEMBLY W/BLEED SCREW,	,	6 6 4 2 0 T	NITT fiel adjusting SCIGW LOCK (*2*4)
	<b></b>	268 169 RI (American Bosch Arma Corp.	è	56 430 D	SCREW, fuel adjusting (7C64G)
		Model No. 1. CBX - 125.A - 136)	8	56 429 D	SCREW, starting adjusting (8293)
		(Will work for CARBURETOR, 309 592 R91)	9	359 620 R1	SCREW, Starting adjusting (7075)
		3/8 x 1-1/4" hex-hd. cap SCREW (2)	11	113 506 RI	NUT. starting adjusting screw lock (7075)
		3/8 X 1-1/4" HEX-110" Cap a comme (-)	•		
		3/8" lock WASHER (2)	12	307 977 R91	BODY, gas inlet and economizer
			12	301 7.7 2272	No. 12 x 7/8" slt-fil-hd. cd-pltd. mach.
					CODEW (A)
_	450 431 PI	COVER, economizer (7944)			No. 12 cd-pltd. light lock WASHER (4)
1	359 6Z3 Rl	No. 8 x 5/8" sit-fil-hd, cd-pltd, mach.			No. 12 Carpita, treat it in the
		No. 6 k 5/6 Section in the Pri			46 31160 mbd
		SCREW (5)	13	19 272 R1	TEE, $1/8 \times 90^{\circ}$ two-way (for $3/16^{\circ}$ tube)
		No. 8 cd-pltd. lock WASHER (5)		371 Z15 R1	print -conline (3)
			14		2 ( DAV 1/8 x 90° (for 3/10° (40c)
			15	32 468 H	GASKET, inlet and economizer (8296)
		SPRING, economizer (2120)	16	359 624 Rl	GASKET, inter and occurrence
Z	3 <b>5</b> 9 622 R1	PERTING. SCONDENS (STATE)			
					NUTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

-29-

# FUEL SYSTEM

REF.	I, M. PART NUMBER	BESCRIPTION
NO.	1101111111	

-29-

CARBURETOR - CONTINUES (American Bosch Arma Corp.) (Liquefied Petroleum Gas)

(Ameri	can Bosch Arm	a Corp., (Educated 1 control		
17	47 856 H	PLUG. 1/2" brs. expansion (6-43-F)		
18	37 024 D	BUSHING, throttle bearing (B-176 B)		
19	374 8 <b>6</b> 2 R91	BODY and THROTTLE ASSEMBLY, partial (9365)		
		(Composed of -     Z BUSHING 37 024 D     I DISC 359 611 R1     NOZZLE 64 835 D     I PLUG 13 123 D     I PLUG 47 856 H     SCREW 56 370 D     SEAL 64 837 D     SHAFT and STOP 373 187 R91 )		
20	64 837 D	OIL SEAL, throttle shaft (7037)		
21	373 187 R91	SHAFT and STOP ASSEMBLY, throttle (9344) No. 10NF x 5/8" sit-fil-hd, cd-pitd, mach, SCREW (4298)		
22	56 370 D	SCREW, throttle shaft (6733) (2)		
23	359 611 R1	DISC, throttle (2320)		
24	58 899 D	WASHER, dust (7036)		
25	359 616 R1	PIN, valve lever (8289)		
26	359 613 R91	DISC ASSEMBLY, spring loaded choke (2324)		
27	359 612 RI	SHAFT, choke (2327)		
28	56 365 D	SCREW, choke shaft (6732) (2)		
29	58 889 D	SUPPORT w/CLAMP, 56 389 D, ASSEMBLY, choke tube  No. 8 x 1/4" sit. binding hd-cd-pltd.  mach. 5CREW (7224) (2)		
30	56 389 D	CLAMP, choke tube (U-357)  No. 10NF NUT  No. 10NF x 3/8" sit-fil-hd. cd-pitd. mach.  SCREW		
31	275 583 R91	LEVER w/SET SCREW, 36 756 D ASSEMBLY, choke No. 10Nf x 1/2" hex-hd. mach. SCREW		
32	36 756 D	SCREW, choke lever set		
33	373 939 R1	VENTURI No. 12 x 3/4" slt-fil-hd. cd-pitd. mach. SCREW No. 12 cd-pitd. light lock WASHER		
34	359 627 R1	GASKET, air intake elbow (8593)		
35	373 190 R1	ELBOW, air intake (4303)  No. 12 x 5/8" slt-fil-hd, cd-pltd, mach,  5CREW (4)  No. 12 cd-pltd, light lock WASHER (4)		
36	13 123 D	PLUG, 3/16" brs. expansion (302)		
37	359 614 RI	LEVER. valve (8288)		
38	359 615 R1	WASHER, apring (1802)		
39	37 183 D	WASHER, valve lever (6347)		
	31 336 D	GASKET. carburetor (not furnished as part o Carburetor Assembly) (will work for 21 632 D)		
	64 835 D	NOZZLE, balance tube (6395)		


-30-

# FUEL SYSTEM

\_REGULATOR \_wign) (Liquefied Petroleum Gas)

# FUEL SYSTEM

FUEL REGULATOR - CONTINUED (Ensign) (Liquefied Petroleum Gas)



NO.	I. H. PART Number	DESCRIPTION	
	371 100 R91	REGULATOR ASSEMBLY, fuel (liquefied petroleum gas) (4391) 5/16 x 1-1/2" hex-hd, cap SCREW (2) 5/16 x 1-1/8" hex-hd. cap SCREW 5/16" lock WASHER	
ı	19 270 R1	SCREW, No. 10NF x 5/8" sit-fil-hd. cd-pltd. mach. w/lock WASHER (821-10S) (6)	
2	444 814	PLUG. 1/8" pipe (in vaporizer cover) (5145)	
3	277 195 R91	COVER, w/PLUG, 13 017 R1 ASSEMBLY, vaporizer (2991)	
4	277 196 R91	SPRING ASSEMBLY, high pressure (2993)	
5	277 370 R91	DIAPHRAGM ASSEMBLY, high pressure (3010)	
6	277 197 RI	COVER, high pressure diaphragm (3019)	
7	19 270 RI	SCREW. No. 10NF x 5/8 alt-fil-hd. cd-pltd. mach. w/lock WASHER (821-10S) (6)	
8	277 198 R1	GASKET, vaporizer cover (3022)	
•	277 199 R.I	.SCREW, vaporizer partition plate (3048) (3)	
10	277 350 RI	PLATE, vaporizer partition (2988)	

REF. NO.	1. M. PART Number	DESCRIPTION
11	277 351 R1	LEVER, high pressure valve (2989)
12	37 179 D	SCREW, idle adjusting (387-C)
13	14 526 D	SPRING, idle adjusting screw retainer (222F)
14	277 352 RI	SCREW, bleed, "B" (4B60)
15	277 353 RI	RETAINER, high pressure valve spring (2715)
16	277 354 R1	GASKET, high pressure valve spring retainer (2689)
17	277 355 RI	SPRING, high pressure valve (2717)
18	277 <b>356</b> R1	SPRING, high pressure valve seat retainer (2987)
19	277 357 R.1	VALVE, high pressure (2985)
20	277 358 R91	SEAT w/SEAL. 359 600 R1 ASSEMBLY, high pressure valve (2979)
21	359 600 K1	SEAL, high pressure valve (8739)
zΣ		VALVE ASSEMBLY, low pressure (not serviced separately - order 277 369 R91)
23	113 443 R91	LEVER ASSEMBLY, low pressure valve (8863)

Januare 1 J. Sty.

# -31-**MEMORANDA**

# -31-FUEL SYSTEM

ARF.	L H. PART	ひころは代(PTION
NO.	NUMBER	

FUEL REGULATOR - Continued (Ensign) (Liquefied Petroleum Gas)

Z <b>4</b>	277 360 R1	SPRING, low pressure val-	ve (3033)				
25	19 271 R91	SCREW w/lock WASHER ASSEMBLY, low pressure valve (771-78) (2)					
26	277 361 R1	SEAT, low pressure valve (3030)					
2 <b>7</b>	27 <b>7</b> 362 R1	PIN. pivot (3119)					
28	352 221 RI	SEAL, low pressure valve					
29	113 434 R91	STRAINER ASSEMBLY, fu	STRAINER ASSEMBLY, fuel inlet (8360)				
30	113 186	PLUG, 3/4" pipe (1533)					
31	103 88 <b>5</b>	BODY, regulator (Not Furnished Separately) (2976) PLUG, 3/8" pipe					
32	59 708 D	VALVE, drain (621 J)					
33	64 433 D	GASKET, low pressure pa	ertition plate (5181)				
34	277 365 R1	PLATE, low pressure par	ctition (3036)				
35	277 366 RI	PIN, diaphragm push					
36	277 367 R91	DIAPHRAGM w/PIN, 277 366 R1 ASSEMBLY, low pressure (3038)					
37	277 368 R2	PLATE, support (3040)					
38	118 831		PLUG. 1/8" slt-hd. pipe (3094)				
39	19 270 R1	SCREW, No. 10NF x 5/8' mach. (support plate) (	'elt-fil-hd. cd-pltd. 521-10-5) (8)				
	373 174 R91	COMPENSATOR ASSEME	SLY (4262-55)				
	277 369 R91	KIT, fuel regulator over! (Composed of -	12ul (3i4l)				
		l DIAPHRAGM	277 367 R91				
		DIAPHRAGM	277 370 R91				
		GASKET	64 433 D				
		1 GASKET	277 354 R1				
		1 GASKET	277 198 Rl 27 <b>7</b> 351 Rl				
		LEVER	352 221 R1				
		1 SEAL	359 600 R1				
		i SEAL I SEAT	277 358 R91				
		1 5CREW	37 179 D				
		3 SCREW	277 199 <b>R</b> l				
		23 SCREW	19 270 RI				
		2 SCREW	19 271 RI 277 196 R91				
		1 SPRING	277 196 K91 277 355 R1				
		1 SPRING 1 SPRING	277 356 R1				
		1 SPRING 1 SPRING	Z77 360 R1				
		1 STRAINER	113 434 R91				
		1 VALVE	277 357 R! )				
		I VALVE	,				

373 173 R1 RING, retaining (4245)

§ - Not Furnished Separately

 $\Sigma \, Z$ 

-32-

### FUEL SYSTEM

ULATOR UNIT (AMERICAN BOSCH)

Aral Gas (C-221 501 Up)

(C-263 501 Up)

Combination Gas and Gasoline

(C-221 501 to 43020)

(C-263 501 to 56635)





ACE.

I. H. PART

# FUEL SYSTEM

REGULATOR UNIT (AMERICAN BOSCH) - Continued Natural Gas (C-221 501 Up) (C-263 501 Up) Combination Gas and Gasoline (C-221 501 to 43020) (C-263 501 to 56635)





...

REF.	I.H.PART NUMBER	DESCRIPTION	NO.	I. H. PART NUMBER	DESCRIPTION
	35 816D	REGULATOR UNIT (Model 1" Type B)	11	268 Z01 R91	BOWL (ensign 6463)
		(RUB100A1) 5/16 x 3/4" hex-hd. cap 5CREW (2)	ιz	37 010 D	SPRING, lower diaphragm (SP 4616)
		5/16" lock WASHER (2)	14	324 797 R1	DIAPHRAGM, lower (DM-464)
ı	37 011 D	SCREW, idle adjusting (5C4619)	14	42 331 D	DIAPHRAGM 324 797 R) and PLATE, 42 333 D, lower (DM 4650 A)
2	36 758 D	SPRING, idle adjusting screw retainer (SP4629)	15	42 333 D	PLATE, lower diaphragm (PL-4617) (2)
	36 9 LZDA	COVER, bowl (Not Furnished Separately)	17	36 897 D	VALVE (VA46112A)
`		No. 10NF x 1/2" mach. fil-hd. cd-pitd. SCREW (SC24-8CA) (8) No. 10 lock WASHER (WA5-5CA) (8)	18	36 896 D	SEAT, valve (ensign 268-12) No. 10-32Nf x 9/16" fil-hd. cd-pltd. mach. SCREW (SC 1900) (3)
4	37 O I Z D	GASKET, upper diaphragm (ensign 5546)	19	36 895 D	GASKET, valve seat (GA4633)
5	36 909 D	DIAPHRAGM w/GASKET, 37 012 D. upper (DM4655A)	20	36 894 D	BODY, regulator (Not Furnished Separately) No. 10-32NF x 1/2" fil-hd. cd-pitd. mach. SCREW (SG24-8CA) (8)
6	36 907 D	ROD, valve lever push (RD4612A)			No. 10 lock WASHER (WA5-5CA) (8)
7	36 910 D	WIRE, partition plate, locking (W1461)	22	37 00 <b>9</b> D	PLUG, 1/8" balance tube (PG-1082)
8	36 911 D	PLATE, partition (PL467)	23	42 334 D	SCREW w/FLATE, 268 207 Ri diaphragm
9	36 902 D	VALVE w/GASKET, 36 903 D, pilot (VA 4656 A)			(PL 4674A)
		No. $6 \times 7/16$ " fil-hd. cd-pltd. mach. SCREW (3)		118 831	PLUG, 1/8" pipe (PG 1088)
		No. 6 lock WASHER (3)		37 009 D	PLUG, 1/8" pipe (pressure test hole plug) (PG 1082)
10	36 903 D	GASKET, valve lever support (GA 4651)		268 207 R1	PLATE, diaphragm screw head

-33-

-33-

MEMORANDĀ

MEMORANDA

100 1 1 1 1 m

-34-


## FUEL SYSTEM



# FUEL SYSTEM

L PIPING AND CONNECTIONS pefied Petroleum Gas)

FUEL PIPING AND CONNECTIONS - CONTINUED (Liquefied Petroleum Gas)



NO.	L.H. PART HUMBER	DEECR(PTION		
ı	128 067	NIPPLE (3/4 x 1-1/2" pipe)		
2	371 100 R91	REGULATOR ASSEMBLY, fuel (for components see list of parts under details of "Regulator")		
3	371 103 R1 371 104 R1	LINE, regulator to carburetor balance LINE, regulator to carburetor idle		
5 6	19 983 RI 32 468 H	NUT, idle line (regulator end) BODY, idle line (regulator end)		
7 8	86 ZZ4-H 68 134 D	SPACER, fuel regulator (Z) ELBOW, 90° water inlet tube (in regulator)		
9	19 987 R1	NUT, coupling water inlet tube (in regulator) (2)		
10	19 985 Al	NUT, coupling balance line (2)		
11	24 847 H	ELBOW, regulator to carburetor balance line (2)		
12	118 755	ELBOW, 3/8" tube x 1/4" pipe		
<b>)</b>	121 758 144 610	NUT. 3/8" fuel filter tube (2) NIPPLE, 1/2 x 1-3/8" close pipe		

	144	HARTED	STATES	٥F	AMERICA
RINTED	114	DMILED	SIVIED	~	Www wire

NEF. NO.	I. H. PART MUMBER	DESCRIPTION		
15	68 134 D	ELBOW, 90 * water inlet NUT, (in cylinder head)		
16	19 987 RI	TUBE, regulator water inlet (regulator to		
17	371 105 R1	cylinder head)		
18	219 199	PLUG, 1/2" sq-hd. pips		
19	138 105	TEE, 1/2" pips water inlet tube (in cylinder head)		
20	19 502 R1	ELBOW, 45" (in water pump)		
21	142 269	BUSHING, 3/8 x 1/2" reducing pipe (in water		
		bauna)		
22	308 322 R1	BRACKET, fuel filter and voltage regulator		
		mounting		
23	118 755	ELBOW, 3/8" tube x 1/4" pipe (in filter)		
24	346 \$18 R91	FILTER ASSEMBLY (for components see list of parts under details of "Fuel Filter")		
25	371 088 R92	CARBURETOR ASSEMBLY (for components see list of parts under details of "Carburetor")		
26	371 102 R1	HOSE, fuel line		
27	274 085 R91	CLAMP, fuel hose (2)		

### -35-

# FUEL SYSTEM

REF.	I, M. FART	BRECKIPTION
	NUMBER	
NO.	144	

FUEL PIPING AND CONNECTIONS - CONTINUES (Liquefied Petroleum Gas)

z8	188 902 R1	NIPPLE (7/8 x 2-5/16") regulator end fuel
29 30	119 099 19 987 R1	ELBOW, 3/4" x 90° pipe NUT, coupling water outlet (in regulator)
31	31 336 D	GASKET, carburetor (will work tor
32	371 106 R2	Line, regulator water outlet (regulator to water pump)


# FUEL SYSTEM

PET.	I. H. PART	DESCRIPTION
NO.	NUMBER	

FUEL PIPING AND CONNECTIONS - CONTINUES (Liquefied Petroleum Gas)

33	308 335 R11	TUBE w/two NUTS, 121 758 fuel filter to
34 35	188 897 R1 68 134 D 266 199 R1	ELBOW, 7/8 x 1-3/4 x 1-3/8" ELBOW, 90° water outlet tube (in regulator) COYER, fuel pump opening 5/16 x 1/2" hex-bd, cap SCREW (2)
	76 950 RZ 33 700 DA	VALVE, spring retainer (6) WIRE, choke control

FUEL PIPING AND CONNECTIONS - Continued (Natural Gas)



HEF.	I, H. PART Number	DESCRIPTION
1	119 100	ELBOW. 1" × 90" pipe
2 3	127 874 35 816 D	NIPPLE, 1 x 1-1/2" pipe (Z) REGULATOR ASSEMBLY (Model "B" Ensign 5069) fuel (for components see list of parts under details of "Regulator") 5/16 x 3/4" hex-hd. cap SCREW (Z) 5/16" lock WASHER (Z)
4	36 521 D	CONNECTOR, balance tube
5 6	19 983 R1 36 521 D	NUT, coupling balance tube CONNECTOR, idle tube
7	19 983 Rl	NUT, coupling idle tube
8	308 326 R1	TUBE, idle
9	308 327 R1	with F. balance
10	300 52. 10.	NUT. coupling idle tube (furnished with
11		TEE (furnished with CARBORETOR,
12		ELBOW (furnished with CARBURETOR, 309 592 R91)
13	277 016 RI	5TUD, carbureter (2) (Used w/CARBURETOR. 309 592 R91)


REF. NO.	I, N. FART NUMBER	DESCRIPTION
13	12 215 D	STUD. carburetor (2) (Used w/CARBURETOR 371 088 R92) 3/8" NUT (2) 3/8" lock WASHER (2)
14	309 59Z R91	CARBURETOR (Model 1-1/4" X G) (Ensign X C 9174) (Service parts will be furnished in next revision of this catalog) (order
14	371 088 R9Z	CARBURETOR W/BLEED SCREW, 268 169 RI (Model CBX-125-A-136) (American Bosch Arma Corp) (for components see list of part)
		under "CARBURETOR") (WILL WORK 104
15	268 169 R1	SCREW, bleed (Used with CARBURETON, 371 088 R92)
	308 325 R1	BRACKET, fuel regulator support 5/16 x 3/4" hex-hd. cap SCREW 5/16" lock WASHER
	31 336 D 76 950 R2	GASKET. carburetor (will work for 21 632 D) VALVE. spring retainer (6)

PRINTED IN UNITED STATES OF AMERICA

8

### FUEL SYSTEM

PIPING AND CONNECTIONS (Combination Natural Gas and Gasoline) C-221 501 to 43020 C-263 501 to 53635



REF, NO.	I, K, PART Humber	PESCRIPTION
1	119 100	ELBOW, I'' x 90° pipe
z	127 874	NIPPLE, 1 x 1-1/2" pipe
3	308 331 R11	BRACKET, fuel regulator mounting 5/16 x 3/4" hex-hd. cap SCREW (2) 5/16" lock WASHER (2)
4	35 816 D	REGULATOR ASSEMBLY (Model "B" Ensign 5069) (for components see list of parts under details of "Regulator") 5/16 x 3/4" hox-hd. cap SCREW (2) 5/16" lock WASHER (2)
5	32 468 H	BODY, balance tube (2)
6	371 215 R1	NUT, coupling balance tube (2)
7	36 521 D	BODY (fuel regulator end)
8	371 215 R1	NUT. coupling idle
9 1 <b>0</b>	308 334 R1 308 333 R1	TUBE, belence TUBE, idle
11	32 468 H	BODY, idle (carburetor end)
12	371 215 R1	NUT, coupling
13	309 593 R91	CARBURETOR ASSEMBLY (Model 1-1/4" KGNI) 3/8NF NUT (2) 3/8" lock WASHER (2)

PRINTED IN UNITED STATES OF AMERICA

3_		
ле.		

## FUEL SYSTEM

DESCRIPTION

(Comb		NNECTIONS - Continued Gas and Gasoline)	
14	171 815 R.I	ELBOW. 3/4 x 1 x 1-3/8 x 90° hose (at carburetor)	
15	274 085 R91	CLAMP, hose (2)	
16	305 836 R1	HOSE, fuel inlet (regulator to carburetor)	
17	171 817 R1	ELBOW, 1 x 1 x 1-3/8" x 90" hose (at regulator)	
	11 177 V	GASKET, strainer cage	* - C.
	36.997 V	GASKET, cover plate	er,
	321 005 R1	GASKET, fuel bowl	en e
	321 006 R1	GASKET, air horn	
. • .:	321 004 R91	PACKAGE, carburetor field service (included Jets. Valves, Pins and Miscellaneous Parts to service CARBURETOR, 309 593 R91)	•
	64 837 D	SEAL, dust	
	76 950 RZ	VALVE, soring rotainer (6)	


P.14/14

## -37-FUEL SYSTEM



# MEMORANDA

FUEL FILTER (Liquefied Petroleum Gas)




Parts without letters after the de indicates the part is used for all assemblies listed below: Letters are used to identify separate filt assemblies.  A 64 147 D FILTER ASSY, fuel (order 346 8 B 346 818 R91 FILTER ASSY, fuel (will work for TOP, filter (order 346 818 R91) CASKET, filler top to filter better	
B 346 818 R91 FILTER ASSY, fuel (will work fo TOP, filler (order 346 818 R91)	iliter s "A" and "B
TOP, filler (order 346 818 R91)	(8 R91)
	r 64 147 D)
2 64 399 D GASKET, filler top to filter botto	
	om
3 64 402 D STUD, filter (Filter A)	
4 64 400 DC ELEMENT. w/GASKET. 64 399 GASKET. 64 401 D ASSY, filter	D and
5 BOWL, filter (order 346 818 R9)	l
6 64 401 D GASKET, filter bowl	
7 64 403 D NUT, filter stud (Filter A)	
8 BOLT, filter bowl (order 346 81 (Filter B)	8 R91)

<u>-38</u>-

# COOLING SYSTEM





NO.	I, R. PART NUMBER	DESGRIPTION	
1	69 676 R1	GASKET, water pump	
2	69 675 R1	PLATE, water pump 1/4 x 1/2" rd-hd. slt. mach. SCREW (cd. or zn-pltd.) (3)	
3	69 674 R1	GASKET, water numb plate	
4	387 931 R1	IMPELLER, water pump (together with SEAL, 265 164 R91, will work for 332 117 R1)	
5	73 Z96 R9Z	SEAL. water pump	
6	318 118 R21	BODY w/two PLUG, 103 868 and PLUG, 143 162 water pump	
7 8	103 868 71 351 R1	PLUG. 1/2" eq.hd CI pipe (3) SLINGER. water numb	
9	ST 680	SHAFT and BEARING w/SLINGER, 71 351 R1, water pump	
10 11 11	102 0 <b>6</b> 9 H 368 501 R2 392 713 R1	RETAINER, bearing HUB, pulley (optional with 392 713 R1) HUB, pulley (optional with 368 501 R2)	
12	601 816 C91	PUMP ASSEMBLY, water  3/8 x 2-1/4" hex-hd. cap SCREW  3/8 x 2-1/2" hex-hd. cap SCREW (2)  3/8" lock WASHER (3)	
13 13	304 435 R1 368 502 R1	PULLEY, water pump (*) PULLEY, water pump (not *) 1/4NF x 1/2" hex-hd cap SCREW (used with HUB, 368 501 &2 and 392 713 R1) (4) 1/4" lock WASHER (4)	
<u></u>	265 164 C91	1/4 x 1/2" hex-hd cap 5CREW (used with HUB, 368 501 R1) (4) RETAINER and SEAL ASSEMBLY, water pump	

I, H. FART NUMBER

143 162

# COOLING SYSTEM

-38-

DESCRIPTION

WATE	R PUMP, THERM	IOSTAT AND RELATED P	ARTS — CONTINUED
15	169 193 R1	NIPPLE, water by-pai	98 (2)
16	240 369 R91	CLAMP, hose (2)	
17	169 192 R1	ELBOW, water by-par	18
18	108 120 R91	THERMOSTAT. 167-1	72 degree opening
19	368 505 R1	GASKET, water outle	e em
<b>20</b>	368 504 R1	OUTLET. water 7/16 x 1-1/4" hex- 7/16 x 2-1/2" hex- 7/16" lock WASHE	hd. cap SCREW
	salita di Salita	V 10" MOZ WILLIAM	
:	374 544 R93	PACKAGE, field services (Composed of - 1 GASKET 1 GASKET 1 IMPELLES 1 RETAINER 1 RETAINER SEAL 1 SEAL	69 674 R1 69 676 RI 387 931 R1 102 069 H

SEAL SEAL SHAFT and

BEARING PLUG, 3/8" sq-soc-hd pipe

5T-680)

(\*) - Used With Hydraulic Pump


PRINTED IN UNITED STATES OF AMERICA

(REV. NO. 1 19-44)

# Ô

# LUBRICATION SYSTEM

### CRANKCASE OIL PAN AND OIL PUMP



REF. I.H. PART DESCRIPTION NO. HUMBER		DESCRIPTION	
١,	230 421 R91	PUMP ASSEMBLY, oil (less screen) (will work for 367 811 R91) (Composed of - § 1 BODY	
		1 COVER 169 679 RI	
		1 GASKET 69 607 R1	
		I GEAR 69 608 RI	
		1 GEAR 227 713 R1	
		1 KEY 103 905 1 PIN 112 011	
		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
		1 SHAFT 35 647 H	
		GEAR 230 409 R91)	
		5/16 x 1" hex-hd cap SCREW (2)	
		5/16" lock WASHER (2)	
2	69 608 RI	GEAR, oil pump drive	
3	69 606 R11	SHAFT w/GEAR, oil pump drive C-263 501 to 15879 C-221 501 to 14944	
3	230 409 R91	SHAFT w/GEAR, oil pump drive C-263 15880 Up C-221 14945 Up	
4.	169 <b>240</b> RI	"O" RING, $3/32 \times 9/16 \times 3/4$ " oil pump screen	
5	367 812 R91	SCREEN, oil pump 1/8 x 1-1/4" cottor PIN (phosphate coated)	
6	369 984 R1	GASKET, crankcase pan	
7	114 869 R1	REINFORCEMENT, crankcase oil pan C-263 501 to 14924 C-221 501 to 14469	
8	367 575 R92	PAN ASSY w/GASKET, 3 405 H and PLUG. 41 300 HA, grankcase oil	
9	41 300 HA	PLUG. crankcase oil pan drain (optional with 359 875 R1)	
9	359 875 Ri	PLUG, crankcase oil pan drain (optional with 41 300 HA)	
10	3 405 H	GASKET, oil pan drain plug	


# LUBRICATION SYSTEM

NO.	I, H, PART NUMBER	DESCRIPTION
ÇRANI	KCASE OIL PAN	AND OIL PUMP - CONTINUED
11		SCREW, 5/16 x 3/4" hex-hd cap (25) 5/16" lock WASHER (20) 11/32 x 11/16" x 16 ga. WASHER (5)
12	16 <b>9</b> 679 R1	COVER, oil pump body 5/16 x 1" hex-hd cap SCREW (4) 5/16" lock WASHER (4)
13	69 607 R1	GASKET, oil pump cover
14	35 631 H	GEAR, pump body driven G-263 501 to 15879 G-2Z1 501 to 14944
14	277 713 RI	C-ZZF 19979 OP
15	35 647 H	SHAFT, idler gear
16	103 905	KEY, oil pump drive gear (Woodruff No. 5)
17	112 011	PIN, 1/8 x 7/8" square end straight
18	312 157 R91	SUPPORT ASSY, oil pump shaft (will work for 278 375 R91) C-221 50kto,43020
		C-263 501 to 56635  (Composed of - 21 FITTING 21 226 1 HOUSING 312 158 Rt 1 PLATE 312 162 Rt 1 PLUG 172 557
		1 PLUG 369 013 R91 1 SHAFT 3FZ.159 R11 )
19	271 284	FITTING, lubrication (Alemite No. 1612B) (optional with 109 460)  C-221 501 to 43020  C-263 501 to 56635
19	109 460	FITTING, lubrication (Lincoln No. 5300) (optional with 271 284) C-221 501 to 43020 C-263 501 to 56635
20	369 013 R1	PLUG, distributor housing G-221 501 to 43020 G-263 501 to 56635
Zī	312 162 R1	FLATE, thrust
		G-221 501 to 43020 G-263 501 to 56635
22	312 159 R11	SHAFT w/GEAR and WATER, support G-221, 50% to 43020 G-263 501 to 56635
23	31Z 158 RI	HOUSING, cil pump shaft support C-221 501 to 43020 C-263 501 to 56635
	¥ \$	
	353 937 R1	CLAMP, oil pump shaft support (used with SUPPORT, 278 375 R91) (2) 5/16 x 7/8" hex-bd cap SCREW (2) 5/16" lock WASHER (2)
	353 936 R2	GASKET, oil pump shaft support (used with SUPPORT, 278 375 R91)
	143 992	PLUG. 1/4" stl-hd pipe
	172 577	PLUG. 1-3/16" x .083" housing expansion C-221 501 to 43020 C-263 501 to 56635
		§ - Not Furnished Separately

# -40 -

LUBRICATION SYSTEM

OIL FILTER C-221 501 to 43020 C-263 501 to 56635



# LUBRICATION SYSTEM

-40-

REF.	I. H. PART Number	DESGRIPTION
AU EU	_TER - CONTINU	
C-221	501 to 43020	••
C-263	501 to 56635	
	371 236 R91	FILTER ASSEMBLY, oil (consists of the following parts)
1	304 005 R91	TUBE w/PIN, 17 141 RI. SPRING, 304 009 RI and VALVE. 304 008 RI. oil filter center
Z	17 141 R1	PIN. by-pass valve and spring retainer (5/3Z x 1" Esna)
3	304 008 R1	VALVE, oil filter by-pass
4	304 009 R1	SPRING. oil filter by-pass valve
5	320 273 R91	PACKAGE, oil filter center tube
6		PIN, 1/16 x 1-1/16" cotter
7	303 998 R1	CASE, oil filter
8	304 011 R1	SPRING, oil filter element retaining
9	304 010 R1	WASHER, oil filter element retaining spring
10	304 854 R1	GASKET, oil filter case (will work for 193 527 R1)
11	323 827 R91	PACKAGE, oil filter element
12	61 Z61 VA	VALVE, oil pressure relief
13	49 946 HA	SPRING, oil pressure relief valve
14	3 405 H	GASKET, oil pressure relief valve cap
15	61 263 VA	CAF, oil pressure relief valve
16	371 Z37 R11	BASE ASSEMBLY, oil filter (Composed of - § 1 BASE 1 CAP 61 263 VA 1 GASKET 3 405 H 1 PLUG 17 191 R1 1 5FRING 49 946 HA 1 VALVE 61 261 VA) 5/16 x 1-5/8" hex-hd cap SCREW 7/16 x 1" hex-hd cap SCREW 7/16 x 1-1/4" hex-hd cap SCREW 7/16 x 2-3/4" hex-hd cap SCREW 7/16 x 2-3/4" hex-hd cap SCREW 5/16" lock WASHER (2)
17	349 364 R1	GASKET, oil filter base (not furnished as part of 371 236 R91)

§ - Not Furnished Separately.

17 191 R1 PLUG, 1/4" hex-hd pipe drain

DESCRIPTION

REP. NO.


I.H.PART

LUBRICATION SYSTEM

# -41-

# LUBRICATION SYSTEM

OIL FILTER C-ZZ1 430Z1 Up C-263 56636 Up



5	384 535 R1	GROMMET, element retaining washer
6	384 533 R91	RETAINER ASSY, clement (consists of GROMMET, 384 535 R1, SPRING, 384 536 R1 and WASHER)
7	279 994 R91	ELEMENT, oil filter
8	304 854 RI	GASKET, oil filter case
9	303 322 R1	RING. snap
10	384 525 R1	SPRING, check valve
11	384 5Z8 K1	VALVE, lubricating oil filter base (3)
12	384 523 R12	BASE ASSY, oil filter  (Composed of -  § 1 BASE  1 PLUG 397 299 R1  3 RING 303 32Z R1  1 SPRING 384 525 R1  1 SPRING 384 526 R1  1 SPRING 384 527 R1  3 VALVE 384 528 R1 )  5/16 x 1-1/2" hex-hd cap SCREW (2)  7/16 x 1-1/2" hex-hd cap SCREW  5/16 x 1-1/2" hex-hd cap SCREW  5/16 x 1-1/2" hex-hd cap SCREW
13	397 299 R1	PLUG, oil filter base (will work for 444 61
14	384 526 R1	SPRING, pressure regulating
15	384 527 R1	SPRING, element by-pass
16	384 537 K2	GASKET, oil filter base

NEF.	I, R. PART NUMBER	DESCRIPTION	
	384 522 R9Z	FILTER ASSY, oil  (Composed of -  1 BASE 384 523 R12  1 CASE 384 529 R1  1 ELEMENT 279 994 R91  1 GASKET 304 854 R1  1 GASKET 364 532 R1  1 RETAINER 384 533 R91  1 TUB£ 384 530 R11 )	
l	384 530 R11	TUBE, oil filter center	
2	384 532 R1	GASKET, center tube	
3	384 529 R1	CASE, lubricating oil filter	
4	384 536 R1	SPRING, element hold-down	

§ - Not Furnished Separately

PRINTED IN UNITED STATES OF AMERICA

(RRV, NO. 1 10-66)

ार नहेंचा बन्दा अवस्थित है

-42-

# MISCELLANEOUS

I, H, PART NUMBER DESCRIPTION

-	L		
	<b>N</b>		
Ì	~	GASKET	
,	1K ( CD	CASKEL	2512
	ne)		
٠			

384 535 R1 352 221 R1

103 364

310 665 R1

352 221 R1



### MISCELLANEOUS

REP. NO.	I, H, PART Number	DESCRIPTION	
		THE ANI	

### PRODUCT GRAPHICS

	•		
372 770 R93	GASKET SET, valve grinding includes 8 gaskets as follows -		The following identification and instructional Product Graphics are available for the
31 336 D	GASKET, carburetor		UC-221 and UC-263 Engines:
164 418 R1	GASKET, cylinder head	2 752 477 R1	PRODUCT GRAPHIC, air cleaner instructions (for units painted other than Red)
69 752 R1	GASKET, intake and exhaust manifold	Z 75Z 478 RI	PRODUCT GRAPHIC, air cleaner instructions (for units painted red)
85 868 R1	GASKET, intake to exhaust manifold		
369 983 RI	GASKET, valve cover	2 751 188 R1	PRODUCT GRAPHIC, air cleaner instructions (for units painted other than Red)
368 505 R1	GASKET, water outlet	Z 75Z 141 R1	PRODUCT GRAPHIC, air cleaner instructions (for units painted red)
164 420 R1	GROMMET, valve cover		
111 024 RI	SEAL, intake valve stem	1 001 071 RZ	PRODUCT GRAPHIC, generator warning
866 834 RI	DEFLECTOR, intake and exhaust valve stem oil	Z 75Z 048 R1	PRODUCT GRAPHIC, engine shut-down (for units painted other than Red)
381 737 R92	GASKET SET, engine includes 21 gaskets as follows - (together with 372 770 R93 will	2 752 049 R1	PRODUCT GRAPHIC, engine shut-down (for units painted red)
369 981 R1	work for GASKET SET 372 771 R91)	2 751 259 R1	PRODUCT GRAPHIC, "International" (2 for units painted other than Red)
	GASKET, breather pipe	2 751 272 R1	PRODUCT GRAPHIC, "International" (Z for
378 237 R1	GASKET, crankcase front cover		units painted red)
367 574 R1 367 570 R1	GASKET, crankcase front cover GASKET, crankcase front plate	2 75 <b>2 149 R</b> 1	PRODUCT GRAPHIC, "I.H.C. of Canada" (for units painted other than Red)
307 310 KI	Cubrent, Claurespe Hour bists	2 752 150 R1	PRODUCT GRAPHIC, "I.H.C. of Canada"
369 984 R1	GASKET, crankcase pan		(for units painted red)
353 936 R2	GASKET, distributor	2 751 533 R1	PRODUCT GRAPHIC. flo-matic (for units painted other than Red)
42 965 V	GASKET, filter drain plug	2 751 534 R1	PRODUCT GRAPHIC, flo-matic (for units
612 293 C1	GASKET, fuel pump		painted Red)
367 669 R1	GASKET, governor housing	2 752 445 R1	PRODUCT GRAPHIC, control switch escutcheon
371 238 R.I	GASKET, oil filter base		
304 854 R1	GASKET, oil filter case	2 753 190 R1	PRODUCT GRAPHIC, "Made in the United States of America"
384 532 RI	GASKET, oil filter center tube	2 751 469 RI	PRODUCT GRAPHIC. model symbol "UG-221" (2 for units painted red)
3 405 H	GASKET, oil pan drain plug	2 751 470 Ri	
3 405 H	GASKET, oil pressure relief valve cap	2 /31 4/0 R1	PRODUCT GRAPHIC, model symbol "UC-221" (2 for units painted other than Red)
69 607 RI	GASKET, oil pump cover (2)	2 751 475 R1	PRODUCT GRAPHIC, model symbol "UC-263"
369 982 R1	GASKET, valve push rod cover		(Z for units painted red)
69 674 RI	GASKET, water pump plate	2 751 476 RI	PRODUCT GRAPHIC, model symbol "UC-263" (2 for units painted other than Red)
69 676 R1	GASKET, water pump	2 751 144 R1	PRODUCT GRAPHIC, oil filter instructions

PRINTED IN UNITED STATES OF AMERICA

GROMMET, element retainer washer

"O" RING, oil pump screen seal 320 273 R91 PACKAGE, oil filter center tube gasket PIN, retaining spring washer 1/16 x 1-1/4" cotter PIN

PLUG. rear bearing cap (2)

SEAL, oil pump screen "O" ring


PRINTED IN UNITED STATES OF AMERICA

(REV, NO. 1 (0-44)

### -43-ET ECTRICAT.

ELECTRICAL SYSTEM

SPARK PLUGS, COIL, CABLES AND DISTRIBUTOR (Battery Ignition)



REF. NO.	I. H. PART NUMBER	DESCRIPTION
ł	66 711 R92	CABLE, coil to distributor (high tension) (for use with COIL, Delco-Remy No. 1115098)
ı	318 437 R91	CABLE, coil to distributor (high tension) (for use with COIL, Delco-Remy No. [115082]
2	312 118 R11	BRACKET, ignition coil (for use with COIL, Delco-Remy No. 1115098) 5/16 x 5/8" hex-hd cap SCREW (2) 5/16" lock WASHER (2) 11/32" copper WASHER (2) 7/16 x 1/2" hex-hd cap SCREW (3) (a**sembled in left front of cylinder head) 15/32" copper WASHER (3) (a**sembled in left front of cylinder head)
2	370 534 R11	BRACKET, ignition coil (for use with COIL.  Delco-Remy No. 1115082)  7/16 x 1/2" hex-hd cap SCREW (2)  7/16 x 7/8" hex-hd cap SCREW (2)  7/16" lock WASHER (2) (assembled in left front of cylinder head)  15/32" lock WASHER (2) (assembled in left front of cylinder)
3		COIL, ignition (Delco-Remy No. 1115082) No. 10NF cd-pltd NUT (2) 5/16 x 1/2" hex-hd cap SCREW (2) No. 10 cd-pltd lock WASHER (Z) 11/32 x 11/16" x 16 ga. WASHER
3		(1/32 x 11/16 to get 10
4		RESISTOR, ignition coil (Delco-Remy No. 1957154) (together with SPACER, 31 987 D, will work for resistor, Delco-Remy No. 1928016)
5	370 594 R91	CABLE, coil to resistor

ELECTRICAL SYSTEM

NGF.	L.H. FART Number	DESCRIPTION
SPARK (Batte)	(PLUGS, COIL. ry Ignition)	CABLES AND DISTRIBUTOR - CONTINUES
6	69 700 R91	CABLE, coil to distributor primary (for use
6	368 267 R91	with COIL, Delco-Remy No. 1115098) CABLE, coil to distributor primary (for use with COIL, Delco-Remy No. 1115082)
7	312 354 R91	CABLE, spark plug (No. 1 and 6) (Z)
8	266 Z63 R91	CABLE, spark plug (No. 2 and 5) (2)
9		SPARK PLUG (Champion D-182) (light or moderate service) (*) (6)
9		SPARK PLUG. (Prestoute to-ocy (man vi
9		spark PLUG, (Champion D-16) (intermediate service)* (6)
9		SPARK PLUG, (Prestolite 18-81) (intermediate service)* (6)
9		service)* (6) SPARK PLUG. (Champion 8 com.) (normal service)* (6)
9		SPARK PLUG, (AC-85) (normal service)* (6)
9		SPARK PLUG, (Auto-Lite BT-8) (normal service)* (6)
9		SPARK PLUG. (Prestolite 18-8) (mormal service)* (6)
9		SPARK PLUG. (Champion D-9) (severe service)* (6)
9		SPARK PLUG. (AC-C\$3) (severe service)* (6)
9		SPARK PLUG w/GASKET, 37 762 H (normal service) (Champion D-15Y) (6) %
9		SPARK PLUG. (Auto-Lite BT-4) (severe service)* (6)
9		SPARK PLUG, (Prestolite 18-3) (severe service) + (6)
9		SPARK PLUG, (Champion D-6) (extreme
9		SPARK PLUG, (AC-C81) (extreme severe service)* (6)
9		SPARK PLUG, (Auto-Lite BT-3) (extreme severe service)* (6)
9		SPARK PLUG. (Prestolite 18-2) (extreme severe service) # (6)
10	37 762 H	GASKET, spark plug (6)
11	318 <b>0</b> 56 R91	
12		DISTRIBUTOR ASSEMBLY (for components see list of parts under details of "Distributo
13	353 936 RZ	GASKET, distributor
14	353 937 R1	GLAMP, distributor (2) 5/16 x 7/8" hex-bd cap SCREW (2) 5/16" lock WASHER (2)
15	370 535 R1	CLIP, coil to distributor cable (for use with COIL, 11(508Z)
	324 460 R1	RETAINER, spark plug wire (2)
	31 987 D	SPACER (For use with registor Delco- Remy No. 1957154 only)
		<ul> <li>(*) - For Use With Gasoline And Combinatio Gas Or Gasoline Engines.</li> <li>(%) - For Use With Natural Gas And Liquefied Petvoleum Gas Engines.</li> </ul>

-44-


#### ELECTRICAL SYSTEM



#### ELECTRICAL SYSTEM

K PLUGS AND CABLES cto ignition) 501 to 43020 501 to 56635

SPARK PLUGS AND CABLES - CONTINUES (Magneto Ignition) C-221 501 to 43020 C-263 501 to 56635



REF. NO.	I. H. PART NUMBER	QESCRIPTION.	REF. NO.	I. H. PART NUMBER	SESTRIPTION OF S
1		SPARK PLUG (Champion D-23) (light or moderate service) (*) (6)	1		SPARK PLUG (Auto-Lite BT -3) (extreme severe service) (*) (6)
I		SPARK PLUG (AC-88S com.) (light or moderate service) (*) (6)	1		5PARK PLUG (B.G. Corp RB-485) (long life) (%) (6)
1		SPARK PLUG (Auto-Lite BT -10) (light or moderate service) (*) (6)	1		SPARK PLUG (Champion D-6) (long life) (%) (6)
		SPARK PLUG (Champion D-16) (intermediate service) (*) (6)	ı		SPARK PLUG (AC-C-81) (long life) (%) (6)
		SPARK PLUG (Champion 8 com.) (normal service) (*) (6)	1		SPARK PLUG (Auto-Lite BT-3) (long life) (%) (6)
		SPARK PLUG (AC-85S) (normal service) (*)	2	37 762 H	GASKET, spark plug (6)
		(6)	3	310 964 R91	CABLE, magneto high tension (cylinder No. 1)
1		SPARK PLUG (Auto-Lite BT-8) (normal service) (*) (6)	4	310 965 R91	CABLE, magneto high tension (cylinder No. 2)
1		5PARK PLUG (Champion 5 com.) (severe service) (*) (6)	5	310 966 R91	CABLE, magneto high tension (cylinder, No. 3)
1		SPARK PLUG (AC-835 com.) (severe service) (*) (6)	6	310 967 R91	CABLE, magneto high tension (cylinder No. 4)
ì		SPARK PLUG (Auto-Lite BT-4) (severe service) (*) (6)	7	310 968 R91	CABLE, magneto high tension (cylinder No. 5)
1		SPARK PLUG (Champion 4 com.) (extreme severe service) (*) (6)	8	310 969 R91	CABLE, magneto high tension (cylinder No. 6)
.1		SPARK PLUG (AC-81S com.) (extreme service) (*) (6)	9	308 579 F.1	SLIP, spark plug cable (2) 5/16 x 5/8" hex-hd cap SCREW 5/16" lock WASHER

 <sup>(\*) -</sup> For Use With Gasoline And Combination Gas Or Gasoline Engines.
 (%) - For Use With Natural Gas And Liquefied Petroleum Gas Engines.

-45-

\_

# ELECTRICAL SYSTEM


EL

Ĥ

DISTRIBUTOR

ELECTRICAL SYSTEM

DISTRIBUTOR ... CONTINUES



REF. NO.	I.H.PART Humber	DESCRIPTION	MO.	J. H. PART NUMBER	DESCRIPTION (
	367 839 R92	DISTRIBUTOR ASSY (order 372 867 R92) C-221 501 to 43020 C-263 501 to 56635	13	353 920 R1	GUARD, governor weight  No. 8 x 3/16" slt-fil-hd. mach. SCREW (2) No. 8 lock WASHER (2)
	372 867 R92	DISTRIBUTOR ASSY (will work for 367 839 R92)	14	353 917 R91	ARM, weight (2)
		C-22I 501 to 43020 C-263 501 to 56635	15	356 192 R91	CAM
	383 177 R91	DISTRIBUTOR ASSY C-221 43021 Up	16	368 10Z R91	SPRING, governor (set of two) (used with DISTRIBUTOR, 367 839 R92)
	388 592 R91	DISTRIBUTOR ASSY C-263 56636 Up	16	373 331 R91	SPRING, governor (set of two) (used with DISTRIBUTOR, 372 867 R92)
I	368 062 R91	CAP, distributor	16	373 963 R91	SPRING, governor (set of two) (used with DISTRIBUTOR, 388 592 R91)
2	353 896 R91	ROTOR, distributor	16	372 963 R91	SPRING, governor (set of two) (used with DISTRIBUTOR, 383 177 R91)
3	353 901 RZ	SEAL. breaker cover felt	17	352 293 R1	SPACER, weight arm (4)
4	384 830 R1	GASKET, cover	18	368 059 R91	SHAFT, distributor (used with DISTRIBUTOR, 367 839 R92 and 372 867 R92)
5	384 831 RII	COVER w/SEAL, 353 901 RZ and GASKET, 384 830 R1, BREAKER	18	388 593 R9I	SHAFT, distributor (used with DISTRIBUTOR, 388 592 R91)
6 7	353 903 R92 353 905 R1	CONDENSER CLAMP, condenser	18	383 178 R9}	SHAFT, distributor (used with DISTRIBUTOR, 383 177 R91)
		No. 8 x 3/16" slt-fil-hd. mach. \$CREW No. 8 lock WASHER	19	368 096 R1	SPRING, distributor cap (2)
8	353 172 R91	POINT SET, breaker arm and stationary (used with DISTRIBUTOR, 367 839 R92)	20	353 895 R1	SUPPORT. distributor can spring (2) No. 8 x 3/8" sit-rd-hd. mach. SCREW (2) No. 8 lock WASHER (2)
8	37Z 951 R91	POINT SET, breaker arm and stationary (used with DISTRIBUTOR, 372 867 R92, 383 177 R91 and 388 592 R91) No. 8 x 3/16" sit-pan-hd mach SCREW	21	369 013 R1	PLUG, distributor housing (not used with TACHOURMETER ATTACMENT)
	21 394 D	WASHER, stationary point terminal	22	368 054 R1	WASHER. distributor thrust lower
9	353 907 R1	SCREW, terminal	23	368 053 R1	COLLAR, distributor shaft
10	353 906 R1	iNSULATOR, spring anchor terminal	24	354 552 R1	PIN, distributor shaft collar
11	251 538 R.I	WASHER, terminal insulating	25	368 057 R91	OIL SEAL, distributor shaft
	251 550 KI	No. 8 type "F" NUT (3) No. 8 lock WASHER (3)	26	368 055 R1	WASHER, distributor thrust upper
12	352 277 R11	PLATE, breaker (used with DISTRIBUTOR, 367 839 R92)	27	368 051 R11	HOUSING w/WASHER, 368 055 R!, and OIL 5EAL, 368 057 R9!, distributor
12	372 868 R11	PLATE, breaker (used with DISTRIBUTOR,			PLUG. 1/8" sit-hdis. pipe
		372 867 R92, 383 177 R91 and 388 592 R91) No. 8 x 3/5" rd-hd slt-mach SCREW		355 460 R1	FELT, cam oil hole
		No. 8 lock WASHER		41 372 D	TUBE. of distributor grease



The state of the s


#### ELECTRICAL SYSTEM


ů

#### ELECTRICAL SYSTEM

CRANKING MOTOR

CRANKING MOTOR - Continued (Delco-Remy)





NEF, NO.	NUMBER	DESCRIPTION
	1107350	MOTOR ASSY, cranking 3/8" NUT No. 8 NUT No. 10NF NUT 3/8 x 1-1/4" hex-hd cap SCREW (3) 3/8" (cd or zn-pitd) lock WASHER No. 8 (cd or zn-pitd) lock WASHER No. 10 (cd or zn-pitd) lock WASHER
Į		SCREW, No. 10NF x 7/16" slt-rd-hd (2)
Ż	1923935	WASHER, cover attaching screw (2)
3	1949653	SCREW, field lead attaching
4		NUT, No. iONF ("R" terminal) (2)
5		WASHER. No. 10 internal lock
6	1946143	WASHER, lock
		NUT, 3/8" (2)

NÇ.	• • • • • • • • • • • • • • • • • • • •			
	1042575	A CONTRACTOR		
10 11	1963525 1950070	COVER, switch INSULATOR, cover		
12	185334Z	SPRING. contact return		
13	1935645	CONTACT ("R" terminal)		
14	1950069	STUD ("R" terminal) No. 10NF		
15	1956226	CONTACT w/PUSH ROD		
16	1950120	STUD. 3/8" terminal		
17		Not Furnished Separately		
18	1949538	CLIF ("S" terminal)		
19	1950069	STUD ("5" terminal)		
21		NUT. No. 10NF ("5" terminal) (2)		
22	1946143	WASHER, lock		
Alway	s Give CRANE	UNG MOTOR NUMBER When Ordering Parts.		

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

-47-

# -47-ELECTRICAL SYSTEM

*	2	
	Ţ	

### ELECTRICAL SYSTEM

REF.	NUMBER	DESCRIPTION	NO.	NUMBER	DESCRIPT	10N
CRANKING MOTOR - Continues (Delco-Remy)			CRANKING MOTOR — Continues (Delco-Remy)			
23	1904419	NUT, 3/8" (2)	64	1926648	SCREW, brush attachin	ıg (4)
24		WASHER, 3/8" lock	65	1928966	FRAME, commutator	end.
25	1950061	STUD, 3/8" terminal	66	1935168	GROMMET, lead (in fi	eld frame)
26	·	SCREW, 1/4 x 1/2" slt-rd-hd (2)	67	37521	RING, snap	Charles The second se
27		WASHER, 1/4" lock (2)	68	1838436	COLLAR, motor drive	A CARLONS
28	1114356	SWITCH ASSY	69	1931477	SPR NG, motor drive	
29	1958679	SPRING, plunger return	70	· ·	GEAR (Not Furnished	Separately)
30	1953041	PLUNGER, solenoid switch	71	1873796	BUSHING, oilless	
31	1932205	LEVER, shift		820148	BUSHING, center bear	
32	455106	PIN, shift lever		1952427	GASKET (between swit	2.745 Ball Co. 100 Co.
33	1932197	STUD, shift lever		8Z0149	PLATE, center bearing	
34	1950306	HOUSING w/BUSHING, 1862383, drive			PLUG. 1/8" pipe (driv	1 <u>2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2</u>
	1862383	RUSHING, drive end		125547	WASHER (between cen	The state of the s
35	1926640	NUT, shift lever stud		821 453	drive)	The second second
36	•	WASHER, 5/16" lock		1909560	WICK (drive end)	<b>K</b>
37	1838568	COLLAR, drive end spacing				
38	1928021	RING, pinion stop retainer snap (drive end)			•	- \$\frac{1}{2}\delta \frac{1}{2}\delta \frac{1}
39	1928022	COLLAR, pinion stop (drive end)				•
40	809593	PIN, dowel (drive end)				
41	1946220	DRIVE ASSY, motor				
43	1950307	ARMATURE				
44	833602	WASHER, commutator end spacing				1 to <del>1</del> 11 .
45	1927853	INSULATION, field coil (4)				4 ( 4 ( )
46	1913960	SCREW, pole shoe (4)				
47	1926616	SHOE, pole (4)				
48	1935131	COIL, field shunt				

Always Give CRANKING MOTOR NUMBER When Ordering Parts.

COIL, field (3 coils)

PIN, support attaching (2)

LEAD, brush ground (2)

NUT, No. 10 (4)

BOLT, thru (2)

BRU5H (4)

SPRING, brush (2)

WASHER, No. 10 lock (4)

KIT. brush holder support (2)

HOLDER, brush insulated (2)

HOLDER, brush ground (2)

WASHER, lock (center bearing attaching) (Z)

SCREW, center bearing attaching (2)

SCREW, No. 11 x 1/2" slt-truss-hd (4)

SUPPORT (Not Furnished Separately)

1935128

1962276

132 900

1926600

1926605

1928015

1939970

1926622

1926618

1926617

1906945

49

50

51

52

53

54

55

56

57

58

59

60

61

62


6.3

DESCRIPTION

# ů

#### ELECTRICAL SYSTEM

GENERATOR, VOLTAGE REGULATOR AND CONNECTIONS



REF. NO.	), H. PART Number	DESGRIPTION
I.		GENERATOR ASSEMBLY (Deico-Remy No. 1102034) (12 volt) (for components see list of parts under details of "Generator") (*
2	312 514 R1	BRACE, generator adjusting (*) 7/16 x 1-1/8" hex-hd cap SCREW 7/16" lock WASHER
2	312 068 R1 61 252 H	STRAP, generator adjusting (not *) SPACER, generator adjusting 7/16 x 3/4" hex-hd cap SCREW 7/16" lock WASHER
3		REGULATOR, voltage (Delco-Remy No. 1[1899) (12 volt) (for components see hist of parts under details of "Voltage Regulator" 1/4NF NUT (2) 1/4NF x 3/4" hex-hd cap SCREW (2) 1/4" lock WASHER (2)
4		FAN, generator (Delco-Remy No. 1944437)
6		PULLEY, generator (Delco-Remy No. 1946716)
7	315 722 R1	BRACKET, regulator (*) 1/2 x 1-3/8" hex-hd cap SCREW (2) 1/2" lock WASHER (2)
7	312 069 R1 277 006 R1	BRACKET, voltage regulator (not *) SPACER, voltage regulator 1/2 x 1-1/4" hex-hd cap SCREW 5/8 x 3/4" hex-hd cap SCREW 1/2" lock WASHER 5/8" lock WASHER
8	367 661 R1	BRACKET, generator (not *) 5/16 x 1" hex-hd cap SCREW (Z) 5/16" lock WASHER (2)
8	318 024 RI	BRACKET, rear generator (*) 5/16 x 1" hex-hd cap SCREW 5/16" lock WASHER

#### ELECTRICAL SYSTEM

GENERATOR, VOLTAGE REGULATOR AND

CON	NECTIONS - Com	TINUED
9	316 250 R1	BELT, water pump and generator fan (not *)
9	312 515 R1	BELT, fan (*)
10		WASHER, generator drive shaft lock
11		NUT, generator drive shaft
	318 434 R91	ATTACHMENT, generator and regulator (for use with hydraulic pump) (see NOTES 1 and 3)  (Consists of -  1 BRACKET 315 722 R1  1 BRACE 312 514 R1  1 BRACKET 318 024 Rt  1 CLIP 263 515 R1  1 FAN 312 515 R9:  1 FAN (Delco- Remy No. 1944437)  1 GENERATOR (Deico-Remy No. 1102034)  1 HARNESS 265 191 R91  1 PULLEY (Delco- Remy No. 1946716)  2 REGULATOR (Delco- Remy No. 1118999)
	263 515 R91	CLIP, harness

265 191 R91 HARNESS, generator to regulator

(\*) - Used On Units Equipped With Hydraulic Pump.

NOTE ! - Factory Application - Order On Machine Order Form.

NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

## ELECTRICAL SYSTEM

-49-

GENERATOR - CONTINUED

#### ELECTRICAL SYSTEM

REF.	DELCO-REMY	DESCRIPTION
NO.	NUMBER	
MU.	NOMBER -	

GENERATOR (Part of ATTACHMENT, 318 434 R91) (Delco-Remy) (12 Volt) (Used with Hydraulic Pump)

33 33 33 33 33 33 33 33 33 33 33 33 33	21 22 23 24 25 20 20 20 20 20 20 20 20 20 20 20 20 20
	IPA-60101

RET. NO.	OR CO-SEMY NUMBER	DESCRIPTION
	1102034	GENERATOR ASSY (1Z volt) 5/16" NUT 5/16 x 3/4" hex-hd cap SCREW 5/16 x 1" hex-hd cap SCREW 5/16 x 1-1/4" hex-hd cap SCREW 5/16" lock WASHER (3) 11/32 x 11/16" x 16 ga. WASHER (2)
1	125 609	Oiler, commutator end
4	1925204	FRAME, commutator end
3	904751	BEARING, commutator end ball
4	1929959	RING, commutator end bearing
5	1923295	BRUSH (2) No. 6 x 1/4" rd-hd cap SCREW
	1904377	WASHER, lock
6	1978183	ARM, brush (3)
7	1908829	SPRING, brush (2)
8	1857414	WASHER, space (Z)

(Part of ATTACHMENT, 318 434 R91) (Delco-Remy) (12 Volt) (Used with Hydraulic Pump) HOLDER, ground brush (package) 1964488 9 STUD, "F" terminal 1921860 10 BUSHING, insulating ("F" terminal) 1885090 . 1 WASHER, insulating ("F" terminal) 1858753 12 WASHER, terminal stud lock (4) 1904661 NUT. No. 12 (4) 1881409 WASHER, flat (2) 15 COIL, field 1922701 16 WASHER, 1/4" lock 17 5CREW, 1/4 x 3/8" fil-hd sit 6 18 SHOE, pole (Z) 19 1912725 SCREW, pole shoe (2) 1843646 ÷ 100 INSULATOR, field coil 1912073 20 WASHER, 5/16" heavy lock (2) 21 BOLT, thru ZZ 809763 OLLER, drive end 125609 23 NOT USED 24 FRAME, drive end 1910404 25 NUT. drive end hex. 806915 26 WASHER, drive end nut lock 804000 KEY, Woodruff, 1/8 x 5/8" 124545 28 COLLAR, spacing 1858603 29 PIN. drive end dowel 809593 30 WASHER, drive end felt 809961 PLATE, drive end felt retainer 819104 3.2 BEARING, drive end ball 954378 33 WASHER, drive end inner space 809945 34 GASKET, bearing retainer الاورون بين المنظم ا المنظم 35 1912008 PLATE, bearing retainer, drive end 1911263 36 SCREW, retainer plate WASHER, lock 1904370 1880781 rafinasia. ARMATURE 1925210 37 CLIP, terminal to brush 200382 38 CASE (Not Furnished Separately) 39 STUD ("A" terminal) 1921369 40 BUSHING, insulating ("A") 1921362 41 HOLDER, insulated brush (package) 192289 44 PIN, commutator end dowel 809062

Always Give GENERATOR NUMBER When Ordering Parts.

PRINTED IN UNITED STATES OF AMERICA

# ELECTRICAL SYSTEM


- 50 -



### ELECTRICAL SYSTEM

ERATOR to-Remy) (Not used with Hydraulic Pump)

GENERATOR - CONTINUED (Delco-Remy) (Not used with Hydraulic Pump)



REF.		DESCRIPTION	REF. NO.	PERSONAL PROPERTY	DESCRIPTION
	KEY TO UNIT:	3	9	1881409	WASHER, terminal stud plain (2)
~					·
A -	1100305	GENERATOR ASSEMBLY (12 volt) (order Delco-Remy No. 1100374)	10	121743	NUT, No. 12 terminai (4)
в.	1100374	GENERATOR ASSEMBLY (12 volt) (will work	11	1921860	STUD. "F" terminal
_		for Delco-Remy No. 1100305) 5/16" NUT	12	1885090	BUSHING. "F" terminal insulating
		5/16 x 1" hex-hd cap SCREW 5/16 x 9/16" hex-hd cap SCREW	13	1858753	WASHER, field terminal stud insulating
		5/16 x 1-1/8" hex-hd cap SCREW 11/32 x 11/16 x No. 16 ga. WASHER	14	1904661	WASHER, terminal stud lock (4)
		5/16" lock WASHER (3)	15	1923625	COIL w/CLIP, 200382, field (Unit A)
			15	1953879	COIL w/CLIP. 20038Z, field (Unit B)
(X) -	the description	se units correspond with those shown following on of the parts in the list below and identifics which the part is used. Items without letters	16	225577	SCREW, field frame ground (Unit B)
		ription indicates the part is used for all units.	17	120380	WASHER, field frame ground lock (Unit B)
1	1939857	FRAME w/OILER, 125609, PIN and 809062, commutator and (Unit B)	18	1843646	SGREW, pole shoe (2)
		,	19	1914618	SHOE, pole (2)
<b>1</b>	1927451	FRAME w/OILER, 1880635, FIN, 809062, and WICK, 804080 (commutator end) (Unit A)	20	1914491	INSULATOR, field coil (2)
Ż	132688	SCREW, brush lead attaching (Z)	21	815018	BOLT, thru (2)
3	1904377	WASHER, brush lead attaching lock (2)	22		WASHER, 5/16", thru bolt, lock
4	1923295	BRUSH w/LEAD	23	[ \$\$0 64 ]	OLLER (drive end)
5	1916324	SPRING, brush (2 for Unit A)	24	124545	KEY, $1/8 \times 5/8$ " (drive end) (Woodruff No. 5)
5	1908829	5PRING, brush (2 for Unit B)	25		WASHER, 5/16", thru bolt lock
6	1878183	ARM, brush (2)	26	806915	NUT, shaft (drive end) (Unit A)
			26	1911324	NUT, shaft (drive end) (Unit B)
7	1904368	WASHER, brush arm space (2 for Unit A)	27	804000	WARTER look /duise and /IInit Al
7	1857412	WASHER, brush arm space (2 for Unit B)	27	1888439	WASHER, shaft nut lock (drive end) (Unit A) WASHER, shaft nut lock (drive end) (Unit B)
	1922288	HOLDER, ground brush	Alway	s Give GENE	RATOR NUMBER When Ordering Parts.

-51-

# Ŝ

## MEMORANDA

# ELECTRICAL SYSTEM

REF.	DELCO-REMY	DESCRIPTION
NO.	NUMBER	

-51-

GENERATOR - Continues (Delco-Remy) (Not used with Hydraulic Pump)

28	1910404	FRAME w/OILER, 1880641 (drive end) (Unit A)
28	1871693	FRAME w/OILER, 1880641 (drive end) (Unit B)
29	809593	PIN, dowel (drive end)
30	1880781	WASHER, retainer plate lock (3)
31	1904370	SCREW, retainer plate (3)
32	Z00382	CLIP, terminal (to brush)
33	1921362	BUSHING, "A" terminal insulating
34	1921369	STUD, "A" terminal
35	1922289	HOLDER, insulated brush
36 36	1880635 125609	OILER (commutator end) (Unit A) OILER (commutator end) (Unit B)
37 37	1946903 817807	ARMATURE ARMATURE
38	1911263	PLATE, retainer (drive end)
39	809945	WASHER, inside space (drive end)
40	954378	BEARING, ball (drive end)
41	819104	PLATE, (elt retainer (drive end)
42	809961	WASHER, felt (drive end)
43	1858603	COLLAR, space (drive end)
44	1912008	GASKET, bearing retainer
	904751	BEARING, ball (commutator end) (Unit B)
	1927448	CUP, felt retainer (commutator end) (Unit A)
	1948326	PLUG, bearing well (commutator end) (Unit B)
	80906Z	PIN, dowei (commutator end)
	1929959	RING, bearing clamp (commutator end) (Unit B)
	192 <b>744</b> 7	WASHER, felt (commutator end) (Unit A)
	804080	WICK, oil (commutator end) (Unit A)
	823551	WICK, oil (drive end)







-52-




# ELECTRICAL SYSTEM



#### ELECTRICAL SYSTEM

VOLTAGE REGULATOR
Delco-Remy)
Part of ATTACHMENT, 318 434 R91)
(For use with Negative Grounded Battery)

VOLTAGE REGULATOR - CONTINUED (Delco-Remy)
(Part of ATTACHMENT, 318 434 R91)
(For use with Negative Grounded Battery)



REF.	Office-nemy				
NO.	NUMBER	DESCRIPTION	NO.	PELGO-MENT NUMBER	PESCRIPTION
	1118999 \	REGULATOR, voltage 1/4NF NUT (2)	12	1944590	SCREW, regulator armature adjusting (2)
		1/4NF x [/2" hex-hd cap SCREW (2) 1/4" lock WASHER (2)	13		NOT USED
⁄سيبية	1927980	COVER	14	1878505	WASHER, regulator contact attaching screw lock (2)
2	1953902	GASKET, cover	ιs	1935031	WASHER, cover screw lock (2)
3	1939646	ARMATURE, relay	16	1924764	SCREW, relay armature attaching (2)
4		NOT USED			
5	1878493	CONTACT and SUPPORT, voitage regulator	17	1878516	SCREW, regulator contact attaching (2)
6	1912176	SPRING, regulator armature (2)	18	1927982	SCREW, cover (2)
7		NOT USED	19	1864099	SCREW, terminal (3)
8	1910174	RESISTOR, "F" terminal to ground	20	1922599	INSULATOR, regulator contact attaching
9		NOT USED			screw (2)
10		NOT USED	21	1878507	WASHER, insulator regulator contact attaching screw (2)
11	1912159	SCREW, adjusting, relay armature	22	1868137	CLAMP. terminal (3)

-53-

# ELECTRICAL SYSTEM


ELECTRICAL SYSTEM

(Delco-Remy) (For use with Positive Grounded Battery)

VOLTAGE REGULATOR

-53-

VOLTAGE REGULATOR - CONTINUED (Delco-Remy) (For use with Positive Grounded Battery)



MEF.	DELEG-REMY	DESCRIPTION	REF. NO.	NUMBER NUMBER	DESCRIPTION
NO.	1118779	REGULATOR, voltage 1/4NF NUT (2)	10	1878505	WASHER, regulator contact attaching screw lock
		1/4NF x 1/2" hex-hd cap SCREW (2) 1/4" lock WASHER (2)	11	1878517	CONTACT and SUPPORT. regulator
ī	1927982	SCREW, cover attaching (2)	12	1878780 454431	ARMATURE, relav SCREW, relay armature (2) WASHER, relay armature attaching
2	1922996	WASHER, insulating cover attaching screw (2)		1904377	screw tock (Z)
3	1927980	COVER	13	1912176	SPRING, regulator armature
4	1927981	GASKET. cover	14	1922408	SCREW. regulator armature adjusting
5	1868137	CLAMP, terminal (4)	ıs	1922599	INSULATOR, regulator contact attaching screw
6	1864099	SCREW. terminal (4)			
7	1878516	SCREW, regulator contact attaching (2)	16	1927975	LEAD, ground
8	1912159	SCREW, adjusting relay armature	17	1910174	RESISTOR. "F" terminal to ground
9	1878507	WASHER, insulating regulator contact attaching screw (2)			

Always give VOLTAGE REGULATOR NUMBER When Ordering Parts.


# ů

# ELECTRICAL SYSTEM

#### ELECTRICAL SYSTEM

CTRIC WIRING
ery Ignition) (For units equipped with Instrument Panel
Archment 305 191 R91 or Automatic Shut-Off Attachment
305 198 R91)

ELECTRIC WIRING - Communico
(Battery Ignition) (For units equipped with Instrument Panel
Attachment 305 191 R91 or Automatic Shut-Off Attachment
305 198 R91)



NO.	I. H. PART Number	DESCRIPTION
1		CABLE, ignition switch to resistor (orange)
1		(order 305 192 R91) (†) CABLE, "C" on relay to resistor (orange) (order 305 192 R91) (‡)
2	366 317 R91	SWITCH, starting (†) (†) No. 10NF NUT (2) No. 10NF x 7/16" slt-yd-hd SCREW (2) No. 10 lock WASHER (2)
Š		CABLE, minus (-) on ammeter to starting switch (positive ground) or plus (+) on ammeter to starting switch (negative ground) (red) (order 305 192 R91) (+) (‡)

PRINTED	114	UNITED	<b>タマハアを</b> 章	٥F	AMERICA

NO.	I, H, PART NUMBER	SEECRIPTION
4		CABLE, minus (-) on ammeter to "B" on solenoid (positive ground) or plus (+) on ammeter to "B" on solenoid (negative ground (red) (order 305 192 R91) (†) (‡)
5	62 801 DC	SWITCH, ignition (†)
6		CABLE, ignition switch to "L" on voltage regulator (yellow) (order 305 192 R91) (1)
6		CABLE. "B" on relay to "L" on voltage regulator (yellow) (order 305 192 R91) (‡)
7		CABLE, starting switch to "5" on solenoid (green) (order 305 192 R91) (7) (‡)

## ELECTRICAL SYSTEM

REF.	I. H. PART NUMBER	DESCRIPTION	
NO.	NOMBER		

ELECTRIC WIRING - Continued (Battery Ignition) (For units equipped with Instrument Panel Attachment 305 191 R91 or Automatic Shut-Off Attachment 305 198 R91)

8	269 103 R91	AMMETER (f) (‡)
9		CABLE, positive (+) on ammeter to "B" on voltage regulator (positive ground) or minus (-) on ammeter to "B" on voltage regulator (negative ground) (blue) (order 305 192 R91) (†) (‡)
10		CABLE, "R" on solenoid to resistor (brown) (order 305 192 R91) (7) (1)
11	305 192 R91	HARNESS, cable (f) (‡)
12	165 518 R91	COIL, ignition (also illustrated with "Spark Plugs, Coil Cables and Distributor")
13	370 594 R91	CABLE, minus (-) on coil to resistor (positive ground) or plus (+) on coil to resistor (negative ground) (also listed with "Spark Plugs, Coil, Cables and Distributor")
14		RESISTOR (also listed with "Spark Fluga", Coil Cables and Distributor")
15	368 Z67 R91	CABLE, plus (+) on coil to distributor (positive ground) or minus (-) on coil to distributor (negative ground) (also listed with "Spark Plugs, Coil, Cables and Distributor")
16		DISTRIBUTOR, assembly (for components see list of parts under details of "Distributor")
17		MOTOR, cranking (for components see list of parts under details of "Cranking Motor")
8,		CABLE, battery to ground (not furnished with power unit) (See "Battery and Cables")
19		CABLE, battery to cranking motor (not furnished with power unit) (See "Battery and Cables")
20		BATTERY (12 volt) - dry charged (not furnished with power unit) (See "Battery and Cables")
21	264 164 R91	CLIP, cable (‡) (7) (2)
22		REGULATOR. voltage (for components see list of parts under details of "Voltage Regulator")
23		CABLE, generator "A" to "Gen" on voltage regulator (red w/black tracer) (order 264 637 R93)
24		CABLE, generator "F" to "F" on voltage regulator (black w/red tracer) (order 264 637 R93)
25	265 191 R91	HARNESS, generator to regulator cable (*)
25	264 637 R93	*)
26		GENERATOR (for components see list of parts under details of "Generator")
27	263 515 R9	l CLIP, generator cable
29	265 470 R9	RELAY(‡)

PRINTED IN UNITED STATES OF AMERICA

# -55-ELECTRICAL SYSTEM

REF.	I.H. PART Number	OKSCRIPTION
ELECT Batte: Attach	TRIC WIRING - C	Continued r units equipped with Instrument Panel 91 or Automatic Shut-Off Attachment
<b>2</b> 9		CABLE, "S" on relay to stop switch (furnished as part of SWITCH, 265 471 R91)
30	265 471 R91	SWITCH, stop (1)
31		CABLE, stop switch to oil pressure indicator (furnished as part of 268 542.R91)
32		CABLE, stop switch to water temperature gauge (furnished as part of 256-502 R91)
33	268 542 R91	INDICATOR w/WIRE, oil pressure (1)
34	256 502 R91	INDICATOR W/WIRE, water temperature (‡)
35	370 535 R1	CLIP, coil to distributor cable
36	362 120 RI	CLIP, cranking motor harmoss
37		CABLE, ignition switch to fuel pump (black) (**)
38		CONNECTOR (furnished as part of ignition switch to fuel pump cable) (**)
39		CABLE, fuel pump to connector (furnished as part of fuel pump) (**)
40		PUMP, fuel (for components see list of parts under details of "Electric Fuel Pump") (**)
		; X,
		•
		and the second s
		<ul> <li>(†) - Part Of Instrument Panel Attachment, 305 191 R91.</li> <li>(‡) - Part Of Automatic Safety Shut-Off Attachment, 305 198 R91.</li> <li>(*) - Used On Units Equipped With Hydraulic Pump.</li> <li>(**) - Part Of Electric Fuel Pump Attachment</li> </ul>


PRINTED IN UNITED STATES OF AMERICA


#### -56-ELECTRICAL SYSTEM


# ELECTRICAL SYSTEM


CTRIC WIRING

gneto Ignition) (For units equipped with Instrument Panel Actachments, 312 062 R91 and 312 063 R91 or Automatic Shut-Off Attachments, 312 059 R91 and 312 060 R91) C-221 501 to 43020 C-263 501 to 56635









NUMBER	DESCRIPTION
	CABLE, ignition switch to magneto (orange) (order 312 061 R91) (+)
	CABLE, stop switch to magneto (orange) (order 312 061 R91) (*)
366 317 R91	<pre>SWITCH, starting (+) (*)</pre>
	CABLE, minus (-) on ammeter to starting switch (positive ground) or positive (+) on ammeter to starting switch (negative ground) (red) (order 312 061 R91) (+) (*)
	CABLE, minus (-) on ammeter to "B" on solenoid (positive ground) or positive (+) on ammeter to "B" on solenoid (negative ground) (red) (order 312 061 R91) (+) (*)

NET.	i. H. PART NUMBER	DESCRIPTION
5	54 207 DB	SWITCH, magneto (*)
6	310 962 R91	MAGNETO (American Bosch MRD-6A302) high tension (medium duty- tungsten points) (for components see list of parts under details of "Magneto")
6	310 963 R91	MAGNETO (American Bosch MRF-6A302) (high tension) (heavy duty - tungsten points) (for components see list of parts under details of "Magneto")
		<ul> <li>(*) - Part Of Instrument Panel Attachments 312 062 R91 And 312 063 R91.</li> <li>(*) - Part Of Automatic Safety Shut-off Attachments 312 059 R91 and 312 060 R91.</li> </ul>

-57 -

# ELECTRICAL SYSTEM

### -57-ELECTRICAL SYSTEM

REF. NO.	I. H. PART NUMBER	<b>OCSCRIPTION</b>	REF.	I, H. PART NUMBER	DESCRIPTION
ELECT (Magne Attach Attach C-221	FRIC WIRING - C	CONTINUES OF Units equipped with Instrument Panel R91 and 312 063 R91 or Automatic Shut-Off R91 and 312 060 R91	(Magn Attach Attach C-221	manta 312 062	Continues or units equipped with Instrument Panel R91 and 312 063 R91 or Automatic Shut-Off R91 and 312 060 R91)
6	313 698 R91	MAGNETO (American Bosch MRF-6A332) (high tension) (heavy duty-platinum points) (for components see list of parts under	:	ST 633	BEARING, idler pulley shaft (also listed and illustrated with "Fan Belt, Idler Pulley and Arm")
_		details of "Magneto")  CABLE, starting switch to "S" on solenoid		305 177 R1	BELT, water pump and generator fan (also listed and illustrated with "Fan Belt, Idler
7	1	(green) (order 312 061 R91 (+) (*)			Polloy and Arm")
8	269 103 R91	AMMETER (+) (*)		310 964 R91	
9		CABLE, positive (+) on ammeter to "B" on voltage regulator (positive ground) (or negative (-) on ammeter to "B" on voltage regulator (negative ground) (blue) (order		310 965 R91	(also listed and illustrated with "Spars Fings and Cables")
10	312 061 R91	3 2 06  K91  (+) (*)  HARNESS, cable (used with Electric Starting) (+) (*)		310 966 R91	CABLE, magneto high tension (cylinder No. 3) (also listed and illustrated with "Spark Plugs and Cables")
11		MOTOR, cranking (for components see list of parts under details of "Cranking Motor")		310 967 R91	CABLE, magneto high tension (cylinder No. 4) (also listed and illustrated with "Spark Plugs and Cables")
12		CABLE, battery to ground (not furnished with power unit) (See "Battery and Cables")		310 968 R91	CABLE, magneto high tension (cylinder No. 5 (also listed and illustrated with. "Spark Plugs and Cables")
13		CABLE, battery to cranking motor (not furnished with power unit) (See "Battery and Cables")		310 969 R91	No. 6
14.		BATTERY (12 volt) - dry charged (not furnished with power unit) (See "Battery and Cables")		308 579 RI	and Cables")  CLIP, spark plug cable (also listed and illustrated with "Spark Plugs and Cables") (2
1.5	264 164 R91	CLIP, cable (+) (*) (2)			5/16 x 5/8" hex-hd cap SCREW 5/16" lock WASHER
16		REGULATOR, voltage (for components see list of parts under details of "Voltage Regulator")		109 461 138 322 H	FITTING, 1/8" lubrication (Lincoln 5000) (optional with 138 322 H) FITTING, 1/8" lubrication (Alemite 1610BL)
17		CABLE, generator "A" to "GEN" on voltage regulator (red w/block tracer) (order 264 637 R93)		353 936 RZ	(optional with 109 461)  GASKET, oil pump shaft support (also listed and illustrated with "Crankcase Oil Pan and
18		CABLE, generator "F" to "F" on voitage			Oil Pump")
		regulator (black w/red tracer) (order 264 637 R93)		312 051 R91	
19	264 637 R93	HARNESS, generator to regulator cable		312 054 RI	PULLEY, idler (also listed and illustrated with "Fan Belt, Idler Pulley and Arm")
20		GENERATOR (for components see list of parts under details of "Generator")		143 992	PLUG, 1/4" slf-hd pipe (also listed and illustrated with "Crankcase Oil Pan and Oil Pump")
Z1	263 515 R91			133 502 R1	RING, snap (also listed and illustrated with
22 23	265 471 R91	CABLE, stop switch to oil pressure indicator			"Fan Beit, Idler Pulley and Arm!") (2) SUPPORT, idler pulley adjusting arm (also
Z4		(furnished as part of 313 067 R91)  CABLE, stop switch to heat indicator		312 056 RI	SUPPORT, their pulley adjusting all listed and illustrated with "Fan Belt, Idler Pulley and Arm") 13/32 x 13/16 x 1/16" ga WASHER (2)
25	313 067 R91	(furnished as part of 265 468 R91)  INDICATOR w/WIRE, oil pressure gauge (*)		312 1 <b>57</b> R9	
26	265 468 R91	INDICATOR w/WIRE, heat gauge (*) CLIP, cable harness			Pump")
27 28	362 120 R1 62 862 D	CABLE, ignition switch to magneto (not used with electric starting)		312 052 R1	SCREW, 5/16 x 1" hex-hd cap (at front
	312 055 R1	ARM, idler pulley adjusting (also listed and illustrated with "Fan Belt. Idler Pulley and Arm")  3/8 x 1" hex-hd cap SCREW  13/32 x 13/16 x 1/16" ga WASHER  3/8" lock WASHER			WASHER, 5/16" lock (cover  (+) - Part Of Instrument Panel Attachments 312 062 R91 And 312 063 R91.  (*) - Part Of Automatic Safety Shut-Off Attachments 312 059 R91 And 312 060 R91.

8


-58-

### ELECTRICAL SYSTEM

# ELECTRICAL SYSTEM

ECTRIC WIRING
attery Ignition)
or units with instruments and instrument panel (regular gauges)
Attachment, 349 132 R91)

ELECTRIC WIRING - CONTINUED (Battery Ignition) (For units with instruments and instrument panel (regular gauges) Attachment, 349 132 R91)



MO.	I.H.FART HUMBER	DESCRIFTION	NO.	I, H, PART HUMBER	DESCRIPTION
1	269 103 R91	AMMETER (part of ATTACHMENT, 349 13Z R91)	12		CABLE, minus on call to distributor
2		CABLE, plus (+) on ammeter to "B" on solenoid (order 349 128 R91)	13		RESISTOR, ignition coil (also listed and illustrated with "Spark Plugs, Coil, Cables and Distributor")
3 ·		CABLE, "R" on solemoid to resistor (order 349 129 R91)	14		CABLE, resistor to "IGN" on ignition and starter switch (order 349 129 R91)
4		CABLE, "S" on solenoid to "SOL" on ignition and starter switch (order 349 128 R91)	15		COIL w/CLAMP, ignition (also listed and illustrated with "Spark Plugs, Coil, Cables
5		SOLENOID (furnished as part of "Cranking Motor")			and Distributor")\\
6	•	CONNECTOR, cranking motor to "M" on solenoid (furnished as part of "Cranking Motor")	16	370 594 R91	CABLE, plus (+) on coil to resistor (also listed and illustrated with "Spark Plugs, Coil, Cables and Distributor")
7		MOTOR ASSY, cranking (for components see	17		CABLE, "B" on regulator to minus (-) on ammeter (order 349 130 R91)
8		list of parts under details of "Cranking Motor") CABLE, cranking motor to battery (not furnished with power unit) (See "Battery and Cables")	18		CABLE, "L" on regulator to "BAT" on ignition and starter switch (order 349 130 R91)
9		BATTERY (12 volt) (not furnished with power unit) (See "Battery and Cables")	19		CABLE, "G" on regulator to "A" on genera- tor (order 264 637 R93)
10		CABLE, battery to ground (not furnished with power unit) (See "Battery and Cables")	20		GENERATOR ASSY (for components see list of parts under details of "Generator")
		DISTRIBUTOR ASSY (for components see list of parts under details of "Distributor")	ZI		CABLE. "F" on regulator to "F" on generator (order 264 637 R93)

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

(MEV. NO. | 10-49)

-59 -

ELECTRICAL SYSTEM

DESCRIPTION

-59-

# **MEMORANDA**

(Batte	TRIC WIRING — ( ary Ignition) units with isntr hment, 349 132	uments and instrument panel (regular gauges)
<b>Z</b> 2		REGULATOR, voltage (12 volt) (for compo- nents see list of parts under details of "Voltage Regulator")
23	33 <b>7 354</b> R3	PANEL, instrument (part of ATTACHMENT, 349 132 R91)
		NOT HSED

NOT USED 24 The section of the SWITCH, ignition and starter (part of 327 144 R91 25 ATTACHMENT, 349 132 R91) CABLE, tachourmeter to "ACC" on ignition 26 and starter switch (furnished as part of hourmenter or tachourment) TACHOURMETER (part of ATTACHMENT. 349 134 R92) 338 595 R91 **Z7** HOURMETER, electric (part of ATTACH-MENT, 349 136 R91) 27-28

264 637 R93 HARNESS, generator to regulator

CABLE, tachourmeter to ground (furnished as part of hourmeter or tachourmeter) HARNESS, cranking motor cable (part of ATTACHMENT, 349 127 R91) 349 128 R91 HARNESS, ignition cable (part of ATTACHMENT, 349 127 R91) 349 129 R91 HARNESS, regulator cable (part of ATTCHMENT, 349 127 R91) 349 130 R91

are the second

CONTRACTOR OF THE

a agranda har



-60-

\_ .....

# ELECTRICAL SYSTEM

ELECTRICAL SYSTEM

CTRIC WIRING

ery Ignition)

units with instruments and instrument panel (safety gauges)

Attachment, 349 133 R91)

ELECTRIC WIRING - CONTINUED (Battery Ignition) (For units with instruments and instrument panel (safety gauges) Attachment, 349 133 R91)



30 42 40 40 5 6	SAFETY SHUT-OFF SYSTEM  SAFETY SHUT-OFF SYSTEM  12  15  16  17  18  18  19  10  10  11  12  10  10  10  10  10  10	
35 35 35 36 37 38 38 39 30 30 30 30 30 30 30 30 30 30 30 30 30	25 23 23 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	20 3 / 20 3 / 5
30 28 29		CEA-83242

NO.	I. H. PART Number	DESCRIPTION	NO.	I. H. PART NUMBER	DESCRIPTION
1	347 604 R91	INDICATOR, safety oil pressure (part of ATTACHMENT, 349 133 R91)	7		CABLE, "5" on solenoid to "SOL" on ignition and starter switch (order 349 128 R91)
z	42 915 D	BLOCK, junction (part of ATTACHMENT, 349 133 R91)	8		CONNECTOR, cranking motor to "M" on solenoid (furnished as part of "Cranking Motor")
%. <b>2</b> .	42 917 D	BLOCK w/BLOCK, 42 915 D and BRACKET, 42 916 D, junction (optional with 352 110 R91) (part of ATTACHMENT. 349 133 R91)	9		SOLENOID (furnished as part of "Granking Motor")
<i>∰</i> , <b>z</b>	352 110 R91	BLOCK w/BLOCK, 42 915 D and BRACKET, 42 916 D, junction (optional with 42 917 D)	10		MOTOR ASSY, cranking (for components see list of parts under details of "Grankings" (http://www. Motor")
<i>:</i>		(part of ATTACHMENT, 349 133 R91) No. 8NF NUT (cd or zn-pltd) 3/8" NUT 3/8 x 1/2" hex-hd cap SCREW	11		GABLE, cranking motor to battery (not furnished with power unit) (See "Battery and Cables")
		No. 8 int tooth lock WASHER 3/8" lock WASHER	12		BATTERY (12 voit) (not furnished with power unit) (See "Battery and Cables")
3		CABLE, "B" on regulator to minus (-) on ammeter (order 349 130 R91)	13		CABLE, battery to ground (not furnished with power unit) (See "Battery and Cables")
4	269 103 R91	AMMETER (part of ATTACHMENT, 349 133 R91)	14		DISTRIBUTOR ASSY (for components see list of parts under details of "Distributor")
5		CABLE, plus (+) on ammeter to "B" on	15		CABLE, minus on coil to distributor
		solenoid (order 349 !28 R91)  CABLE, "R" on solenoid to resistor (order 349 129 R91)	16		RESISTOR, ignition coil (also listed and illustrated with "Spark Plugs, Coil, Cables and Distributor")

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

ıů:

P.19/23

-61-

# ELECTRICAL SYSTEM

# ELECTRICAL SYSTEM

M <b>EF.</b> NO.	I. H. PART NUMBER	DESCRIPTION	REP. No.	I.H. PART Number	DESCRIPTION
(Batte (For v	TRIC WIRING — Fy Ignition) Inits with instrument, 349 133	uments and instrument panel (safety gauges)	(Batte (For	TRIC WIRING — ery Ignition) units with instr hment, 349 133	ruments and instrument panel (safety gauges)
17		CABLE, resistor to "IGN" on ignition and starter switch (order 349 129 R91)	36		CABLE, safety oil pressure indicator to junction block (order 347 604 R91)
18		COIL w/CLAMP, ignition (also listed and illustrated with "Spark Plugs, Coil, Cables and Distributor")	37	253 818 R91	SWITCH, safety control toggle (optional with 603 884 C91) (part of ATTACHMENT, 349 133 R91)
		M 34			
19	370 594 R91	CABLE, plus (+) on coil to resistor (also listed and illustrated with "Spark Plugs, Coil, Cables and Distributor")	37	603 884 C91	SWITCH, safety control toggle (optional with 253 818 R91) (part of ATTACHMENT, 349 133 R91)
20		GENERATOR ASSY (for components see list of parts under details of "Generator")	38		NOT USED
Z1		CABLE, "F" on regulator to "F" on genera- tor (order 264 637 R93)	39		NOT USED
		101 (01001 001 031 1173)	40		NOT USED
22		CALBE, "G" on regulator to "A" on genera- tor (order 264 637 R93)	41		CAB LE, tachourmeter to ground (furnished as part of hourmeter or tachourmeter)
23		REGULATOR, voltage (12 volt) (for compo- nents see list of parts under details of "Voltage Regulator")	42		TACHOURMETER (part of ATTACHMENT, 349 134 R9Z)
24		CABLE, "L" on regulator to "BAT" on ignition and starter switch (order 349 130 R91)	42		HOURMETER, electric (part of ATTACH- MENT, 349 136 R91)
25	337 354 R3	PANEL, instrument (part of ATTACHMENT, 349 133 R91)	43		CABLE, tachourmeter to junction block (furnished as part of hourmeter or tachourmeter)
26	327 144 R91	SWITCH, ignition and starter (part of ATTACHMENT, 349 133 R91)		42 916 D	BRACKET, junction block (part of ATTACHMENT, 349 133 R91) No. 10 NUT
27	63 713 DA	CABLE, "BAT" on relay to "IGN" on ignition and starter switch (part of ATTACHMENT, 349 133 R91)			No. 10 x 1/2" sit-hd mach SCREW No. 10 lock WASHER
				264 637 R93	HARNESS. generator to regulator
28		NOT USED		349 128 R91	HARNESS, cranking motor cable (part of ATTACHMENT, 349 127 R91)
29		NOT USED			
30		NOT USED		349 129 R91	HARNESS, ignition cable (part of ATTACHMENT, 349 127 R9!)
31	606 069 C91	RELAY, automatic shut-off (part of ATTACHMENT, 349 133 R91)		349  30 R91	HARNESS, regulator cable (part of ATTACHMENT, 349 127 R91)
32	274 747 R91	CABLE, safety control toggle switch to "Switch" on relay (part of ATTACHMENT, 349 133 R91)			
33	347 60Z R91	INDICATOR, safety heat (part of ATTACH- MENT, 349 133 R91)			
34		CABLE, heat indicator to junction block (order 347 602 R91)			
35	274 747 R91	CABLE, safety control toggle switch to junction block (part of ATTACHMENT. 349 133 R91)			

-62-


ELECTRICAL SYSTEM





ELECTRICAL SYSTEM

-62-

MAGNETO (Bosch) (High Tension) C-221 501 to 43020 C-263 501 to 56635 MAGNETO - CONTINUED (Bosch) (High Tension) C-221 501 to 43020 C-263 501 to 56635







IPA-66134

-63-

# ELECTRICAL SYSTEM

-63-

ELECTRICAL S'	YSTEM
---------------	-------

REF. NO.	I. H. PART NUMBER	DESCRIPTION	REF. NO.	I. H. PART NUMBER	DESCRIPTION
Bosch C-221	ETO - Continue (High Tensic 501 to 43020 501 to 56635		(Bosch ⊂-221	ETO - Continui ) (High Tensi 501 to 43020 501 to 56635	on)
	310 962 R91	MAGNETO, high tension (Bosch MRD-6A-302)	45		GEAR (NF5)
		(Medium duty - tungsten points) 3/8 x 1-3/8" hex-hd cap SCREW	46		ROTOR (NF5)
		3/8 x 1-1/4" hex-hd cap SCR.EW 3/8" lock WASHER (2)	48		*SCREW and LOCKWASHER
	62 493 D	WASHER, magneto screw (2)	49		*GEAR (NFS)
}		SEAL (NFS)	51		*GASKET
•		*GASKET	52		* BRUSH W/SPRING
5		PIN (NFS)	53	:	STUD (NFS)
ó		PIN (NFS)	54		SPRING (NFS)
<b>7</b>		SCREW (NFS)	55		DISTRIBUTOR, plate assembly (includes Ref.
}		COVER (NFS)			Nos. 53, 54 and 56 to 62 (NFS) WASHER (NFS)
7		*GASLET	56		
0		SCREW (NFS)	57		WASHER (NFS)
1 1		COIL, includes Ref. No. 12 and 14 (NFS)	58		NUT (NFS)
Į Z		SPRING (NFS)	59		*GASKET
14		CABLE (NFS)	60		WINDOW (NFS)
16		*WASHER	61		WASHER (NF5)
17		*STRIP	62		SCREW (NF5)
18		BEARING (NF5)	64		*SCREW
19		* WASHER	65		*SCREW and lock WASHER
Z <b>O</b>		* WASHER	66		CLIP (NF\$)
ZĮ		KEY (NFS)	67		NIPPLE (NFS)
ZZ		ROTOR (NFS)	68		IMPULSE COUPLING ASSEMBLY - includes Reference Nos. 69 to 79 (NFS)
23		*WASHER (.012" thick)	69		NUT (NFS)
23		*WASHER (,007" thick)	70		WASHER (NFS)
23		*WASHER (.004" thick)	71		HOUSING (NFS)
23		*WASHER (.002" thick)	72		BALL (NFS)
25		*SCREW and lock WASHER	73		SPRING (NFS)
26		*CONDENSER	74		WICK (NFS)
<b>Z</b> 7		PLATE (NFS)	75		CAM (NFS)
31		WICK (NFS)	76		WEIGHT (NFS)
34		*BRACKET ASSEMBLY - includes Ref. No. 38 and 39	77		HUB (NFS)
35		CLIP (NFS)	78		SCREW and WASHER (NFS)
36		*SCREW and lock WASHER	79		PLATE (NFS)
37 38		*WASHER *WASHER		31 <b>7 8</b> 35 R9	1 * PACKAGE, magneto field service
39		*RING			
41		* RING			
<b>4</b> Z		WASHER (NFS)			
43		BEARING (NFS)			* - Furnished As Part Of Magneto Field Service Fackage 317 835 R91.
44		WASHER (NFS)			Service Fackage 317 835 K41.  NFS - Not Furnished Separately.

-64-


# ELECTRICAL SYSTEM

PRINTED IN UNITED STATES OF AMERICA



#### -64-ELECTRICAL SYSTEM

MAGNETO - Continues (Bosch) (High Tension) C-221 501 to 43020 C-263 501 to 56635 TNETO Joh) (High Tension) C-221 501 to 43020 C-263 501 to 56635



NO.	I. H. PART NUMBER	DESCRIPTION	REF. NO.	I. H. FART NUMBER	DESCRIPTION
	313 698 R91	MAGNETO, high tension (Bosch MRF-6A-332) (Heavy duty - platinum points)	18		KEY (NFS)
	310 963 R91	MAGNETO, high tension (Bosch MRF-6A-302)	19		ROTOR (NFS)
		(Heavy duty-tungsten points) 3/8 x 1-3/8" hex-hd cap SCREW	20		KEY (NFS)
		3/8 x 1-1/4" hex-hd cap SCREW 3/8" lock WASHER (2)	Z1		*WASHER (.012" thick)
	62 493 D	WASHER, magneto screw (Z)	21 21		*WASHER (.007" thick) *WASHER (.004" thick)
		*SCREW and lock WASHER	21		*WASHER (,002" thick)
1		*SCKE M SECTION MADURA	22		*WASHER
Z		COVER (NFS)	23		SCREW (NFS)
3 4		SCREW (NFS) SCREW (NFS)	24		WASHER (NFS)
5		HOUSING (NFS)	25		INSULATION (NFS)
6		SCREW (NFS)	26		SCREW and lock WASHER (NFS)
7		PIN (NFS)	27		CONDUCTOR (NFS)
8	٠.	INSULATION (NFS)	<b>Z</b> 8		GEAR AND ROTOR (NFS)
9		COIL (NFS)	29		ROTOR (NFS)
10		CABLE (NFS) TERMINAL (NFS)	30 31		BEARING (NFS) SPAGER (NFS)
12		* Washer	32		BRACKET (NFS)
13		*SEAL	33		SCREW and lock WASHER (NFS)
14		*WASHER	34		CLIP (NFS)
15		*STRIP (.009 thich)	35		* CONDENSER
15		*STRIP (.008 thick)			<ul> <li>Furnished As Part Of Magneto Field Service Package 317 834 R91.</li> </ul>
6 17سے		BEARING (NFS) Washer (NFS)			NFS - Not Furnished Separately.
		PRINTED IN UNITED STATES OF AMERICA		PP	INTED IN UNITED STATES OF AMERICA

-65-

ELECTRICAL SYSTEM

# 

# ELECTRICAL SYSTEM

	ELECTRICAL SISTEM				
REF. NO.	I.M. PART DESCRIPTION	REF.	I. H. PART Number	DESCRIPTION	
(Bosch)	O - Continues (High Tension) 01 to 43020 01 to 56635	(Bosch C-221	ETO - Continues i) (High Tension 501 to 43020 501 to 56635	a)	
36	SCREW and lock WASHER (NFS)	77		WASHER (NFS)	
37	GEAR (NFS)	78		IMPULSE COUPLING ASSEMBLY - Include Ref. Nos. 79 to 89 (NFS)	.C.B
38	WASHER (NFS)	79		NUT (NFS)	
39	SCREW and lock WASHER (NFS)	80		WASHER (NFS)	
40	WASHER (NFS)	81		HOUSING (NFS)	
41	HOOK (NFS)	82		BALL (NFS) 198,AC North	y
42	WICK (NFS)	83		SPRING (NFS)	
43	SCREW and lock WASHER (NFS)	84		WICK (NFS)	
44	WASHER (NFS)	85		CAM (NFS)	
45	Breaker Plate (NFS)	86		WEIGHT (NFS)	
46	*BRACKET	87		HUB (NFS)	
47	SCREW and lock WASHER (NFS)	88		SCREW and WASHER (NFS)	
48 49	WASHER (NFS) WASHER (NFS)	89		PLATE (NFS)	
50	NUT (NFS)			PLATE (NFS) PLATE (NFS)	
51	* LEVER			PLATE (NFS)	
52	*WASHER			*GASKET	
53	WASHER (NFS)		317 834 R91	*PACKAGE, magneto field service	
5 <b>4</b>	PIN (NFS)		*	- Furnished as part of Magneto Field	
55	* BRUSH			Service Fackage 317 834 R91. NFS - Not Furnished Separately.	
56	CAM (NF5)				
57	WASHER (NFS)	BATT	ERY AND CABL	ES	•
58	SCREW w/lock WASHER (NFS)				
59	+BRUSH w/SPRING			BATTERY, dry-charged (12 volt) (Auto-	Lite
60	*GA5KET			12H-70-3)	
61	PLATE			BOLT, battery terminal (X)	+ i
6Z 63	*WASHER *WASHER		30 668 DB	Kidmana anni-//	,
64	*SCREW		53 023 DA	CABLE. battery to cranking motor (nega grounded battery)	tive
65	WASHER		263 518 R91		nded
66	GASKET (NFS)			battery)	
67	WINDOW (NF5)		30 668 DB	CABLE, battery to ground (negative ground battery)	maea
68	RING (NFS)			13/32 x 13/16 x No. 16 ga. WASHER 3/8" internal-external tooth lock WAS	HER
69	TERMINAL (NFS)				
70	NIPPLE (NFS)			•	
71	*GASKET				
72	CAP (NF5)				
73 74	* WASHER * WASHER				
75	SCREW (NFS)				
76	*SCREW		W	(X) - As Required.	

PAINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA


-66-

# **ATTACHMENTS**



# ATTACHMENTS

CLEANER aldson) (Oil Bath Type) AIR CLEANER - Continues (Donaldson) (Oil Bath Type)



MO.	I.H.PART NUMBER	BESCRIPTION
A - B -	305 180 R91 349 144 R91	ATTACHMENT, air cleaner (+) ATTACHMENT, air cleaner (see Notes I and 3)
	ų.	Parts without letters after the description indicates the part is used for all attachments listed below. Letters A and B are used to identify separate attachments.
	55 804 DX	BRACKET, air cleaner (2 for Attachment A) 5/16" NUT (2) 3/8" NUT (4) 5/16 x 1-1/4" sit-fil-hd mach SCREW (2) 3/8 x 7/8" hex-hd cap SCREW 3/8 x 1-1/8" hex-hd cap SCREW
ı	55 804 DX	5/8 x 1-1/8" hex-hd cap SCREW (2) 3/8" lock WASHER (4) 13/32 x 13/16" x 1/16" WASHER BRACKET, air cleaner (2 for attachment B) 3/8" NUT (4) 3/8 x 7/8" hex-hd cap SCREW (2) 3/8 x 1-1/8" hex-hd cap SCREW (2) 3/8" lock WASHER (4)
2	353 018 R92	CAP, air intake
3	265 331 R1	CAP, vent tube
4	318 140 R1 349 141 R1	BRACE, air cleanar support (Attachment A) BRACE, air cleaner support (Attachment B) 3/8 x 3-1/4" hex-hd cap SGREW
,	305 181 R13 349 138 R91	SUPPORT, air cleaner (Attachment A) SUPPORT, air cleaner (Attachment B)

NO.	T. M. PART HUMBER	DESCRIPTION
6	274 088 R91	CLAMP, air pipe hose (2)
7	31 790 DA	BRACKET, air hose support 3/8" NUT 3/8 x !" hex-hd cap SCREW 3/8" lock WASHER
В	305 886 R1	ANGLE, air hose support
9	305 885 R1	PIPE, air
LO		BODY (Not Furnished Separately)
10	357 659 R92	CLEANER W/BODY, CLAMP, 54 269 D. CUP 355 444 R92, ASSY, air (7") (FCAO7-1431) (Attachment A)
10	305 626 R91	CLEANER w/BODY, CLAMP, 54 269 D, CUP, 355 444 R92, ASSY, air (7") (FCAO7-1437) (Attachment B)
1 İ	54 269 D	CLAMP, oil cup retaining (P-3009)
12	355 444 R92	CUP, oil (P-14844)
		+ - Attachment No Longer Available Service Parts Only Will Be Furnished. NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

- 67 -

-67-


# **ATTACHMENTS**



# ATTACHMENTS

AIR CLEANER AND CONNECTIONS (United Specialties) (Dry type)

AIR CLEANER AND CONNECTIONS - CONTINUES (United Specialties) (Dry Type)



NO.	L H, PART NUMBER	DESCRIPTION
	349   37 R91	ATTACHMENT, air cleaner and connections (see NOTES I and 3)
1	353 018 R92	CAP, weather
z	338 887 R91	CLEANER, 217
3	313 965 R91	RETAINER, air cleaner element (193B 3K030)
4	317 70Z R91	ELEMENT, air cleaner (250C4-5)
5		BODY, sir cleaner (not Furnished Separately)
6	274 088 <b>R91</b>	CLAMP, air pipe (2)
7	347 598 RI	PIPE, air
8	112 030 H	CLAMP, air pipe support 3/8" NUT 3/8 x 1-1/8" hex-hd cap 5CREW 3/8" lock WASHER
9	349 143 R1	SUPPORT, air pipe 3/8 x 3-1/4" hex-hd cap SCREW

ND.	I, H. PART Number	DESCRIPTION
10	347 599 R1	SLEEVE, sir pipe hose
11	122 316 R91	CLAMP, dust unloader
l Z	324 194 Rl	UNLOADER, dust
13	349 138 R91	SUPPORT, sir cleaner
14	349 141 R1	BRACE, air cleaner support 3/8 x 3-1/4" hex-bd cap SCREW
15	349 142 R1	BRACKET, air cloaner 3/8" NUT (4) 3/8 x 1" hox-hd cap SCREW (4) 3/8" lock WASHER (4)
16	341 373 R91	BRACKET, air cleaner mounting (2) 3/8" NUT (4) 3/8 x 3/4" hex-hd cap SCREW (4) 3/8" lock WASHER (4)
	2 751 188 R1	PRODUCT GRAPHIC, decalcomania, air cleaner instruction

NOTE! - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

-68-

#### **ATTACHMENTS**




# ATTACHMENTS

MATIC SAFETY SHUT-OFF
hy Panel) (Not used on unite equipped with Instruments
anel Attachments 305 191 R91, 312 062 R91 and 312 063 R91)

AUTOMATIC SAFETY SHUT-OFF - CONTINUED

(Murphy Panel) (Not used on units equipped with Instruments and panel attachments 305 191 R91, 312 062 R91 and 312 063 R91)



NEF. NO.	I. H. PART HUMBER	DESCRIPTION
(x) - :	KEY TO UNITS	
A -	305 198 R91	ATTACHMENT, automatic safety shut-off (Murphy panel) (Battery ignition) (+)
В-	312 059 R91	ATTACHMENT, automatic safety shut-off (Murphy panel) (Magneto ignition) (For units equipped with Cranking Motor and Generator (+)
c -	312 060 R91	ATTACHMENT, automatic safety shut-off (Murphy panel) (Magneto ignition) (For units not equipped with Granking Motor and Generator) (+)
(X) -	the description	e units correspond with those shown following on of the parts in the list below and identifies hich the part is used. Items without letters cription indicates the part is used for all units.
1	304 585 R11	BRACKET, instrument panel mounting (2) 3/8" NUT (2) 3/8 x 3/4" hex-hd cap SCREW (4) 3/8" lock WASHER (4)
2 3	304 586 R1 278 597 R2	HOUSING, instrument panel PANEL, instrument 1/4 x 1/2" slt-rd-hd SCREW (4) 1/4" lock WASHER (4)
	269 103 R91	AMMETER (also listed with "Electric Starting (Units A and B)

REF. HO.	I, M. PART Mumber	DESCRIPTION
5	432 577	PLUG, instrument panel button (2 for Units A and B) (3 for Unit C)
6	304 587 R1	TUBE, oil pressure indicator
7	369 987 R1	NUT, tube (nylon) (2)
8	67 869 D	ELBOW, oil pressure indicator tube (in gauge
9	268 542 R91	GAUGE, oil pressure (also listed with "Electric Starting") (Unit A)
9	313 067 R91	GAUGE, oil pressure (also listed with "Electric Starting") (Units B and C)
10	265 470 R91	RELAY (also listed with "Electric Starting")
11	26 242 D	FELT, heat indicator cable clip
12	254 275 R1	CLIP, heat indicator cable 3/8 x 3/4" hex-hd cap SCREW 3/8" lock WASHER
13	256 502 R91	INDICATOR, heat (also listed with "Electric Starting") (Unit A)
13	Z65 468 R91	INDICATOR, heat (also listed with "Electric Starting") (Units B and C)
		<ul> <li>Attachment No longer Available.</li> <li>Service Parts only will be furnished.</li> </ul>

L. H. PART

-69-

#### **ATTACHMENTS**

NO.	NUMBER		 	
AUTOM	ATIC SAFETY SHUT-OFF	- CONTINUED		

DESCRIPTION


AUTOMATIC SAFETY SHUT-OFF - CONTINUED (Murphy Panel) (Not used on units equipped with instruments and panel attachments 305 191 R91, 312 062 R91 and 312 063 R91)

14	366 317 R91	SWITCH, starting (also listed with "Electric Starting")
15	265 471 R91	SWITCH, stop (also listed with "Electric Starting")
16	346 598 RI	ADAPTER, heat indicator
	62 862 D	CABLE, ignition switch to magneto (Unit C)
	29 901 D	CONNECTOR, oil pressure indicator tube (in crankcase)
	264 164 R91	CLIP, cable harness (illustrated with "Electric Starting") (Z for Units A and B) (Unit C)
	362 120 R1	CLIP, cable harness (illustrated with "Electric Starting") (Units B and C)
	305 192 R91	HARNESS, cable (illustrated with "Electric Starting") (Unit A)
	312 061 R91	HARNESS, cable (illustrated with "Electric Starting") (Unit B)

-69-

# ATTACHMENTS

#### **SUPPORTS**



MEY.	L. H. PART	
	NUMBER	DESCRIPT! OF
MO.	NUMBER	

#### ⟨X⟩ - KEY TO UNITS

B - 305 296 R91 ATTACHMENT, front support (See NOTES 1 and 3)

B - 305 297 R91 ATTACHMENT, rear support (See NOTES 1 and 3)

C - Letters of these units correspond with those shown following the description of the parts in the list below and identifies the unit for which the part is used. Items without letters after the description indicates the part is used for all units.

304 546 R12 SUPPORT, front (Unit A)
5/8" NUT (4)
5/8 x 3-3/4" hex-hd. cap SCREW (4)
5/8" lock WASHER (4)

2 304 543 R11 SUPPORT, rear (Unit B)

1/2" x 1" hex-hd. cap SGREW (8)


1/2" lock WASHER (8)

NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

 $= \sum_{i \in \mathcal{I}_{i}} \left( \sum_{i \in \mathcal{I}_{i}} \left( \sum_{i \in \mathcal{I}_{i}} \sum_{i \in \mathcal{I}_{i}} \left( \sum_{i \in \mathcal{I}_{i}} \sum_{i \in \mathcal{I$ 

#### **ATTACHMENTS**

GINE CONTROLS
-r engines with Machanical Governor)





MO.	1. M. PART NUMBER	DESCRIPTION
,		Parts without letters after the description indicate the part is used for all attachments listed below: Letters A, B, C and D are used to identify separate attachments.
A .	305 185 R92	ATTACHMENT, engine controls (for units equipped with Natural Gas. LPG and Combination Gas and gasoline engines and IH mechanical governor) (see NOTES I and 3)
Ē	312 064 R91	ATTACHMENT, engine controls (for units equipped with Natural Gas. LFG and combination gas and gasoline engines and Novi mechanical governor) (see NOTES 1 and 3)
С	323 826 R91	ATTACHMENT, engine controls (for units equipped with gasoline engines and Novi mechanical governor) (see NOTES 1 and 3)
D	323 862 R91	ATTACHMENT, engine controls (for units equipped with gasoline engines and I.H. mechanical governor) (see NOTES I and 3)
1	349 148 R1	BRACKET, governor control cable 3/8 x 7/8" hex-hd cap SCREW (2) 3/8" lock WASHER (2)
2	305 114 R92	CABLE, governor control (Attachments A and D)
2	31 <b>3 069 R93</b>	CABLE, governor control (Attachments B and C)
3	332 077 R1	COUPLING, governor control cable (Attach- ments A and D) 1/4"NF NUT
4	312 428 R91 312 199 R91	WIRE, choke control (Attachments A and B) WIRE, choke control (Attachments C and D)
5	349 147 R1	BRACKET, choke control wire
	109 415	BALL JOINT, governor control cable (Attackment B and C) 1/4"NF NUT (2) 1/4" lock WASHER
<u> </u>	35 758 D	CLIP, governor control cable (mount on center oil pan bolt) (Attachments B and C) 1/4"NF NUT 1/4"NF x 1/2" hex-hd cap SCREW 1/4" lock WASHER 11/32 x 11/16 x 1/16" WASHER

#### ATTACHMENTS

-70-

EXHAUST MUFFLER AND RAIN CAP (Nelson Muffler Co.)





NO.	J. H. PART Humber	DESCRIPTION		_
	332 516 R91	ATTACHMENT, exhaust rain cap (See 1 and 3)	NOT ES	
	276 250 R91	ATTACHMENT, exhaust muffler (5ee I 1 and 3)	NOTES	
ı	281 424 R91	CAP, exhaust rain (optional with 338 5		
1	338 576 R91	(part of ATTACHMENT, 332 516 R91) CAP, exhaust rain (optional with 281 4 (part of ATTACHMENT, 332 516 R91)	Z4 R91)	
2	313 <b>847</b> R91	MUFFLER, exhaust (T6965) (part of ATTACHMENT, 276 250 R91)		
3	31 790 DA	CLAMP, exhaust muffler (part of ATT, MENT, 276 250 R91) 3/8" NUT		
		3/8 x 1-1/4" hex-hd cap SCREW 3/8" lock WASHER	v 1	
			er <del>j</del> ega verije se og	eth heima di
			1: ::	

NOTE 1 - Factory Application Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Chamels.


-71-


-71-




## **ATTACHMENTS**

EXPANSION TANK AND CONNECTIONS







NO.	), H, PART NUMBER	DESCRIPTION
	332 181 R91	ATTACHMENT, expansion tank and connections (For use with flormatic valve attachment and engine support attachment) (see NOTES 1 and 3)
ı	317 654 R91	CAP, tank filler
z	316 029 R93	TANK, w/PLUG. 103 874, water expansion 5/16" NUT (4) 5/16 x 1-3/4" hex-hd cap 5CREW (4) 5/16" lock WASHER
	103 874	PLUG, 1/2" pipe
3	346 611 R1	HOSE, 3" ID x 2-1/2" long inlet and outlet tube connector (*) (2)
	279 0 <b>29</b> R91	GLAMP, hose (4)
4		VALVE, flo-matic (Not furnished as part of "Expansion Tank and Connections Attach- ments") (for components see list of parts under details of "Flo-Matic Valve")
5	316 040 R11	TUBE, water outlet
6	316 035 R1	SUPPORT, expansion tank (2) 3/8" NUT (8) 3/8 x 1" hex-hd cap SCREW (8) 3/8" lock WASHER (8) 7/16" lock WASHER (8)
7	316 058 RZ 279 029 R91	ELBOW, by-pass valve body (2) CLAMP, hose (5)

NEF. NO.	I. H. PART NUMBER	DESCRIPTION
B	316 039 R1	"U" BOLT, water tube (2) 5/16" NUT (6) 5/16" lock WASHER (4) 11/3Z x 11/16" x No. 16 ga. WASHER (4)
9	316 059 R1	TUBE, water return
10	31 729 D	VALVE, drain
11	316 037 R11	TUBE, water inlet
12	316 036 RI 316 060 RI	SUPPORT, tube (2) 5/16" NUT (4) 5/16 x 1-3/4" hex-hd cap SCREW (4) 5/16 x 1-3/4" hex-hd cap SCREW (4) 11/32 x 11/16" x No. 16 ga. WASHER (4) SUPPORT, water return tube (2) 5/16" NUT (4) 5/16 x 1" hex-hd cap SCREW (4) 5/16" lock WASHER (4)
	332 182 R1 332 183 R1	ELBOW, engine water outlet ELBOW, engine water inlet
	279 0 <b>26 R91</b>	CLAMP, hose (3)
		NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels. *Make From Bulk Stock. Bulk Stock Furnished in 3 Foot Lengths. Part No. Is For 1 Foot Of Hose Only.

MATIC VALVE


-72-

**ATTACHMENTS** 



ATTACHMENTS

FLO-MATIC VALVE - CONTINUED



-73-

## **ATTACHMENTS**

REF.	I, M. PART	DESCRIPTION
FLO-	MATIC VALVE —	Сонтінико
	332 184 R91	ATTACHMENT, flo-matic valve (see NOTES 1 and 3)
1	316 253 R2	INLET, flo-matic valve
2	31 729 D	VALVE, 3/8" vent
3	171 819 R1	NIPPLE, 5/8 x 3/8" hose (2)
4	274 085 R91	CLAMP, hose (4)
5	171 807 RI	ELBOW, 5/8 x 3/8" x 90° hose (short)
6 7	169 192 R1 120 879 RI	ELBOW, 90° x 5/8" rubber hose (2) ELBOW, 5/8 x 3/8" x 90° hose (long)
8	346 637 R91	CONTROL, vernatherm 1/4 x 5/8" hex-hd cap SCREW (2) 1/4" lock WASHER (2)
9 10	102 776 H 107 761	PIN, rod end PIN, 1/16 x 3/4" cotter
11	316 063 R11	ROD w/CLEVIS, overtravel
12	103 373	PIN, 3/32 x 3/4" cotter (2)
13	61 635 D	SPRING, return
14	316 06 <b>5</b> Rl	CLIP, return spring
15	300 415 R1	SPRING, overtravel
16		WASHER, 9/32 x 5/8" x No. 16 ga. (2)
17	317 554 R91	LEVER ASSY, throttle shaft (3)
18	268 296 R91	COLLAR w/SCREW, 36 756 D, throttle shaft (3)
19	36 756 D	SCREW, set (4)
20	332 488 R91	STOP w/rwo SCREW, 11 189 V, throttle
	11 189 V	SCREW, throttle stop adjusting (2)
21	316 046 R4Z	BODY ASSY. flo-matic valve (Composed of - § 1 BODY 4 BUSHING 347 001 R1 § 2 DISC 2 SHAFT 612 179 C1 4 SCREW 4 WASHER )
22	347 001 R.I	BUSHING, throttle shaft (4)
23	321 881 R91	SEAL, water (4)
24		DISC, throttle (Not Furnished Separately)
25	612 179 CL	SHAFT, flo-matic valve (2)
26		SCREW. No. 6 x 7/16" sit-fil-hd (4) No. 6 lock WASHER (4)
27	103 879	PLUG. 3/8" sq-hd pipe
28	316 049 RI	LINK, throttle shaft lever
29	103 373	PIN, 3/32 x 3/4" cotter (2) 9/32 x 5/8" x No. 16 ga. WASHER (2)

GASKET, flo-matic valve

5/16" lock WASHER (4)

PRINTED IN UNITED STATES OF AMERICA

SUPPORT, flo-matic valve (2) 5/16" NUT (4) 5/16 x 1-1/2" hex-hd cap SCREW 5/16 x 1-1/4" hex-hd cap SCREW (3)

316 048 R1

323 847 RI

30

31

## -73-**ATTACHMENTS**

		ATTACHMENTS
REF. NO.	L.H. PART NUMBER	<b>Seacetr</b> Y.≎H
FLO-	MATIC VALVE -	Сонтимер
32	323 850 R1	BRACKET, return spring 5/16" NUT 5/16 x 7/8" hex-hd cap SCREW 5/16" lock WASHER
	323 849 R92	VALVE ASSY, flo-matic  (Composed of -  1 BODY 316 046 R42  1 BRACKET 323 850 R1  2 CLAMP 316 065 R1  3 COLLAR 268 296 R91  1 CONTROL 346 637 R91  1 ELBOW 177 807 R1  3 LEVER 317 554 R91  1 LINK 316 049 R1  2 NIPPLE 171 819 R1  1 PIN 102 776 H  4 PIN 103 373  1 FIN 107 761  1 PLUG 103 879  1 ROD 316 063 R11  1 SCREW 36 756 D  4 SEAL 321 881 R91  1 SPRING 61 635 D  1 SPRING 61 635 D  1 STOP 332 488 R91 )
		1 इत्य
		et e la la la la la la la la la la la la la
		* · ·
		<ul> <li>Not Furnished Separately.</li> <li>NOTE 1 - Factory Application - Order On Machine Order Form.</li> <li>NOTE 3 - Field Application - Order Through Regular Service Parts Channels.</li> </ul>

100

#### ATTACHMENTS


-74-

\_\_\_\_


FAN - CONTINUED

ATTACHMENTS






Suction Fan Standard




Suction Fan Tropical



Blower Fan

I.H. PART



Suction Fan

DESCRIPTION

A - Service parts for suction fan (standa:	dia. 6 l and 3)
- 1800 to 2400 rpm)  B - 304 576 R91 ATTACHMENT, suction fan (tropical ed cooling - 1800 to 2400 rpm) (order 320 165 R91)  C - 304 549 R93 ATTACHMENT, blower fan (18-1/2" blade w/1.00" spacer) (See NOTES  D - 316 168 R91 ATTACHMENT, blower fan (18" dia. w/1.00" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  E - 316 170 R91 ATTACHMENT, suction fan (18" dia. w/1.38" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  F - 320 165 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.38" spacer) (will work for 304 576 R91) (See NOTES 1 and 3)  G - 320 166 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.62" spacer) (for use with single "B" sheave suciliary drive pu ATTACHMENT, 318 002 R91) (See 1	dia. 6 l and 3)
ed cooling - 1800 to 2400 rpm) (order 320 165 R91)  C - 304 549 R93 ATTACHMENT, blower fan (18-1/2" blade w/1.00" spacer) (See NOTES  D - 316 168 R91 ATTACHMENT, blower fan (18" dia. w/1.00" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  E - 316 170 R91 ATTACHMENT, suction fan (18" dia. w/1.38" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  F - 320 165 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.38" spacer) (will work for 304 576 R91) (See NOTES 1 and 3)  G - 320 166 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.62" spacer) (for use with single "B" sheave suxiliary drive pu ATTACHMENT, 318 002 R91) (See 1 and 3)	dia. 6 l and 3) 6 blade
blade w/1.00" spacer) (See NOTES  D - 316 168 R91 ATTACHMENT, blower fan (18" dia.	l and 3) 6 blade
w/1.00" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  E - 316 170 R91 ATTACHMENT, suction fan (18" diaw/1.38" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 0 (See NOTES 1 and 3)  F - 320 165 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.38" spacer) (will work for 304 576 R91) (See NOTES 1 and 3)  G - 320 166 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.62" spacer) (for use with single "B" sheave succliary drive pu ATTACHMENT, 318 002 R91) (See 1 and 3)	
w/1.38" spacer) (for use with 48 H. ible coupling ATTACHMENT, 318 00 (See NOTES 1 and 3)  F - 320 165 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.38" spacer) (will work for 304 576 R91) (See NOTES 1 and 3)  G - 320 166 R91 ATTACHMENT, suction fan (18-1/2" blade w/1.62" spacer) (for use with single "B" sheave auxiliary drive pu ATTACHMENT, 318 002 R91) (See 1 and 3)	04 R91)
G = 320 166 R91 ATTACHMENT, suction fam (18-1/2" blade w/1.62" spacer) (for use with single "B" sheave auxiliary drive pu ATTACHMENT, 318 002 R91) (See N 1 and 3)	P. flex-
blade w/1.62" spacer) (for use with single "B" sheave auxiliary drive pu ATTACHMENT, 318 002 R91) (See 1 and 3)	dia.6 r
	6.75" Lley
H - 323 768 R91 ATTACHMENT, blower fam (18-1/2" blade w(1.31" spacer) (for use with drive pulley ATTACHMENTS, 318 0 318 002 R91 or 318 003 R91) (See NC and 3)	auziliary 01 R91.
(X) - Letters of these units correspond with those shown for the description of the parts in the list below and iden the unit for which the part is used. Items without le after the description indicates the part is used for all	tifics
1 86 898 R91 FAN, suction (standard) (18-1/2" dia (optional with 82 796 R91) (Unit A)	. 4 blades
! 82 796 R91 FAN, suction (standard) (18-1/2" dia blades) (optional with 86 898 R91) (U 1/4 x 2-1/8" hex-hd cap SCREW (4 1/4" lock WASHER (4)	nit A)
Z 267 450 R91 FAN. suction (tropical) (18-1/Z" dia. (optional with 371 633 R91) (Unit B)	5 blades)

.,,,,,,		
3	306 355 R91	FAN, blower (18-1/2" dia. 6 biades) (Units C and H)
3	317 7 <b>2</b> 0 R91	FAN, blower (18" dia. 6 blades) (Unit D) 1/4NF x 1-5/8" hex-hd cap SCREW (4 for Unit D) 1/4NF x 2" hex-hd cap SCREW (4 for Unit H) 1/4NF x 2-1/4" hex-hd cap SCREW (4 for Unit C) 1/4" lock WASHER (4)
4	317 719 R91	FAN, suction !18" dia. 6 blades) (Unit E)
4	321 565 R91	FAN, suction (18-1/2" dia. 6 blades) (Units F and G) 1/4NF x 2" hex-hd cap SCREW (4 for Unit E) 1/4NF x 2-1/4" hex-hd cap SCREW (4 for Unit F) 1/4NF x 2-1/2" hex-hd cap SCREW (4 for Unit G) 1/4" lock WASHER (4)
	316 1 <b>6</b> 9 R1	SPACER, fan (1.00") (Units C and D)
	574 100 R1	SPACER, fam (1.31") (Unit H)
	304 575 RI	SPACER, fan (1. 38") (Units B, E and F) 304 575 R1 SPACER, fan (1. 38") (Units B, E and
	318 008 R1	SPACER, fam (1.62") (Unit G)

NOTE : Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

1/4" lock WASHER (4)

371 633 R91

FAN, suction (tropics1) (18-1/2" dia. 5 blades) (optional with 267 450 R91) (Unit B) 1/4 x 2-1/8" hex-hd cap SCREW (4)

-75-


### **ATTACHMENTS**



# -75-ATTACHMENTS

FAN BELT IDLER (Not used with Generator)

FAN BELT IDLER - CONTINUED (Not used with Generator)



NET. NO.	I. H. PART Number	DESCRIPTION
	312 959 R91	ATTACHMENT, fan beit idler (see Notes i and 3)
ı	312 056 RI	SUPPORT, idler pulley adjusting arm 13/32 x 13/16 x 1/16" ga. WASHER (2)
z	312 055 RI	ARM, idler pulley adjusting  3/8 x 1" hex-hd cap SCREW  5/16 x 1" hex-hd cap SCREW  13/32 x 13/16 x 1/16" ga WASHER  3/8" lock WASHER  5/16" lock WASHER

HO.	I. H. PART Number	DESCRIPTION
3	133 50Z R1	RING, snap
4	ST 633	BEARING, idler pulley shaft
5	312 054 R1	PULLEY, idler
	30 <b>5 177 R</b> I	BELT, water pump and generator fan


#### ATTACHMENTS



#### ATTACHMENTS

ENGINE SUPPORT





MEF. NO.	(.H.PART HUMBER	DESCRIPTION
	332 190 R91	ATTACHMENT, engine support (for use with expansion tank and connections) (not used on gasoline and gasoline high altitude engines equipped with hydraulic pump) (see NOTES 1 and 3)
ı	320 015 R93	BASE, box type
2	332 191 R11	SUPPORT, from:  1/2" NUT (2)  5/8" NUT (4)  5/8 x 4-1/2" hex-hd cap SCREW (4)  1/2 x 1-3/4" hex-hd cap SCREW (2)  1/2" lock WASHER (2)  5/8" lock WASHER (4)


REF. No.	I.H.PART Number	DESCRIPTION
	332 180 R1	SPACER, rear support (2) 3/4" NUT (2) 3/4 x 2-1/4" hex-hd cap SCREW (2) 3/4" lock WASHER (2)
ı	304 543 RII	SUPPORT, rear 1/2 x 1" hex-hd cap SCREW (8) 1/2" lock WASHER (8)

-77-

# **ATTACHMENTS**

# -77-**ATTACHMENTS**

HOOD SIDE DOOR



HOOD SIDE DOOR - CONTINUED

NO.	(, H, PART Number	DESCRIPTION
	268 227 R91	ATTACHMENT, hood side doors (See NOTES   and 3)
1	268 228 R11	DQQR, hood side (Z)

ND,	V.H. PART	DESCRIPTION
2	268 230 R11	SHEET, hood side (2) 3/8" NUT (8) 3/8 x 3/4" hex-hd. cap SCREW (8) 3/8" lock WASHER (8)
3	353 443 R91	LATCH, hood side door (4) 3/16 x 5/16" f-hd. RIVET (8)

NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

#### **ATTACHMENTS**




### -78-ATTACHMENTS

#### CHOMETER AND TACHOURMETER



#### TACHOMETER AND TACHOURMETER - CONTINUES



MEF. NO.	J. H. PART NUMBER	DESCRIPTION	MEF. NO.	I, H, PART Number	DESCRIPTION
		Parts without letters after the description indicate the part is used for all attachments listed below: Letters A, B and C are used to identify separate attachments and service parts list.	5	73 163 H	CLIP, tachometer or tachourmeter drive cable 1/4" NUT 1/4 x 1/2" hex-hd cap SCREW 1/4" lock WASHER
	306 686 R91	ATTACHMENT, tachometer (mechanical) (for daits equipped with dash) (order 349 134 R92) (+)	6	56 787 RI	EXTENSION, tachometer or tachourmeter drive cable clip
В	306 687 R91	ATTACHMENT, tachometer (mechanical) (for units not equipped with dash) (order 349 134 R92) (+)	7	328 637 RI	BRACKET, tachometer mounting plate (Attachment B) 3/8" NUT (2) 3/8 x 1" hex-hd cap SCREW (2) 3/8" lock WASHER (2)
С	349 134 R92	ATTACHMENT, tachourmeter (mechanical) (combination tachourmeter and service meter with correction factor dial) (for use with Novi mechanical governor and instrument and instrument panel ATTACHMENTS, 349 132 R91 and 349 133 R91) (see NOTES 1 and 3)	8	281 801 R.I.)	PLATE w/three GROMMET, 281 802 R91, tachometer mounting (Attachments A and B) No. 8 NUT (3) No. 8 X I" sit-rd-hd mach SCREW (3) No. 8 lock WASHER (3): 11/64 x 13/32" x 18 ga. WASHER (6)
1	368 245 R1Z	GEAR, tachometer or tachourmeter drive			,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
2	368 246 R1	HOUSING, tachometer or tachourmeter connection	10	281 802 R91	GROMMET, tachometer mounting (3 for Attachments A and B) 1/8 x 1/4" rd-hd solid RIVET (6)
3	63 364 H	ADAPTER, box type (1.440 ratio)			**************************************
4	306 394 R91	CABLE, tachometer or tachourmeter drive	11	338 595 R91	TACHOURMETER
4	306 398 R91	(optional with 306 398 R91) CABLE, tachometer or tachourmeter (optional with 306 394 R91)		263 Z97 RZ	CLAMP, tachometer or tachourmeter No. 10 NUT (2) No. 10 lock WASHER (2)

(\*) - Attachment No Longer Available. Service
Parts Only Will Be Furnished.

NOTE 1 - Factory Application - Order On
Machine Order Form.


NOTE 3 - Field Application - Order Through
Regular Service Parts Channels.

## -79-ATTACHMENTS



## -79-**MEMORANDA**

#### HOURMETER



REF. NO.	i. H. PART Number	DESCRIPTION
		Parts without letters after the description indicate the part is used for all attachments listed below: Letters A, B and C are used to identify separate attachments.
A	305 ZOZ R91	ATTACHMENT, hourmeter (for units equippe with dash) (+)
В	305 203 R91	ATTACHMENT, hourmeter (for units not equipped with dash) (+)
С	349 136 R91	ATTACHMENT, hourmeter (for use with instrument and panel ATTACHMENTS, 349 13Z R91 and 349 13Z R91) (see NOTES 1 and 3)
1	310 820 R91	HOURMETER No. 6 x 5/16" sli-rd-hd mach SCREW (3) No. 6 lock WASHER (3)
z	264 674 R <b>9</b> 1	DAMPER, hourmeter vibration (Attachments A and B) No. 6 x 1/2" slt-rd-hd mach SCREW (3) No. 6 lock WASHER (3)
3	305 201 R1	PLATE, hourneter mounting (Attachment B) 3/8" NUT 3/8 x 1" hex-hd cap SCREW 3/8" lock WASHER
4	305 199 R91	CABLE, hourmeter to ignition switch (Attachments A and B)
4	271 066 R92	CABLE, hourmeter (Attachment C)
5	267 807 R91	CABLE, hourmeter to ground screw 3/8" internal-tooth lock WASHER (Attachments A and B)


(+) - Attachments No Longer Available. Service Parts Only Will Be Furnished.
 NOTE 1 - Factory Application - Order On Machine Order Form.
 NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

-80-ATTACHMENTS

ATTACHMENTS

NSTRUMENTS AND PANEL
Not used with units equipped with Automatic Safety-

INSTRUMENTS AND PANEL - Continued (Not used with units equipped with Automatic Safety-Shut-Off)



MO.	NUMBER	DESCRIPTION
(X) -	KEY TO UNITS	•
A -	305 191 R91	ATTACHMENT, instruments and panel (Battery Ignition) (+)
В-	312 062 R91	ATTACHMENT, instruments and panel (Magneto Ignition) (For units equipped with cranking motor and generator) (+)
Ċ-	312 063 R91	ATTACHMENT, instruments and panel (Magneto Ignition) (For units not equipped with cranking Motor and generator) (+)
D -		Service parts for instruments and panel (Battery Ignition) (for units equipped with Hydraulic Pump)
(X) -	Latters of these	t write comment of the state of

(X) - Letters of these units correspond with those shown following the description of the parts in the list below and identifies the unit for which the part is used. Items without letters after the description indicates the part is used for all units.

REF. I.H.PART NO. NUMBER		DESCRIPTION		
1	304 585 R11	BRACKET, instrument panel mounting (2) 3/8" NUT (2) 3/8 x 3/4" hex-hd cap SCREW (4) 3/8" lock WASHER (4)		
2	304 586 R1	HOUSING, instrument panel		
3	278 597 R2	PANEL, instrument 1/4 x 1/2" rd-hd sltd SCREW (4) 1/4" lock WASHER (4)		
4	269 103 R91	AMMETER (also listed with "Electric Starting") (Units A, B and D)		
		(+) - Attachment No Longer Available Ser- vice Parts Only Will Be Furnished.		

I. H. PART Humber -81-

DESCRIPTION

## ATTACHMENTS

ıÖ.

### -81-MEMORANDA

NQ.	HUMBER	
INSTR (Not u	UMENTS AND PA	ANEL - Continued quipped with Automatic Safety Shut-Off)
5	432 577	PLUG, instrument panel button (2 for Units A, B and D) (3 for Unit C)
6	304 587 R1	TUBE, oil pressure indicator
7	369 987 R1	NUT, tube (nylon) (2)
8	67 869 D	ELBOW, oil pressure indicator tube (in gauge)
9	62 801 DC	SWITCH, ignition (also listed with "Electric Starting") (Units A and D)
9	54 207 DB	SWITCH, ignition (magneto) (also listed with "Electric Starting") (Units B and C)
10	313 177 R91	INDICATOR, oil pressure (Units A. B and C)
10	313 177 R91	INDICATOR, oil pressure (Unit D)
11	59 109 D	SPACER, ignition switch
12	26 242 D	FELT, heat indicator cable clip (Units B. C and D)
13	254 275 R1	CLIP, heat indicator cable (Units B, C and D) 3/8" NUT 3/8 x 3/4" hex-hd cap SCREW 3/8" lock WASHER
14	273 602 R91	INDICATOR, heat (Units A, B and C)
14	67 136 D	INDICATOR, heat (Unit D)
15	366 317 R <b>9</b> 1	SWITCH, starting (also listed with "Electric Starting") No. 10NF sq NUT No. 10NF x 7/16" rd-hd sltd mach SCREW (2) No. 10 lock WASHER (2)
	62 862 D	CABLE, ignition switch to magneto (also listed with "Electric Starting") (Unit C)
	264 164 R91	GLIP, cable harness (also listed with "Electric Starting") (2)
	29 901 D	CONNECTOR, oil pressure indicator tube (in crankcase)
	305 19 <b>2</b> R91	HARNESS, cable (Illustrated with "Electric Starting") (Unit A)
	312 061 R91	HARNESS, cable (Illustrated with "Electric Starting") (Unit B)

316 160 R91 HARNESS, cable (Unit D)


-82-ATTACHMENTS

ATTACHMENTS

-82-

INSTRUMENTS, INSTRUMENT PANEL AND INSTRUMENT
PANEL MOUNTING

INSTRUMENTS, INSTRUMENT PANEL AND INSTRUMENT PANEL MOUNTING -- CONTINUED



-83-

#### -83-

### **ATTACHMENTS**

		· · · · · · · · · · · · · · · · · · ·	
REF.	I. H. PART	口をおります。	
1402			

INSTRUMENTS, INSTRUMENT PANEL AND INSTRUMENT PANEL MOUNTING — CONTINUED

١		Parts without letters after the description indicates the part is used for all attachments listed below: Letters "A," "B," and "C" are used to identify separate attachments.
<b>A</b>	349 132 R91	ATTACHMENT, instruments and instrument panel (regular gauges) (for use on units equipped with Instrument Panel Mounting Attachment, 349 127 R91) Tachourmeter Attachment, 349 134 R92 or Hourmeter Attachment, 349 136 R91) (see NOTES 1 and 3)
В	349 133 R91	ATTACHMENT, instruments and instrument panel (safety gauges) (for use on units equipped with Instrument Panel Mounting Attachment, 349 127 R91, Tachourmeter Attachment, 349 134 R92 or Hourmeter Attachment, 349 136 R91) (see NOTES 1 and 3)
С	349 127 R91	ATTACHMENT, instrument panel mounting (for use on units equipped with Instruments and Instrument Panel Attachment, 349 132 R91 or Instruments and Instrument Panel Attachment, 349 133 R91) (see NOTES 1 and 3)
ι	337 113 R11	FRAME, instrument panel (Attachment C) 3/8" NUT (4) 3/8 x 3/4" hex-hd cap SCREW (4) 3/8" lock WASHER (4)
2 .	337 354 R3	PANEL, instrument (Attachments A and B)
3	370 940 R11	COVER, tachometer opening (Attachments A and B) (Not used with Tachourmeter attachment)
4	269 103 R91	AMMETER (Attachments A and B)
5 6	432 577 432 582	PLUG. 2-3/32" button (attachments A and B) PLUG, 2-1/4" button (Attachments A and B)
7	346 597 R91	INDICATOR, heat (Attachment A)
8	347 602 R91	INDICATOR, safety heat (Attachment B)
9	347 601 RI	ADAPTER, heat indicator (Attachment C)
10	327 1 <b>44 R91</b>	SWITCH, ignition and starting (Attachments A and B)
11	347 604 R91	INDICATOR, safety oil pressure (Attachment B)
12	313 177 R91	INDICATOR, oil pressure (Attachment A)
13	9 409 923	ELBOW, 1/8" x 90" (Attachments A and B)
14	336 419 R91	MOUNT, vibration (Attachments A and B)
15		WASHER, No. 10 lock (4 for Attachments A and B)
16		SCREW, No. 10 x 3/4" rd-hd mach (4 for Attachments A and B)
17	337 112 Rl	BRACKET, instrument panel (2 for Attach- ment C) 3/8" NUT (4) 3/8 x 3/4" hex-hd cap SCREW (4) 3/8" lock WASHER (4)
18	346 592 R91	HOSE w/two FITTING, oil pressure indicator (HOSE, 19" ID x 17" long including FITTINGS (Attachment C)
19	118 753	ELBOW, 1/4" x 90° oil pressure hose (Attachment C)
		CHATED IN UNITED STATES OF AMERICA

### **ATTACHMENTS**

NO.	), H. PART HUMSER	DESGRIPTION
INSTE	RUMENTS, INSTR L MOUNTING — C	RUMENT PANEL AND INSTRUMENT
	42 915 D	BLOCK. junction (Attachment B) (%)
	42 917 D	BLOCK, w/BLOCK, 42 915 D and BRACKET, 42 916 D, junction (eptional with 352 110 R91) (Attachment B) (%)
	352   10 R91	BLOCK w/BLOCK, 42 915 D and BRACKET, 42 916 D, junction (optional with 42 917 D) (Attachment B) (%) No. 8 NF NUT (cd or sn-pike)
	ادر در در این میرسون	1/8" NUT 3/8 x 1/2" hex-hd cap State No. 8 ins tooth lock WASHER 3/8" lock WASHER
	42 916 D	BRACKET, junction block (All compat B) (%) No. 10NUT No. 10 x 1/2" slt-hd mach SCREW
		No: 10 lock-WASHER
	63 713 DA	CABLE, relay to ignition switch (Attachment B) (%)
	274 747 R91	CABLE, safety control to junction block (Attachment B) (%)
	274 747 R91	(Attachment B) (%)
	264 164 RI	CLIP, regulator cable (Attachment C)
	327 071 R1	CLIP, capillary tube (Attachment C)
	263 308 R1	CLIP, cranking motor cable harmess (Attachment C) (*)
	370 535 RI	CLIP, ignition cable (Attachment C)
	349 128 R91	HARNESS, cranking motor cable (Attach- ment C) (*)
	349 129 R91	HARNESS, ignition cable (Attachment C) (*)
	349 130 R91	HARNESS. regulator cable (Attachment C) (*)
	2 752 445 R1	PRODUCT GRAPHIC, safety control switch escutcheon (Attachment B)
	606 069 C91	RELAY, ignition cutout (Attachment B) (%)
	603 884 C91	SWITCH, safety control toggle (optional with 253 818 R91) (Attachment B) (%)
	253 818 R91	SWITCH, safety control toggle (optional with 603 884 C91) (Attachment B.
		A CONTRACTOR OF THE CONTRACTOR
		e en en en en en en en en en en en en en
		NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.
		% - Also Listed And Illustrated With "Electric Wiring (Safety Gauges)."

\* - Also Listed And Illustrated With "Electric Wiring (Regular Gauges)."


-84

### **ATTACHMENTS**

Ô

### -84-ATTACHMENTS

ER TAKE-OFF kford) C-221 Regular Duty) (UC-263 Light Duty) POWER TAKE-OFF - Continued (Rockford) (UC-221 Regular Duty) (UC-263 Light Duty)



REF.	I.H. PART NUMBER	DESCRIPTION	REF. NO.	I. H. FART NUMBER
	273 017 R91	ATTACHMENT, power take-off, 319 503 R91 w/BEARING, 305 861 R91 (UC-221 regular	1	273 231 R1
		duty) (UC-263 light duty) (with 10" single plate over-center drive ring type clutch) (See NOTES 1 and 3)	2	273 230 R1
		•••	3	273 233 R1
`		NOTE 1 - Factory Application - Order on Machine Order Form. NOTE 3 - Field Application - Order through	4	255 663 R1
		Regular Service Parts Channels.	5	266 68Z R1

NO.	NUMBER	DESGRIFTION		
1	273 231 R1	NUT, hex. (PT-73Z-Z)		
2	273 230 R1	WASHER, lock (PT-733-3)		
3	273 233 R1	BODY, clutch (GL-8490-10)		
4	255 663 R1	RING, driving (CL-6951)		
5	266 68Z R1	FACING, clutch (CL-6952)		
		· · · · · · · · · · · · · · · · · · ·		

ATTACHMENTS

-85-

## ATTACHMENTS

POWER TA Rockford (UC-221 F	Regular Duty	ONTINUED ) (UC-Z63 Light Duty)  PLATE w/LOCK, Z68 869 1 (UCL-9520)  LOCK, adjusting (CL-8516  NUT, adjusting (CL-8494-		/Rocks	R TAKE-OFF - ( ford) 21 Regular Duty	Сонтичес y) (UC-263 Light Duty)
7 26	68 869 R1 47 871 R1 47 872 R1	(UCL-9520) LOCK, adjusting (CL-8516		33		
	47 871 R1 47 872 R1		-1)		266 662 R1 124 553	SHAFT, yoke (PT-201) KEY, (Woodruff, No. 15) (PT-351) (2)
	47 871 R1 47 872 R1			34		LEVER. shifting (UPT-87)
			1)	35	266 666 R91 305 861 R91	BEARING, clutch pilot (optional with
	66 704 R1	PLATE, adjusting ring (CI	-11361)		303 661 K31	338 543 R91)
		SPRING. separator (CL-85	541) (3)		338 543 R91	BEARING, clutch pilot (optional with 305 861 R91)
	68 865 R91	SPRING, lever (CL-9465)			273 255	FITTING, lubrication (Alemite 1743B) (2)
	66 697 R1	PIN, clevis (CL-8400) (6)			258 370 R1	NUT, 5/16NF, elastic stop (Esna)
	66 698 R1	RING, retaining (CL-7130)	(6)		258 370 KI	(CL-7356) (2)
•	68 8 <b>66</b> R1	LEVER (CL-8556-1) (3)			319 531 R1	LOCK, positive (GL-9216-1)
	166 694 R1	PIN. clevis (CL-8484) (3)			319 503 R91	POWER TAKE-OFF w/10" over-center dutch assembly (PTA-31036) (will work for
	266 69 <b>6 R1</b>	Link, connecting (CL-855	7) (6)			273 015 R91) (Composed of "
	255 395 R1	RING. retaining (CL-7107)				1 CLUTCH 273 232 R91 2 CONE 13 396 DC
	273 235 R1	SLEEVE, release (CL-855				2 CUP 13 390 D 3 FITTING 109 461
*.	273 236 R91	BEARING w/two NUT. 250 PLUG, 103 883, release	8 370 R1 and			2 FITTING 273 255 1 GASKET 266 656 R1 1 HOUSING 273 238 R1 2 KEY 124 553
19 2	273 232 R91	CLUTCH ASSEMBLY, 10' (Composed of -  1 BODY 1 FACING 3 LEVER 1 LOCK 6 LINK 1 NUT 3 PIN 6 PIN 1 PLATE 1 PLATE 1 PLATE 3 RING 6 RING 6 RING 1 SCREW 1 SLEEVE W/BEARING	273 233 R1 266 682 R1 268 866 R1 319 531 R1 266 696 R1 347 871 R1 266 697 R1 268 697 R1 268 958 R91 347 872 R1 255 395 R1 255 395 R1 266 698 R1 19 559 R1 273 234 R91		103 883	KEY
		3 SPRING 1 SPRING	266 704 R1 268 865 R91)			SCREW, 1/4 x 3/8" rd-hd, mach. (2) SCREW, 1/4 x 3/8" fil-hd.
20	321 481 R1	PLATE, instruction (PT-	-1593)			SCREW, 3/8 x 1-1/4" hex-hd. cap (2)
Z1	266 656 R1	GASKET, cover (PT-770)	)			SCREW, 5/16 x 1/2" hex-hd, cap
22	273 238 R1	HOUSING, clutch (PT-99.	3-1)			SCREW. 1/2 x 1-3/4" hex-hd. cap
23 23	13 396 DC 13 390 D	CONE, tapered roller be CUP, tapered roller beau	aring (390) (2) ring (394A) (2)			SCREW, 5/16NF x 1-3/4" hex-hd. cap (Z)
24	109 461	FITTING, 1/8", plug pip	e (Lincoln 5000) (3)			SCREW. 5/16 x 1/4" f-pt. set.
25	266 667 R91	TUBE, flexible (PT-1026	5-1)		19 559 R1	SGREW. 1/4 x 3/8" hex-hd cap (CL-8807-1)
26		NUT. 5/8NF			273 234 £91	SLEEVE, 273 235 R1, w/release BEARING 273 236 R91 (UCL-3-8558)
27	319 536 RI 103 883	SHAFT, drive (PT-1356. PLUG, 1/8" pipe	-3)			WASHER, 5/16" lock
28	266 668 R1	KEY (PT-781) KEY (PT-884)				WASHER, 3/8" lock (2)
29	266 660 R1	RETAINER, bearing (PT	:-72 <b>7</b> }			WASHER, 1/2" lock
30 31	266 661 R1	PLATE, lock (PT-44)	•			WASHER, 1/4" (Shakeproof)

266 665 R91

32

-86-


**ATTACHMENTS** 




**ATTACHMENTS** 

-86-

WER TAKE-OFF WITH EXTENDED SHAFT POWER TAKE-OFF WITH EXTENDED SHAFT - Continues (Rockford)





-87-

## **ATTACHMENTS**

|--|

### **ATTACHMENTS**

π <b>ε</b> ₽.	1. H, FART NUMBER	DESCRIPTION	REF. NO.	I.H.PART NUMBER	DESCRIPTION
	R TAKE-OFF WI	TH EXTENDED SHAFT - CONTINUED		ER TAKE-OFF WI (ford)	TH EXTENDED SHAFT - Continued
		ATTACHMENT, power take-off w/extended		266 656 R1	GASKET, cover (PT-770)
	304 535 R91	= abaft (11=1/Z" overcenter drive r	/extended 21 ring type 22	273 240 R1	HOUSING, clutch (PT-817-2)
		clutch) (See NOTES 1 and 3) (Composed of -		13 396 DC	CONE, tapered roller bearing (Z)
		1 BEARING 305 861 1 BLOCK 304 485	R91	13 390 D	CUP, tapered roller bearing (2)
		1 BRACKET 304 573 1 FOWER			FITTING, lubrication (3)
		TAKE-OFF 319 519 1 SPACER 265 636	S RI	109 461 266 667 R91	TUBE, flexible (PT-1026-1)
		1 SHIM 304 539 1 SHIM 304 540 1 SHIM 304 541	RI		NUT, 5/8NF (CL-4355)
			27	273 209 RI	SHAFT, drive (PT-1466)
ı	266 681 R1	NUT, drive shaft (PT-732)	28	268 864 R1	KEY, 3/8 x 3/8 x 3-1/2" (PT-1307)
z	273 212 R1	WASHER, drive shaft lock (PT-73	33- <b>4</b> ) 2 <del>9</del>	268 863 R1	KEY. 5/8 x 11-1/2" (PT-1308)
3	273 Z14 R1	BODY, clutch (CL-8498-7)	30	273 211 R1	KEY, 3/8 × 3/8 × 2-1/4" (PT-1363)
4	Z67 065 R1	RING, driving (CL-6950)	31	266 660 R1	RETAINER, bearing (PT-727)
5	338 903 RI	FACING. clutch (CL-6953-52)	32	266 661 RI	PLATE, lock (PT-44)
		PLATE, w/LOCK, 319 531 RI, p		273 210 R91	YOKE, clutch (UPT-726-1)
6	268 861 R91	(UC-9518)	34	266 663 R1	SHAFT, yoke (PT-822)
7	319 531 R1	LOCK, positive (CL-9216)	35	124 553	KEY (PT-351) (2)
_		NUT. adjusting (CL-8494-1)		266 666 R91	LEVER, shifting (UPT-87)
8	347 871 R1	PLATE, adjusting ring (CL-1186	36	304 485 R91	SLOCK W/BEARING, 305 166 R91 and
8A	347 872 RI				FITTING, 109 461, outboard bearing pillow (optional with 304 486 R91)
9	266 704 R1	SPRING, separator (CL-8541) (3)	, 37	304 486 R91	BIOCK W/BEARING, 305 167 R91, outboard
10	Z68 865 R91	SPRING, lever (CL-9465)	31	301 400 2271	bearing pillow (Optional with 304 485 K91)
11	266 697 R1	PIN. clevis (CL-8400) (6)			1/2 x 2" hex-hd cap SCREW (2) 1/2" lock WASHER (2)
12	266 698 R1	RING, retaining (CL-7130) (6)			$17/32 \times 1-11/16$ " x 13 ga. WASHER (2)
13	268 866 R1	LEVER (CL-8556-1) (3)	38	305 166 R91	BEARING w/locking COLLAR
14	266 694 R1	PIN, clevis (CL-8484) (3)	38	305 167 R91	BEARING w/locking COLLAR
15 16	266 696 RI 255 <b>395</b> RI	LINK, connecting (CL-8557) (6) RING, retaining (CL-7107) (3)	39	304 539 R1	SHIM, outboard bearing (beavy)
17	273 217 R1	SLEEVE, release (CL-8630-3)		304 540 R1	SHIM, outboard bearing (medium) (2)
17	273 216 R91	SLEEVE, 273 217 R1 w/BEARIN 273 218 R91) (UCL-2-8630-3)	41	304 541 Rl	SHIM. outboard bearing (light) (x)
18	273 218 R91	BEARING w/two NUT, 19 503 R	l and and one	304 537 R11	
		PLUG. 103 883, release (UCL-	-5-6979) 42	304 337 2011	
19	273 215 R91	(Composed of -		305 861 R91	BEARING, clutch pilot (optional with 338 543 R91)
		1 FACING 338 9 3 LEVER 268 8 6 LINK 266 6	14 R1 03 R1 66 R1 96 R! 71 R1	338 543 R91	BEARING, clutch pilot (optional with 305 861 R91)
		3 FIN 266 6 6 FIN 266 6 1 FLATE 268 8	94 RI 97 RI 161 R91 172 RI	273 355	FITTING, hydraulic lubricator (1/4" drive type) (2)
		3 RING 255 3 6 RING 266 6	95 R1 98 R1 965 R1	19 503 Rì	NUT, 5/16NF elastic stop (2)
		3 SPRING 266 7	216 R91 704 R1 365 R91 )		NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.
		PLATE, instruction (PT-1593)			x - Four Or More As Required.

I. M. PART

-88-

#### ATTACHMENTS

DESCRIPTION

Ű

#### MEMORANDA

-		H-Q-MINE, A			
	" <del>.</del>		WIND EVERNOED	CHAET -	C
			WITH EXTENDED	SHAF! -	CONTINUE
	"cocktore	i)			

319 519 R91 POWER TAKE-OFF w/extended SHAFT ASSY.
(PTA-31140) (Willwood for 304 493 R91)
(Composed of -

CLUTCH 273 215 R91 CONE 13 396 DC CUP 13 390 D 109 461 273 355 FITTING FITTING GASKET HOUSING 266 656 R1 273 240 R1 KEY Z68 863 R1 KEY 124 553 268 864 R1 KEY 273 211 R1 266 666 R91 LEVER NUT 266 681 RI PLATE PLATE RETAINER 321 481 R1 266 661 R1 266 660 R1 SHAFT 273 209 R1 SHAFT 266 663 R1 266 667 R91 TUBE WASHER YOKE 273 210 R91 ) 3/8 x 1-1/8" hex-hd cap SCREW (12) 3/8 x 1-1/2" hex-hd cap SCREW (8) 3/8" lock WASHER (20)

103 883 PLUG. 1/8" slt-hd slt pipe (release bearing)

SCREW, 5/16NF x 2" hex-hd cap (release bearing) (2)

SCREW,  $3/8 \times 1-1/4^{\circ}$  hex-hd cap (clutch yoke) (2)

SCREW, 1/4 x 3/8" fil-hd mach (pressure plate)

SCREW, 5/16 x I/4" fl-pt set (clutch housing)

SCREW,  $1/4 \times 3/8$ " rd-hd mach (instruction piate) (2)

SCREW, 5/16 x 1/2" hex-hd cap (lock plate)

SCREW, 3/8 x 1-1/2" hex-hd cap (shifting lever)

265 636 R1 SPACER, clutch pilot bearing

WASHER, 3/8" lock (clutch yoke) (3)

WASHER, 1/4" (Shakeproof) (pressure plate)

WASHER, 5/16" lock (lock plate)

-89-

-89-MEMORANDA

Ô

MEMORANDA

QWER TAKE-OFF ckford)


:-263 Regular Duty)

ATTACHMENTS



# ATTACHMENTS

POWER TAKE-OFF - CONTINUED (Rockford) (UC-263 Regular Duty)



ſ₽	<b>6</b> -7	2	30	¢

NO.	I. H. PART NUMBER	PESCRIPTION									
	273 019 R92	ATTACHMENT. power take-off, 319 524 R91 w/BEARING. 305 861 R91 and SPACER, 265 636 R1 (UC-263 Regular Duty) (with 11-1/2" single plate over-center drive ring type clutch operating at 2200 RPM or below) (See NOTES! and 3)									
	266 681 R1	NUT. 2-3/16-12, hex. (PT-732)									

REF.	A.H. FART	
NO, NUMBER		DESCRIPTION
z	273 212 R1	WASHER, lock (PT-733-4)
3	273 214 R1	BODY, clutch (CL-8498-7)
4	267 065 R1	RING, driving (CL-6950)
		NOTE 1 - Factory Application - Order On
		Machine Order form.  NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

. 91

# ATTACHMENTS

REF.	I, H, PART	DESCRIPTION	
NO.	NUMBER		

POWER TAKE-OFF - CONTINUED (Rockford) (UC-263 Regular Duty)

(UC-2	63 Regular Duty	
5	338 903 R1	FACING, clutch (CL-6953-52)
6	268 861 R91	PLATE w/LOCK, 319 531 R1, pressure (UCL-9518)
7	319 531 R1	LOCK, positive (CL-9216)
8	347 871 Ri	NUT, adjusting (CL-8494-1)
8A	347 872 R1	PLATE, adjusting ring (CL-1186-1)
9	266 704 R1	SPRING. separator (CL-8541) (3)
10	268 865 R91	SPRING. lever (CL-9465)
11	2 <b>66 697</b> R1	PIN. clevis (CL-8400) (6)
12	266 698 R1	RING, retaining (CL-7130) (6)
† 3	268 866 R1	LEYER (CL-8556-1) (3)
14	266 694 R1	PIN. clevis (CL-8484) (3)
15	266 696 R1	LINK, connecting (CL-8557) (6)
16	255 395 R1	RING, retaining (CL-7107) (3)
17	273 217 RI	SLEEVE, release (CL-8630-3)
18	273 218 R91	BEARING w/two NUT, 258 370 R1, and FLUG. 103 883, release (UCL-5-6979)
19	273 ZI5 R91	CLUTCH ASSEMBLY (11-1/2") (CLA-2181-37) (Composed of -  1 BODY 273 214 R1 1 FACING 338 903 R1 3 LEVER 268 866 R1 6 LINK 266 696 R1 1 NUT 347 871 R1 3 PIN 266 694 R1 6 PIN 266 697 R1 1 PLATE 268 861 R91 1 PLATE 347 872 R1 3 RING 265 395 R1 6 RING 266 698 R1 1 RING 266 698 R1 1 RING 267 065 R1 1 SLEEVE W/BEARING 273 216 R91 3 SPRING 268 865 R91)
20	321 481 R1	PLATE, instruction (PT-1593)
<b>Z1</b>	266 656 R!	GASKET, cover (PT-770)
22	273 240 R1	HOUSING, slutch (PT-817-Z)
23 23	13 396 DC 13 390 D	CONE, tapered roller bearing (390) (2) CUP, tapered roller bearing (394A) (2)
24	109 461	FITTING, 1/8" pipe plug (Lincoln 5000) (PT-1012) (3)
25	266 667 R91	TUBE. flexible (PT-1026-1)
Z <b>6</b>		NUT, 5/8NF
27	319 946 RI	SHAFT, drive (PT-1357-3)
28 29	267 060 R1 273 211 R1	KEY (FT-780) KEY, 1/2 x 1-7/8" (FT-1363)
30	266 660 R1	RETAINER, bearing (PT-727)
31	266 661 RI	PLATE, lock (PT-44)

273 210 R91 YOKE, clutch (UPT-726-1)

PRINTED IN UNITED STATES OF AMERICA

32

ny M

### **ATTACHMENTS**

REF.	NUMBER	DESCRIPTION
(Rock	R TAKE-OFF - ( ford) :63 Regular Duty	
	-// //2 P1	SHAFT, voke (PT-822)
33	266 663 R1	KEY (Woodruff No. 15) (PT-351) (2)
34	124 553	
35	266 666 R91	LEVER, shifting (UPT-87)
	305 861 R91	BEARING, clutch pilot (optional with 338 543 R91)
	338 <b>543</b> R91	BEARING, clutch pilot (optional with 305 861 R91)
	19 503 R1	NUT, 5/16NF, elastic stop (2)
	319 524 R91	POWER TAKE-OFF, w/11-1/2" over-center clutch assembly (PTA-31133) (will work for 273 016 R91)  (Composed of -
	103 883	3/8" lock WASHER (20) PLUG. 1/8" slt-hd. pipe (steel) (PT-989)
		5CREW, 1/4 x 3/8" rd-hd mach (2)
		SCREW, 1/4 x 3/8" fil-hd.
		SCREW, 3/8 x 1-1/4" hex-hd. cap (2)
		SCREW, 5/16 x 1/2" hex-hd. cap
		SCREW, 1/2 x 1-3/4" hex-hd. cap
		SCREW, 5/16NF x 2" hex-hd. cap (2)
		SCREW, 5/16 x 5/16" f-pt. set
	273 <b>21</b> 6 R91	STEEVE: 273 217 Rl. w/release BEARING,
	2/3 210 K31	273 218 R91, release (UCL-8630-3)
	265 636 RI	SPACER. clutch pilot bearing
		WASHER, \$/16" lock
		WASHER, 3/8" lock (2)
		WASHER, 1/2" lock
		WASHER, 1/4" (Shakeproof)

OWER TAKE-OFF ockford) (UC-221 Light Duty)


-92-

### **ATTACHMENTS**

**ATTACHMENTS** 

-92-

POWER TAKE-OFF - CONTINUES (Rockford) (UC-221 Light Duty)



IP8-7359B

REF. NO.	I, H, PART NUMBER	DESCRIPTION
	273 020 R91	ATTACHMENT. power take-off 319 500 R91 w/BEARING. ST 301 (with 8" single plate over-center drive ring type clutch) (UC-221 light duty) (used with flywheel Attachment. 312 729 R91) (Sec NOTES I and 3)
1	258 671 RI	NUT, hex. (PT-706)
Z 3	258 670 R1 269 110 R1	WASHER, lock (PT-718-1) BODY, ciutch (GL-8512-9)
<u> </u>	266 699 R1	RING, driving (CL-6965)

5	266 686 R1	FACING, clutch (CL-7039-1)
6 7 8	266 688 R1 266 690 R1 347 766 R1	PLATE (CL-8513-1) LOCK, adjusting (CL-8516-1) NUT. adjusting (CL-8515-1) (together with PLATE, 347 767 R1 will work for 266 689 R1)  NOTE 1 - Factory Application - Order On Machine Order Form.  NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

DESCRIPTION

I. H. PART NUMBER REF.

-93-

#### ATT

'AÇE	IMLN	S	

	 _
er.	

	_			_			_			_	_	_	_		_	_	_	
•																		
Ç	ş	c	я	1	P	т	ŧ	o	Ν									

POWER TAKE-OFF - CONTINUED
(Rockford) (UC-221 Light Duty)

8.A	347 767 RI	767 Rt PLATE, adjusting ring (CL-11905) (together with NUT. 347 766 R1 will work for Z66 689 R1)				
9	266 687 R1	SPRING, separator (CL-8575) (3)				
10	269 109 R91	SPRING, lever (CL-9464)				
11	266 697 R1	PIN, clevis (CL-8400) (6)				
12	266 698 R1	RING, retaining (CL-7130) (6)				
13	268 866 R1	LEVER (CL-8556-1) (3)				
14	266 694 R1	PIN, clevis (CL-8484) (3)				
15	266 696 R1	LINK, connecting (GL-8557) (6)				
16	255 395 R1	RING, retaining (CL-7107) (3)				
17	266 700 R1	SLEEVE, release (CL-8611)				
18	266 701 R91	BEARING w/two NUT. 19 503 R1 release				
	19 503 R1	(UCL-1-7392-1) NUT, 5/16NF elastic stop (Esna-29£-054) (2)				
		5/16NF x 1-3/4" hex-hd cap SCREW (2)				
20 21 22	266 683 R92 321 481 R1 266 656 R1 266 654 R2	CLUTCH ASSEMBLY, 8" (CLA-2175-A)  (Composed of -				
23 23	6Z 923 R91 ST 977	CONE, tapered roller bearing (2) CUP, tapered roller bearing (2)				
24	271 409	FITTING, 1/8" plug pipe (Lincoln 5000) (3)				
25	266 667 R91	TUBE, flexible (PT-1026-1)				
26		NUT, 5/8NF				
27	319 534 R1 103 881	5HAFT, drive (PT-833-4) PLUG, 1/8" pipe				
28 29	266 669 R1 266 678 R1	KEY (PT-835) KEY (1/4 × 1/4 × 2") (PT-884)				
30	266 659 RI	RETAINER, bearing (PT-834)				
3 1 3 2	266 661 R1 266 665 R91	PLATE, lock (PT-44) YOKE, clutch (UPT-811)				
33	266 662 RI	SHAFT, yoke (PT-201)				
34	124 553	KEY (Woodruff, No. 15) (PT-351) (2)				
35	266 666 R91	LEVER, shifting (UFT-87)				
	5T 301	BEARING, clutch pilot				



#### **ATTACHMENTS**

319 500 R91 POWER TAKE-OFF w/8" over-center clutch

NO.	I. H. PART Number	DESCRIPTION				
	The second secon	17·17				

-93-

POWER TAKE-OFF - CONTINUES (Rockford) (UC-221 Light Duty)

assembly	y (PTA-3815) ( <sup>,</sup>	will work for
265 814 3	R9Z)	
(Comp	osed of -	
1	CLUTCH	266 683 R92
Z	CONÉ	62 923 R91
2	CUP	ST 977
3	FITTING	271 409
2	FITTING	145 692
1	GASKET	266 656 R1
1	HOUSING	266 654 RZ
Z	KEY	1 <b>Z4</b> 553
ı	KEY	266-669 RI
i i	KEY	266 678 R1
1	LEVER	266 666 R91
1	NUT	258 671 RI
i	PLATE	266 661 R1
1	PLATE	321 481 R.I
1	RETAINER	266 659 RI
1	SHAFT	266 66 <b>2</b> R1
1	SHAFT	319 534 R1
1	TUBE	266 667 R91
1	WASHER	258 670 R1
1	YOKE	266 665 R91)
3/8 × 1	-1/8" hex-hd o	ap SCREW (12)
	-3/8" hex-hd o	
3/8" 14	ck WASHER ()	8)
•		

PLUG, 1/8" sltd-hd pipe (PT-989) 103 883

SCREW, 1/4 x 3/8" rd-hd mach (2)

SCREW,  $1/4 \times 3/8$ " fil-hd

SCREW,  $3/8 \times 1-1/4$ " hex-hd cap (Z)

SCREW, 5/16 x 1/2" hex-hd cap

SCREW, 1/2 x 1-3/4" hex-hd cap

SCREW, 5/16 x 1/4" f-pt set

266 691 R91 SLEEVE, 266 700 R1. w/release BEARING, 266 70! R1 (UCL-1-8611)

WASHER, 5/16" lock

WASHER, 3/8" lock (2)

WASHER, 1/Z" lock

WASHER, 1/4" (Shakeproof)

R.

-94-

#### **ATTACHMENTS**

		ATTACHMENTS
REF.	I. H. PART NUMBER	DESCRIPTION
	ER TAKE-OFF -Disc)	
		Parts without letters after the description indicates the part is used for all attachments listed below. Letters "A" thru "F" are used to identify separate attachments.
A	266 818 R9Z	ATTACHMENT, power take-off w/standard shaft (11-1/2" single plate overcenter drive ring type clutch) (for light duty and sideload applications w/FTO speeds of 2200 rpm or below) (see NOTES 1 and 3)
В	304 536 R91	ATTACHMENT, power take-off w/extended shaft (11-1/2" overcenter drive ring type clutch) (see NOTES 1 and 3)
Ċ	345 345 R91	ATTACHMENT, high speed power take-off w/11-1/2" single plate overcenter drive ring clutch, 2-1/4" dia. shaft w/sealed for life cartridge type pilot bearing - P.T.O. shaft has no rifle drill (for heavy duty clutch and side load applications w/ P.T.O. speeds above 2200 rpm) (UC-263) (See NOTES 1 and 3)
D	345 346 R91	ATTACHMENT, high speed power take-off w/ll-1/2" single plats overcenter drive ring clutch, 2-1/4" dia. shaft w/sealed for life cartridge type pilot bearing - P.T.O. shaft has no rifle drill (for heavy duty clutch and side load-applications w/ P.T.O. speeds above 2200 rpm) (includes safety shut-off) (UC-263) (See NOTES 1 and 3)
_E	273 018 R91	ATTACHMENT, power take-off 321 054 R91 w/bearing, 305 861 R91 (UC-221 regular duty) (UC-263 light duty) (with 10" single plate overcenter drive ring type clutch) (See NOTES 1 and 3)
F	273 021 R91	ATTACHMENT, power take-off, 321 052 R91 w/bearing, ST-301 (with 8" single plate overcenter drive ring type clutch) (UC-221 light duty) (Used with flywheel attachment 312 759 R91) (See NOTES 1 and 3)
	305 861 R91	BEARING, clutch pilot (optional with 338 543 R91) (Attachments A thru E)
	338 543 R91	BEARING, clutch pilot (optional with 305 861 R91) (Attachments A thru E)
	ST 301	BEARING, clutch pilot (Attachment F)
	308 610 R91	BLOCK w/BEARING, 305 167 R91, outboard bearing pillow (optional with 304 484 R91, 304 485 R91 and 304 486 R91) (Attachment B)
	304 484 R91	BLOCK w/BEARING, 305 165 R91, outboard bearing pillow (optional with 304 485 R91 or 304 486 R91 and 308 610 R91) (Attachment B)
	304 485 R91	BLOCK w/BEARING, 305 166 R91 and FITTING, 138 322 H, outbornd bearing pillow (optional with 304 484 R91 or 304 486 R91 and 308 610 R91) (Attachment B)
	304 486 R91	BLOCK w/BEARING, 305 167 R91, outboard bearing pillow (optional with 304 484 R91 or 304 485 R91 and 308 610 R91) (Attachment B)
$\supset$		1/2" NUT (2) 1/2 × 2" hex-hd cap 5CREW (2) 1/2" lock WASHER (2) 17/32 x 1-11/16" x 13 ga. WASHER (2)

Ñ

I, H, PART NUMBER

POWER TAKE-OFF - CONTINUES

### -94-ATTACHMENTS

DESCRIPTION

Twin-Disc)	Qualitate .
304 537 R11	BRACKET, outboard bearing (Attachment B)
345 347 R91	CABLE, temperature switch to junction block (Attachment D)
366 460 R1	CLIP, cable (mount on power take-off bolts) (2 for Attachment D)
60 610 D	KEY, belt pulley short (Attachment B)
60 614 D	KEY, belt pulley long (Attachment B) 519
321 054 R91	POWER TAKE-OFF w/STANDARD SHIFT ASSY (Twin-Disc Spec. No. 23712) (Will work for 265 817 R91) (Attachment E) (*)
321 05Z R91	POWER TAKE-OFF w/STANDARD SHAFT ASSY (Twin Disc. Spec. No. 20665) (Will work for 265 816 R91 (Attachment F) (*)
321 056 R91	POWER TAKE-OFF w/extended shaft ASSY, (Twin-Disc Spec. No. 26713) (Attachment B) (*)
321 057 R91	POWER TAKE-OFF w/standard shaft ASSY (Twin-Disk Spec. No. 26769) (Attachment:A) (*)
346 882 R91	POWER TAKE-OFF w/standard shaft ASSY (Twin-Disc Spec. No. 30287) (Attachments C and D) (*)  3/8 x 1-1/8" hex-hd cap SCREW (12)  3/8 x 1-1/2" hex-hd cap SCREW (8)  3/8" lock WASHER (20)
304 539 R1	SHIM, outboard bearing heavy (Attachment B)
304 540 R1	SHIM, outboard bearing medium (2 for Attachment B)
304 541 R1	SHIM, outboard bearing light (4 or more for Attachment B)
265 636 R1	SPACER, clutch pilot bearing
183 350 R91	SWITCH, temperature (250*) (Attachment D)

 Order Detail Service Parts From Nearest Twin-Disc Distributor.

NOTE 1 - Factory Application - Order On Machine Order Form.


NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

DESCRIPTION

# ATTACHMENTS

#### WITHOUTH

GRILLE, HOOD AND DASH



REF. NO.	I, H. PART NUMBER	DESCRIPTION
		Parts without letters after the description indicate the part is used for all attachments listed below: Letters A, B, C and D are used to identify separate attachments.
A	304 581 R91	ATTACHMENT, hood and dash (+)
В	320 136 R91	ATTACHMENT, hi-flow radiator grille (not for use with readiator shutter) (see NOTES 1 and 3)
Ç	320 137 R91	ATTACHMENT, hi-flow radiator grille (for use with radiator shutter) (see NOTES 1 and 3)
۵	349 145 R91	ATTACHMENT, hood and dash (see NOTES I and 3)
1	320 138 R1	HOUSING, radiator grille (Attachment B)
1	320 140 R91	HOUSING, radiator grille (Attachment C) 5/16 x 1/2" hex-hd cap SCREW (8) 5/16" lock WASHER (8)
2	275 1 <b>94 R</b> 91 363 284 R2	EMBLEM, "IH" (Attachments B and C) FASTENER, "IH" emblem (2)
3	265 581 R1	HOOD, LH engine (Attachments A and D)
4	268 390 R11	STRIP, hood center (Attachments A and D) 3/8" NUT (4) 3/8 x 5/8" hex-hd cap SCREW (4) 3/8" lock WASHER (4)
5	304 582 R1	HOOD, RH engine (Attachments A and D)
6	265 586 R91	HOOK, RH hood clamp (2 for Attachments A and D)  5/16 x 1/2" hex-hd cap SCREW (4)  5/16" lock WASHER (4)

1. H, PART NUMBER

GRILLE, HOOD AND DASH - CONTINUED

## ATTACHMENTS

	<b></b> , <i>noop</i> ,	
7	265 585 R9I	HOOK. LH hood clamp (2 for Attachments A and D)  5/16 x 1/2" hex-hd cap SCREW (4)  5/16" lock WASHER (4)
8 9	304 583 R2 349 146 R1	DASH (Attachment A) DASH (Attachment D) 3/8 x 3/4" hex-hd cap SCREW (5 for Attachment A) 3/8" lock WASHER (5 for Attachment A, 4 for Attachment D) 3/8 x 5/8" hex-hd cap SCREW (4 for Attachment D) 13/32 x 13/16" x 16 ga. WASHER (2 for Attachment A)
9	320 139 R1 321 719 R91 354 837 R1	GRILLE, hi-flow (Attachments B and C) BOLT, grille (4) WASHER, flat (4)
9	304 600 R91	DACWACE
	144 229	GROMMET (Attachment A)
	320 149 R1	PACKAGE, radiator grille field service (for units without radiator shuter) (Consists of - 4 BOLT 321.719 R91 1 GRILLE 320 139 R1 1 HOUSING 320 138 R11 4 WASHER 354 837 R1 )
	320 163 R91	PACKAGE, radiator grille field service (for units with radiator shutter) (Consists of - 4 BOLT 321 719 R91 1 GRILLE 320 139 R1 1 HOUSING 320 140 R91 4 WASHER 354 837 R1 )  NUT. 3/8" (+) (2 for Attachment D)  SCREW. 3/8 x 3/4" hex-hd cap (+) (2 for Attachment D)  SCREW. 3/8 x 3/8" hex-hd cap (+) (2 for Attachment D)  WASHER. 3/8" lock (+) (4 for Attachment D)

 For Use With Dash When Instrument And Panel Attachment Is Not Rear Mounted.
 NOTE 1 - Factory Application - Order On Machine Order Form.
 NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

227

-96-


#### **ATTACHMENTS**



# ATTACHMENTS

DIATOR SHUTTER tomatic) (Kvsov Heater)

RADIATOR SHUTTER - CONTINUES (Automatic) (Kysor Heater)



MÉP. NÓ.	I, W. PART NUMBER	DESCRIPTION		
	318 021 R91	ATTACHMENT, radiator shutter (See NOTES 1 and 3)		
1	313 326 R91	SHUTTER w/CONTROL, 615 236 C91. BRACKET, 615 237 C1. and SPRING, 317 785 R1. radiator (M1856) 5/16 x 1/2" hex-hd cap 5CREW (8) 5/16" lock WASHER (8)		
2	615 <b>236</b> C91	CONTROL, vernatherm (C-16318-165) 1/4NF x 1/2" hex-hd cap SCREW (cd-pltd) (4) 1/4" lock WASHER (4)		
3 4	171 819 R1 112 700 RI	NIPPLE, hose (3) CLAMP, hose (4)		
5	312 278 R1	HOSE, radiator to vernatherm (5/8 x 15/16 x 49") (2)		
_'	171 820 R1	NIPPLE, hose		

NEF.	I. H. PART NUMBER	DESCRIPTION
7	137 894	ELBOW, 1/Z x 45" street
8 9	438 159 142 340	PLUG, 1/2" pipe CROSS, 1/2" pipe
10	144 610	NIPPLE, 1/2 x 1-3/8" pipe
11 12	301 819 RI 317 785 RI	CLIP, hose SPRING, control rod (7785)
13	615 237 C1	BRACKET. control (C-Z3102)
	445 673	PLUG, 3/8" pipe
		WASHER, $5/16 \times 3/4 \times .065''$ (cd-pltd) $3/32 \times 1/2''$ cotter PIN
		NOTE 1 - Factory Application - Order on Machine Order Form.
		NOTE 3 - Field Application - Order through Regular Service Parts Channels.

-97**-**

### ATTACHMENTS


-97-



#### ATTACHMENTS

RADIATOR SHUTTER (Manual) (Hardy Mfg. Corp.)

RADIATOR SHUTTER - Continued (Manual) (Hardy Mfg. Corp.)



REF.	I, M. PART NUMBER	DESCRIPTION		
	31Z 184 R91	ATTACHMENT, radiator shutter (5ee NOTES 1 and 3)		
1	317 781 R91	SHUTTER w/operating BAR (27817) 1/4" NUT (4) 1/4 x 5/8" sit-rd-hd mach SCREW (4) 1/4" lock WASHER (4)		
2		FRAME (Not Furnished Separately)		
3	317 680 R91	BELLCRANK w/operating LINK (27811)		
4	47 530 D	SPRING, belicrank (15549)		
5	313 ZZ4 R9i	CONTROL, vernier 1/4Nf x 1/2" av-pt, hex-soc-hd, set \$CREW 1/4Nf NUT		
6	312 185 R1	BRACKET, shutter control 3/8 x 1" hex-hd cap SCREW		

REF.	I. H. PART NUMBER	DESCRIPTION		
	313 <b>Z25</b> R91	SHUTTER ASSEMBLY (Composed of - 1 BELLCRAN: w/LINK §! FRAME 1 SHUTTER. w/BAR 1 SPRING 1 WASHER 5/16 x 1/2" hex-bd	317 680 R91 317 781 R91 47 530 D 352.627 R1 ) cap SCREW (8)	
		NUT, No. 10	unio della di particoloria	
		SCREW, No. 10 x 9/1	6" rd-hd mach	
		WASHER, No. 10 inte	rnal-tooth lock	
	352 627 R I	WASHER, .325 x 5/8' 3/32 x 5/8" cotter	flat (13371) PIN	


-98-

### **ATTACHMENTS**

### **ATTACHMENTS**

DIATOR AND CONNECTIONS AND FAN GUARD

RADIATOR AND CONNECTIONS AND FAN GUARD - CONTINUES



REF. NO.	I. H. PART NUMBER	DESCRIPTION	NO.	J. N. PART NUMBER	DESCRIPTION
(X) -	KEY TO UNITS	i	2	361 705 R91	CAP, radiator (Units B. C. D and E)
		ATTACHMENT, fan guard (UC-221 and	3	274 088 R91	CLAMF, radiator elbow (4 for Unit B and 6 for Unit C: 2 for Units D and E)
A -	304 577 R91	(UC-263) (See NOTES 1 and 3)	4	304 596 R1	ELBOW, radiator injet (Units B, C, D and E)
в -	699 106 C91	ATTACHMENT, radiator and connections (for usits equipped with Hydraulic Pump) (See NOTES 1 and 3)	5	612 292 C1	SHROUD, fan (Unit B) 5/16 x 1/2" hex-hd cap SCREW (4) 5/16 x 3/4" hex-hd cap SCREW (2)
G-	305 193 R92	ATTACHMENT, radiator and connections (for units not equipped with Hydraulic Pump) (UC-263) (See NOTES 1 and 3)			5/16" lock WASHER (6) 3/8 x 1/2" hex-hd cap SCREW (2) 3/8" lock WASHER (2)
D -		Service parts for radiator and connections (for units equipped with Hydraulic Pump) (UC-221)	5	304 590 R11	SHEET, fan housing (Units C, D and E) 5/16 x 1/2" hex-hd cap SCREW (6) 5/16" lock WASHER (6)
E-		Service parts for radiator and connections (for units equipped with Hydraulic Pump) (UC-263)	6	601 712 C1	BRACE, radiator LH (Units B, C, D and E) 3/8 x 3/4" hex-hd cap SCREW
(XC) -	the description	se units correspond with those shown following on of the parts in the list below and identifies which the part is used. Items without letters cription indicates the part is used for all units.			NOTE 1 - Factory Application - Order on Machine Order Form. NOTE 3 - Field Application - Order through
	265 595 R93	RADIATOR (will work for 304 608 R93)			Regular Service Parts Channels.

-99-


#### -99•

### **ATTACHMENTS**

REF. NO.	I, H, PART Number	OESCRIFT ON
RADIA	ATOR AND CONN	ECTIONS AND FAN GUARO - CONTINUED
7	601 713 CI	BRACE, radiator RH (Units B, C, D and E)
8	304 578 R91	GUARD, fan (Unit A) 5/16 x 1/2" hex-hd cap SCREW (4) 5/16" lock WASHER (4)
		$11/32 \times 11/16 \times 16 \text{ ga WASHER (4)}$
9	407 008 R1	HOSE, upper radiator outlet elbow (2 x 2-3/1 x Z-1/4" long) (Units B and C)*
10	305 197 R1	ELBOW, radiator outlet (Units B and C)
11	407 009 R1	HOSE, lower radiator outlet elbow (2-1/8 x 2-5/16 x 1-7/8" long) (Units B and C)*
12	310 336 RII	SUPPORT, radiator (2 for Units B. C. D and E.) 5/8" NUT (4) 5/8 x 1-1/4" hex-hd cap 5CREW (2) 5/8 x 1-1/2" hex-hd cap 5CREW (2) 5/8" lock WASHER (4)
13	265 597 R1	PAD, radiator (2 for Units B, C. D and E)
14	15 024 RI	BOLT, radiator mounting (2 for Units B, C, D and E) 7/16" NUT (2) 7/16" lock WASHER (2) 15/32 x 59/64" x 16 ga. WASHER (2)
15	31 729 D	VALVE, radiator drain (Units B. C. D and E
16	279 038 R1	CLAMP, hose (Z for Units D and E)
17.	278 Z81 K1	HOSE, water inlet (2 x 2-3/8 x 1-3/4") (Unit D and E)
18	312 501 R1	ELBOW, water inlet (Units D and E) 3/8 x 2-3/4" hex-hd cap SCREW (3) 3/8" lock WASHER (3)
19	274 088 R91	CLAMP, radiator outlet elbow hose (4 for Units D and E)
20	304 597 Ri	ELBOW, radiator outlet (Units D and E)
	444 782	PLUG, water inlet (for condenser) (Unit C)
	445 673	PLUG. water inlet (for condenser) (Unit C)

#### **ATTACHMENTS**

(For UC-263 Power Units equipped with Extended Shaft and Outboard Bearing Attachment)



REF. NO.	I. H. PART NUMBER	DESCRIPTION
	304 605 R91	ATTACHMENT, sub-base (UC-263) (See NOTES 1 and 3) (Consists of the following parts -
1	304 602 R91	SUB-BASE 5/8" NUT (6) 5/8 x 1-3/4" hex-hd cap SCREW (6) 5/8" lock WASHER (6)
Z	51 811 D	WASHER, bevel (6)

\*Make From Bulk Stock. Bulk Stock Furnished In 3 Foot Lengths. Part No. 1s For 1 Foot Of Hose Only.

NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

A North Administration

-100-

#### ATTACHMENTS

Ĉ

Access to the

# MEMORANDA

ů

ATTACHME

NUMBER NUMBER

DESCRIPTION

AUXILIARY DRIVE PULLEY

ATTACHMENT, auxiliary drive pulley (6.75"

OD single "A" sheave) (for use with auction
fan ATTACHMENT, 320 165 R91 or blower
fan ATTACHMENT, 323 768 R91) (See
NOTES 1 and 3)

318 002 R91 ATTACHMENT, auxiliary drive pulley (6.75" OD single "B" sheave) (for use with suction fan ATTACHMENT, 320 166 R91 or blower fan ATTACHMENT, 323 768 R91) (18-1/2" dia. 5 blade w/1.62" spacer) (See NOTES 1 and 3)

318 003 R91 ATTACHMENT, auxiliary drive pulley
(5.02" OD single "A" sheave (For use with
suction fan ATTACHMENT, 320 165 R91 or
blower fan ATTACHMENT, 323 768 R91
(See NOTES 1 and 3)

Z84 358 R1 PULLEY, auxiliary drive (part of ATTACHMENT, 318 001 R91)
9 409 030 BOLT. 3/8 x 1-1/4" (Type "AA" lock) (4)

404 030

318 007 R1 PULLEY, auxiliary drive (part of ATTACHMENT, 318 002 R91)
9 409 231 BOLT, 3/8 x l-1/2" (Type "AA" lock) (4)

338 952 R91 PULLEY, auxiliary drive (part of ATTACH-MENT, 318 003 R91)

#### FLEXIBLE COUPLING

318 004 R91 ATTACHMENT, flexible coupling (front power take-off (48 H.P. capacity) (for use with suction fan ATTACHMENT, 316 170 R91) (18" dia. 6 blade w/1.38" spacer) or blower fan ATTACHMENT, 316 168 R91 (18" dia. 6 blade w/1.00" spacer) (See NOTES 1 and 3)

318 005 R91 ATTACHMENT, flexible coupling (front power take-off) (20 H.P. capacity) (for use with blower fan ATTACHMENT, 304 549 R91 and suction (an ATTACHMENT. 320 165 R91) (5ee NOTES 1 and 3)

319 650 R91 COUPLING, flexible (part of ATTACHMENT, 318 005 R91)

319 651 R91 COUPLING, flexible (part of ATTACHMENT, 318 004 R91)
3/8 x 7/8" soc-hd cap SCREW (4)

NUT, l"NF crankshaft jam

NOTE 1 - Factory Application - Order On Machine Order Form.

NOTE 3 - Field Application - Order Through Regular Service Parts Channels.


Û

**ATTACHMENTS** 

ATTACHMENTS

TOOLS
(Owatonna Tool Company)





REF.	MFR'S	OSSCRIPTION	REF. NO.	MFR'S. NUMBER	DESCRIFTION
		TOOL SET (I.H. Part No. 276 822 R91) (order through regular service parts channels) (See	7	CC-24	CHISEL (8" long)
		NOTE)	8	71 Z-A	PLIERS (slip joint - 8" long)
1	ED-1133	ROLL, tool (leatherette)			
-	BP-32	HAMMER (2 lb ball been)	9	E - 24 26	WRENCH, end (3/4 x 13/16")
Z	BP+32		10	E-2628	WRENCH. and (13/16 x 7/8")
3	DA-12	WRENCH (adjustable - 12" long)	10	E+5020	
	SS-123	SCREWDRIVER (3/8" shank)	11	£-2022	WRENCH. end (5/8 x 11/16")
4	55-125		12	£-1820	WRENCH, end (9/16 x 5/8")
5	SS-83	SCREWDRIVER ()/4" shank)	12	D-1050	
-			13	E-1416	WRENCH, end (7/16 x 1/2")
6	TP-24	PUNCH (10" long)			to the second se

NOTE - Order Individual Tools And Complete Tool Sets From Service Tools, Inc., 1923 South Indiana Avenue Chicago 16, Illinois.



CYLINDER OILER

#### -102-


#### **ATTACHMENTS**

rol Manufacturing Company's Marvel" Oiler)



### -102-**ATTACHMENTS**

TOP CYLINDER OILER - Continues (Emerol Manufacturing Company's Marvel" Oiler)



	I. H. PART Number	DESCRIPTION
<b></b>	305 883 R91	ATTACHMENT, top cylinder oiler (See NOTES 1 and 3)
1	38 976 D	CAP, head (T-5-1)
2 3	261 518 R1 261 517 R1	PLUG. filler (T-56-6) BODY, filler (T-56-5) No. 8 x 5/8" slt-fil-hd. SCREW (4)
4 5	38 974 D 39 824 D	GASKET, filler body (T-16-33) NUT, sight glass lock (T-81-10)
6 7	39 822 D 39 823 D	GLASS, sight (plastacele) (T-62-1) GASKET, sight glass (T-16-5)
8 9	38 970 D 38 975 D	HEAD (T-10-510) No. 3 x 5/8" sit-fil-hd. SCREW (6) GASKET, head to tank (T-18-10)
10	38 972 D	SADDLE (T-118-6) (Z) No. 10NF x 1/2" slt-rd-hd. SCREW (4) STRAP (T-118-5) (Z)
11	38 971 D 36 087 DA	OILER, top cylinder (Emerol Company's "Marvel Inverse" Ciler) (Model "TU") (Composed of - 1 BODY 261 517 R1
		1 CAP 38 976 D 1 GASKET 38 974 D 1 GASKET 38 975 D 1 GASKET 39 823 D 1 GLASS 39 822 D 1 HEAD 38 970 D 1 NUT 39 824 D 1 PLUG 261 518 R1 2 SADDLE 38 972 D 2 5TRAP 38 971 D) No. 10 NUT (4)
		No. 10 slt-fil-hd. SCREW (4) No. 10 lock WASHER (4)

REF. NO.	I. H. PART Number	DESCRIPTION
13	36 637 D	ELBOW. top cylinder oiler tube (at oiler)
14	36 092 D	NUT. top cylinder oiler tube coupling (2)
15	305 884 R1	TUBE, top cylinder oiler
16	59 939 D	CONNECTOR, male top cylinder oiler tube (at manifold)
17	305 708 R1	SUPPORT, top cylinder oiler 7/16 x 7/8" hex-hd. cap SCREW (2) 7/16" lock WASHER (2)
	103 865	PLUG, 1/8" sq-hd pipe (CI) (optional with 103 877) (assemble in tee)
	103 877	PLUG, 1/8" sq-hd steel pipe (optional with 103 865) (assemble in tee)
	444 236	TEE, 1/8-27 autorwative pipe (CI) (optional with 444 238 and 444 132) (assemble in intak manifold)
	444 238	TEE, 1/8-27 automotive pipe (brass) (options with 444 236 and 444 132) (assemble in intak manifold)
	444 132	TEE, 1/8-27 automotive pipe (brass) (optional with 444 236 and 444 238) (assemble in intak manifold)
		NOTE 1 - Factory Application - Order On Machine Order Form.
		NOTE 3 - Field Application - Order Through Regular Service Parts Channels.


3

### -8-

#### ATTACHMENTS

10


OIL LEVEL SIGHT GAUGE



REF. NO.	I. H. PART NUMBER	OFECRIPTION
	312 998 R91	ATTACHMENT, oil level sight gauge (for use on Natural Gas, Liquefied Petroleum Gas and Combination Gas or Gasoline engines) (Not Used On Units Equipped With Flo-Matic Valve Attachment) (See NOTES 1 and 3)
t	252 374 RI	ELBOW, 90° vent tube
2	31 <b>2 948 R</b> 11	COVER, fuel pump pad
3	369 987 R1	NUT. 1/4" coupling (2)
4	312 999 R1	TUBE, vent
5	30 402 D	ELBOW, vent tube
6	279 689 R91	GAUGE, oil level
7 8	120 755 120 207	COUPLING, 3/8" pipe NIPPLE, 3/8 x 1" pipe
9	103 868	PLUG, 1/2" pipe
10 11	143 166 190 702	TEE, 1/2 x 1/2 x 3/8" oil level gauge NIPPLE, 1/2 x 5" pipe
12	Z61 505 R1	WIRE, bulk locking (16 ga.) (customer must specify length required)
13	33Z 174 R1	BOLT, oil pan drain retaining
14	3 405 H	GASKET, oil pan drain (2)
15	332 173 R1	UNION, oil pan drain (will work for 108 686)

#### **ATTACHMENTS**

HYDRAULIC PUMPS AND RELATED PARTS



NEF.	I. H, PART NUMBER	DESCRIPTION
1144		- Care N.

- (X) KEY TO UNITS -
- A Service parts for Hydraulic Pump (15 G. P.M.) (gasoline burning power units) (See NOTES 1 and 3) (\*)
- B Service parts for Hydraulic Pump (18 G. P. M.) (gasoline burning power units) (See NOTES 1 and 3) (\*)
- C Service parts for Hydraulic Pump (7 G.P.M.) (gasoline burning power units) (See NOTES 1 and 3) (\*)
- D Service parts for Hydraulic Pump (11 G.P.M.) (gasoline burning power units) (See NOTES 1 and 3) (\*)
- (X) Letters of these units correspond with those shown following the description of the parts in the list below and identifies the unit for which the part is used. Items without letters after the description indicates the part is used for all units.
  - 588 368 R91 PUMP. hydraulic (Unit C) (+)
  - 588 371 R92 FUMP, hydraulic (Unit A) (+)
  - 588 370 R91 PUMP, hydraulic (Unit D) (+) --- ...:
  - 317 528 R91 PUMP, hydraulic (Unit B) (+) 3/8 x 1" hex-hd cap SCREW 3/8 x 1-3/8" hex-hd cap SCREW
- 3/8 x 1-3/8" hex-hd cap SCREW 3/8" lock WASHER (2)
- 2 312 453 R1 GASKET, hydraulic pump
  3 312 452 R1 GEAR, hydraulic pump (27 T)
  - - (\*) For Use With Electric Fuel Fump, 317 696 R91, Generator (Delco-Remy) No. 11102034), Mechanical Governor, 310 840 R91, Instrument Panel, 278 597 R2, Radiator 265 595 R92 And Fan, Attachment 304 576 R91.
    - (+) For Components See List Of Parts Under Details Of "Hydraulic Pump.
    - NOTE 1 Factory Application Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

-104-


#### **ATTACHMENTS**



### **ATTACHMENTS**

-104-

L LEVEL SIGHT GAUGE OIL LEVEL SIGHT GAUGE - CONTINUED ed with Flo-Matic Valve Attachment) (Used with Flo-Matic Valve Attachment)



RÉF. NO.	I. H. PART Number	DESCRIPTION
	332 471 R91	ATTACHMENT, oil level sight gauge (for use on natural gas, liquefied petroleum gas and combination gas or gasoline engines) (for use with Flo-Matic Valve Attachment) (See NOTES 1 and 3)
1	332 174 R1	BOLT, oil pan drain retainer
2	332 173 R1	UNION, cil pan drain
<b>3</b> .	261 505 R1	WIRE, bulk locking (16 ga.) (customer must specify length required)
4	137 894	ELBOW, 1/2" x 45° street
5	144 610	NIPPLE, 1/2 x 1-3/8" pipe
6	119 094	ELBOW, 1/2" x 45° pipe
7	187 249	NIPPLE, 1/2 x 7" pipe
8	143 166	TEE, 1/2 x 1/2 x 3/8" pipe
9	140 537	NIPPLE, 1/2 x 2" pipe
10	187 397	COUPLING, 1/2" pipe
	103 868	PLUG, 1/2" pipe

NEF. NO.	I, H, PART HUMBER	DESCRIPTION
12	3 405 H	GASKET, oil pan drain (2)
13	317 623 R1	GROMMET
14	173 001	NIPPLE, 3/8 x 1-3/4" pipe
15	120 755	COUPLING, 3/8" pipe
16	279 689 R91	GAUGE, oil level sight
17	30 402 D	ELBOW, vent tube
18	31 <b>Z 948 R</b> 1	COVER, fuel pump pad
19	995 061 RI	TUBE, vent (19-1/2" long, copper i/4" OD (#))
20	59 730 M	CONNECTOR, vent tube
żi	369 987 RI	NUT, 1/4" (Z)
		NOTE 1 - Factory Application - Order On Machine Order Form. NOTE 3 - Field Application - Order Through Regular Service Parts Channels. (#) - Part Number and Price Covers One Foot Of Tubing. Furnished Only in 50 Foot Rolls.

650 852 4274

P.22/22

-105-

MEMORANDA

MEMORANDA

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

-106-

### ATTACHMENTS


## B

### ATTACHMENTS

HYDRAULIC PUMP - CONTINUED

(ebster Electric) HYDRAULIC PUMP - CONTINUED

(Webster Electric)



REF. NO.	I. H. PART MUMBER	DESCRIPTION	
(X) -	KEY TO UNI <b>T</b> S	5 -	
A -	588 371 R9Z	FUMP, hydraulic (15 G.P.M.)	
<b>B</b> -	317 528 R91	PUMP, hydraulic (18 G.P.M.)	
Ç.	588 568 R91	PUMP, hydraulic (7 G.P.M.)	
D -	588 370 R91	PUMP, hydraulic (II G.P.M.)	
(X) -	the description the unit for w	se units correspond with those shown following on of the parts in the list below and identifies which the part is used. Items without letters cription indicates the part is used for all units	
1	588 394 RI	PLATE, pilot (151-24845-3) No. 10 x 5/8" f-hd mach SCREW (3)	
2	588 389 R1	SHAFT, drive (151-21075-2) (Unit C)	
2	588 397 R1	SHAFT, drive (151-24806-1) (Unit D)	
2	588 396 R1	SHAFT, drive (151-16848-5) (Unit A)	
2	303 494 R1	SHAFT, drive (151-25202) (Unit B)	
3	103 646	KEY, 1/8 x 3/4" (Woodruff No. 7) (Units A,	E
	427 <b>2</b> 61	and D) KEY, 1/8 x 3/8" (Woodruff No. 213) (Unit C	;)
	P	PRINTED IN UNITED STATES OF AMERICA	٠,

NO.	I. H. PART NUMBER	DESCRIPTION
4	586 201 R91	OIL SEAL (Chicago Rawhide No. 501391)
5	188 287 RI	RING, retaining (4)
6:	2 <b>76</b> 569 R1	WASHER, 49/64 x 59/64 x .030" flat (29602-132) (2)
7	8 521 T	BEARING, ball (5204 L1A)
8	588 391 K1	BODY, pump (151-13752-3) (Units A, C and D)  1/4 x 2" hex-hd cap SCREW (2)  1/4 x 2-1/4" hex-hd cap SCREW (Unit A and D)  5/16 x 1-5/8" hex-hd cap SCREW (2 for Unit C)  1/4" lock WASHER  5/16" lock WASHER (2)
8	303 495 R91	BODY w/BEARING, 276 574 R91, pump (150-16877-14) (Unit B) 1/4 x 2" hex-hd cap SCREW 5/16 x 2" hex-hd cap SCREW (2) 1/4" lock WASHER 5/16" lock WASHER (2)
9	276 574 R91	BEARING, needle (151-30621) (3)

DESCRIPTION

-107-

## ATTACHMENTS

1. H, PART Number Ů


### MEMORANDA

HYDRA: (Webste	JLIC PUMP - Co er Electric)	witnusp
10	303 100 R1	SHAFT, idler (151-20795) (Unit B)
10	572 082 RI	SHAFT, idler (151-21986) (Unit D)
10	57Z 964 R1	SHAFT, idler (151-21073) (Unit C)
10	573 661 R1	SHAFT, idler (151-20794) (Unit A)
11	427 261	KEY, 1/8 x 3/8" (Woodruff No. 213)
12	276 579 RI	GEAR, drive (8 T) (151-21952-2) (Unit D)
12	303 102 R1	GEAR, drive (8 T) (151-20203-1) (Unit B)
12	572 959 R1	GEAR, drive (8 T) (151-21072-4) (Unit C)
12	573 693 R1	GEAR, drive (8 T) (151-20202-1) (Unit A)
13	276 570 R1	GEAR, idler (8 T) (151-21952-1) (Unit D)
13	303 074 R1	GEAR, idler (8 T) (151-20203-2) (Unit B)
13	572 960 R1	GEAR, idler (8 T) (151-21072-3) (Unit C)
13	573 694 R1	GEAR, idler (8 T) (151-20202-2) (Unit A)
14	573 655 R1	PIN, dowel (151-12555-15) (2 for Unit D)
14	303 073 R1	FIN, dowel (151-14001) (2 for Unit B)
14	572 937 R1	PIN, dowel (151-21074) (Z for Unit C)
14	573 657 R1	PIN, dowel (151-30619) (2 for Unit A)
15	303 072 RI	PLATE, gear (151-14471-6) (Unit B)
15	588 388 R.I	PLATE, gear (151-21070-1) (Unit C)
15	588 393 R1	PLATE, gear (151-30615-3) (Unit A)
15	588 395 R1	PLATE, gear (\51-22065-1) (Unit D)
16	317 670 R91	
		1/4 x 2-1/2" hex-hd cap SCREW 5/16 x 2-1/4" hex-hd cap SCREW (4) 1/4" lock WASHER 5/16" lock WASHER (4)
16	588 392 R1	COVER. pump (151-16876-43) (Units A, C and D)  1/4 x Z" hex-hd cap SCREW  1/4 x 2-1/4" hex-hd cap SCREW  5/16 x 1-5/8" hex-hd cap SCREW (4 for
		Unit C) 5/16 x 2" hex-hd cap SCREW (4 for Units A and D) 1/4" lock WASHER 5/16" lock WASHER (4)
17	124 548	KEY. 5/32 x 3/4" (Woodruff No. 8)
	364 145 R	1 "O" RING, 2-1/8 x 2-5/16 x 3/32"

# ÄTTÄCHMENTS

ECTRIC FUEL TRANSFER PUMP 2 Volt) (Eclipse Bendix) (Used with Hydraulic Pump)

17:22



MEF. NO.	L.H. PART Number	DESCRIPTION
	316 1 <b>51</b> R9	ATTACHMENT, electric fuel pump (See NOTES 1 and 3)
	631 259 R9	PUMP ASSEMBLY, electric fuel transfer (480516) (Composed of - \$1 BODY 1 COVER 936 492 R91 1 CUP 317 965 R91 1 GASKET 317 962 R1 1 GASKET 317 964 R1 1 PLUNGER 317 967 R91 1 SCREEN 317 963 R1 3 SCREW 19 714 R1 1 SPRING 936 493 R1 1 /4" NUT (2) 1/4" NUT (2) 1/4 x 5/8" hex-hd cap SCREW (2) 1/4" lock WASHER (2)
l		BODY (order 317 696 R91)
2	369 989 R1	NUT, carburetor to pump tube (3)
3	316 159 R1	TUBE w/two NUT, 369 989 RI, carburetor to pump
4	24 847 H	ELBOW, carburetor to pump tube
5	263 515 R9	CLIP, cable (on oil pan holt)
	267 806 R9	CABLE, fuel pump

# ATTACHMENTS

NO.	NUMBER	DESCRIPTION		
ELECT	RIC FUEL TRANSFER	R PUMP - CONTINUED		
(1.2 Va)	tl (Edlinga Bendist)	(Used with Hydraulia Purna)		

7	317 967 <b>R</b> 91	PLUNGER, pump (476474)
8	936 493 R1	SPRING, plunger (475127)
9	317 964 R1	GASKET, spring cup (475126)
10	317 965 R91	CUF, plunger (476364)
11	19 714 R1	SCREW, No. $4 \times 1/4$ " pan-hd (490028) (3)
12	317 963 RI	SCREEN, filter (475634)
13	317 962 R1	GASKET, sediment cover (475594)
14	936 492 R91	COVER w/GASKET, 317 962 R1 (476563)

316 158 R1 BRACKET, pump mounting

 Not Furnished Separately.
 NOTÉ 1 - Factory Application - Order On Machine Order Form.
 NOTE 3 - Field Application - Order Through Regular Service Parts Channels.


-109-

## ATTACHMENTS

### ATTACHMENTS

CLUTCH (BORG AND BECK) AND CONTROLS

CLUTCH (BORG AND BECK) AND CONTROLS - CONTINUED



REF. NO.	L. H. FART NUMBER	DESCRIPTION
	312 837 R91	ATTACHMENT, clutch and controls (See NOTES   and 3)
I	57 287 D	SPRING, clutch release sleeve return
2	267 814 R91	SLEEVE, clutch release
3	317 533 R91	COVER w/(our RIVET, 317 535 R1 and eight STRAP, 317 534 R1 (11534)
4	317 534 R1	STRAP, driving (5296) (8)
5	317 542 R1	SPRING (3951) (8)
6	317 541 Ri	SPRING (3814) (8)
7	317 535 R1	RIVET, driving strap (5099) (4)
8	317 543 RI	PLATE. pressure (5293)
9	313 771 R91	MEMBER w/FACING, 317 546 R91 driven (12208)
10	317 <b>546</b> R91	PACKAGE, facing (12153)
11	5T 208 B	BEARING, ciutch pilot ball
1.2	317 538 R1	PIN, evebolt (3696) (4)

HEF. NO.	I, H. PART NUMBER	DESCRIPTION
13	317 540 R1	LEVER, release (6038) (4)
14	317 539 R1	STRUT. release lever (3695) (4)
15	317 536 R1	SPRING, anti-rattle (3258) (4)
16	317 537 R91	EYEBOLT and NUT (11509) (4)
17	317 545 R1	FERRULE, driving strap (5295) (4)
18	317 544 R1	SCREW, driving strap (5297) (4)
	313 772 R9!	COVER, clutch (1219) (Composed of - 1 COVER and STRAP 317 533 R91 4 EYEBOLT and NUT 317 537 R91 4 FERRULE 317 545 R1 4 LEVER 317 540 R1 4 PIN 317 538 R1 1 PLATE 317 543 R1 4 SCREW 317 544 R1 4 SPRING 317 544 R1 8 SPRING 317 541 R1 8 SPRING 317 542 R1 8 SPRING 317 542 R1
	73 092 R2	SCREW, clutch cover mounting (8) 3/8" lock WASHER (8)

NOTE 1 - Factory Application - Order On

Machine Order Form.

NOTE 3 - Field Application - Order Through
Regular Service Farts Channels.

#### ATTACHMENTS

I,M.PART DESCRIPTION

MSMISSION ATTACHMENTS

312 838 R91 ATTACHMENT, transmission (four speed sliding gear) (See NOTES 1 and 3) (Consists of all parts listed under "TRANSMISSION (Four Speed Sliding Gear) (Warner)") (For use with 12" spring loaded clutch and controls ATTACHMENT, 312 837 R91 and FLYWHEEL, 312 563 R91) (UC-221)

-110-

#### ATTACHMENTS

REF. I.H.PART DESCRIPTION NO. NUMBER

TRANSMISSION ATTACHMENTS - CONTINUES

312 839 R91 ATTACHMENT. transmission (four speed synchromesh) (See NOTES 1 and 3) (Consists of all parts listed under "TRANSMISSION (Four Speed Synchromesh) (Warner)") (For use with 12" spring loaded clutch and controls ATTACHMENT, 312 837 R91 and FLYWHEEL, 312 563 R91)

NOTE 1 - Factory Application - Order On Machine Order Form.


NOTE 3 - Field Application - Order Through Regular Service Parts Channels.

TRANSMISSION (Four Speed Sliding Gear) (Wafner)

TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS

TRANSMISSION - CONTINUED (Four Speed Sliding Gear) (Warner)

TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS - Continued



REP.	L. H. PART	6.1	SACRIPTION .
NQ.	NUMBER		

313 740 R91 TRANSMISSION ASSEMBLY (AS-148-T9)
(part of ATTACHMENT, 312 838 R91)
3/8 x 1-1/8" hex-hd cap SCREW (12)
3/8" lock WASHER (12)

REF. NO.	I, H, PART HUMBER	DESCRIPTION
1	106 058 H	NUT, main shaft (T9-50P)
<u>2</u> 3	60 19Z H 27 090 H	WASHER, companion flange (T9-50-1/2C) WASHER, mainshaft rear bearing oil (T8-137

REF.

I. H. FART

TRANSMISSION - CONTINUED (Four Speed Sliding Gear) (Warner)

TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS - Continued

- i 11-

### ATTACHMENTS

DESCRIPTION



-111-**ATTACHMENTS** 

ASF. I. H. PART NUMBER DESCRIPTION NO.

TRANSMISSION - Continued (Four Speed Sliding Gear) (Warmer)

TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED FARTS - Continued

4	27 088 H	WASHER, mainshaft roar bearing thrust	38	317 666 RI	HOUSING, clutch (9-1-1/2A)
_		(T69-137)	39	317 634 R1	COVER, hand hole (T9-74) 5/16 x 5/8" fil-hd SCREW (2)
5	27 068 HB	SHAFT, main (T9-2G)			5/16" lock WASHER (2)
6	72 975 H	GEAR, mainshaft first and second (T9-12C)	40	317 635 R1	SHAFT, throw out (short) (192310)
7	62 899 H	GEAR, mainshaft third and direct (T9A-11)			1
8	27 087 H	RING, mainshaft pilot bearing spacer (T8-25)	41	317 637 RI	YOKE, throw out (T64J-360D)
9		PIN, 1/8 x 1-1/4" cotter	42	317 638 R1	SCREW, lock (5573)
10	27 118 H	FORK, reverse speed shift (T8-51)	43	317 636 R1	SHAFT, throw out (long) (T9A-311M)
11	27 083 H	RAIL, reverse speed shift fork (T8-54)			
Į Z	27 079 H	SHAFT, reverse idler gear (T8-35)	44	271 285	FITTING, 1/8" x 90° lubrication (Alemite 1613B) (optional with 109462) (2) (not part of
13	62 90 <b>2 H</b>	GEAR, reverse idler (T9A-10)			Transmission ASSEMBLY, 313 740 R91)
14	95 854 H	WASHER, countershaft gear thrust (T9-30V) (Z)	44	109 462	FITTING, 1/8" x 90° lubrication (Lincoln 5400) (optional with 271 285) (2) (not part of Transmission ASSEMBLY, 313 740 R91)
15	Z3 172 H	BEARING, countershaft gear roller (X4038) (2)			,
16	72 976 H	GEAR, countershaft (T8C-8A)	45		SCREW, 5/16 x 3/4" hex-hd cap (4)
17	27 091 H	SPACER, countershaft gear bearing (T8-28A)	46		WASHER, 5/16" external lock (4)
18	27 069 H	SHAFT, counter (T9-3F)	47	23 045 H	COVER, power take-off opening (T53-160B)
19	27 082 H	PLATE, reverse idler gear and countershaft lock (4501)	48		WASHER, 3/8" lock (6)
20		SCREW, 3/8 x 3/4" hex-hd cap	49		SCREW, 3/8 x 3/4" hex-hd cap (6)
21		WASHER, 3/8" lock	50	111 08Z R1	GASKET, power take-off opening cover (T9-150)
22		SCREW, 3/8 x 1" hex-hd cap (4)			
23		WASHER, 3/8" lock (5)	51	143 968	PLUG. 3/4" sq-soc pipe (cd-pltd)
24	321 811 R1	RETAINER, mainshaft rear bearing (T9-7%)	52	59 586 R91	OIL SEAL, mainshaft
25	27 116 HA	GASKET, mainshaft rear bearing retainer (T9-145-1/2)	53		SCREW, 3/8 x 2" hex-hd cap
26	5T 200	BEARING, mainshaft rear		115 617 H	BOLT, 3/8 x 3/4" (X775) (3)
27	27 073 H	RING, mainshaft rear bearing snap (T8-7-1/2)		Z 750 059 R1	DECALCOMANIA, shifting diagram (not part of Transmission ASSEMBLY, 313 740 R91)
Z8	317 659 R1	CASE, transmission (T9-1TT)			SCREW, 1/2 x 1-1/4" hex-hd cap (6)
29	27 I 22 H	GASKET, control lever mounting (T9-115)			1/Z" lock WASHER (6)
30	27 071 H	RING, main drive gear bearing snap (inner) (T8-6-1/2)			4 + 7 (% S
31	27 009 H	BEARING, mainshaft pilot roller (X4044)			



GEAR, main drive (T9-16X)

BEARING, main drive gear

(TS-136)

(4495)

(T9-145)

WASHER, main drive gear oil retainer

RING, main drive gear bearing snap (outer)

GASKET, main drive gear bearing retainer

RETAINER, main drive goar bearing (T9-6H)

317 663 R1

27 089 H

27 086 H

27 110 H

317 662 R1

ST 201

32

34

35


37

-112-

### ATTACHMENTS

(Four Speed Sliding Gear) (Warner)

TRANSMISSION CONTROL HOUSING AND LEVER



AKF. NO.	I. H. PART Number	DESCRIPTION		
1	317 665 R1	HOUSING, control lever (TSG-148A)		
2		SCREW, 3/8 x 4-7/8" hex-hd cap		
3		WASHER, 3/8" lock (6)		
4	27 085 HA	PIN, control lever locating (4499A)		
5		SCREW, $3/8 \times 7/8$ " hex-hd cap (5)		
6	16 780 H	BALL, control lever hand (C37J-50A)		
7	82 717 R11	LEVER, control (AC9A-2Y)		
8	72 218 H	CAP, control lever (4496K)		
9	72 219 H	WASHER, control lever spring (4497)		
10	27 098 HA	SPRING, control lever (4498B)		
11	83 780 R1	BALL, fulgrum (C8-2-1/2C)		
12	113 163	PIN, fulcrum ball		
13	27 119 HA	RAIL, shift (first and second) (T&A-21)		
14	16 012 R1	BALL, 3/8" shift bar poppet (3)		
<b>}</b> 5	23 074 H	SPRING, shift bar poppet (TSB-44) (3)		

-112-

#### ATTACHMENTS

			_
MEF.	I. H. FART	ロモキモ ホーナー・ウン	
NO.	NUMBER	- Line -	_

TRANSMISSION - Continued (Four Speed Sliding Gear) (Warner)

TRANSMISSION CONTROL HOUSING AND LEVER - Continued

16	27 096 H	PLUNGER, shift bar interlock (T8-86) (2)
17	27 104 H	PIN, shift bar interlock plunger (4446-A)
18	27 105 H	STOP, shift bar interlock plunger pin (4447)
19	27 120 HAX	RAIL w/PIN, shift (third and direct) (T8A-20)
20	27. 121 HA	RAIL, reverse shift (T8-99A)
21	62 894 HB	END, reverse shift rail (T9A-37A)
22		NUT. 1/4NF sit
23		FIN, 1/16 x 1/2" cotter
24	23 079 H	SCREW, shift fork set (4418) (3)
25	6Z 892 HC	SPRING, reverse shift end plunger (T9A-39)
26	62 893 H	PLUNCER, reverse shift and (T98-40)
27	27 111 HA	FORK, shift (third and direct) (T8-23)
28	27 112 HA	FORK, shift (first and second) (TS-24)
29	103 892	PLUG, expansion (3)
	14 189 H	PLUG, speedometer opening (not part of Transmission ASSEMBLY, 313 740 R91)

NOV-27-2001 17:24

SS/L

650 852 5865

P.08/13

-113-

MEMORANDA

MEMORANDA

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

ur Speed Synchromesh) (Warner)

RANSMISSION


-114-**ATTACHMENTS** 

-114-**ATTACHMENTS** 

TRANSMISSION - CONTINUED

(Four Speed Synchromesh) (Warner)

TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS - Continued



NET. NO.	I. H. PART NUMBER	DESCRIPTION	HEF.	I, H, PART Number	DESCRIPTION 42.
	313 739 R91	TRANSMISSION ASSEMBLY (with CONTROL HOUSING) (AS-105-T98A) (part of ATTACHMENT, 312 839 R91)	9	1601Z R1	BALL, 3/8" low and second speed synchronizer (3)
		3/8 x 1-1/8" hex-hd cap SCREW (12) 3/8" lock WASHER (12)	10	71 847 RI	RING, second speed synchronizer blocking (T98-83)
2	59 585 R1	NUT, mainshaft (J1-50)	1 1	154 075 R1	GEAR, mainshaft second speed (T98A-31)
3	317 627 R1	SPACER, speedometer drive gear (T98-75-1/2)	12	82 079 R1	SPACER, mainshaft second speed gear (T98-65)
4	77 945 R1	RING, mainshaft snap (4745E)			• • •
5	ST 236	BEARING, main drive gear	13	71 834 RZ	SHAFT, main (T98-ZA)
6	71 843 R1	RING, mainshaft second speed gear snap (4745 D) (3)	14	71 846 R1	ROLLER, mainshaft second speed bearing (4741) (34)
7	82 092 R91	SYNCHRONIZER, low and second speed (AT98-80)	15	71 842 R1	WASHER, mainshaft second speed gear thrust (T98-63)
	73 298 Rt	SPRING, low and second speed synchronizer (T87D-42) (3)	16	154 076 R!I	GEAR w/BUSHING, 72 202 R1, mainshaft third speed (AT98A-11)

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

I, M. PART

-115-

#### **ATTACHMENTS**

DESCRIPTION

I. H. PART NUMBER

REF. NO.

#### -115-**ATTACHMENTS**

DESCRIPTION

TRANSMISSION - CONTINUED (Four Speed Synchromesh) (Warner) TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS - Continued				TRANSMISSION - CONTINUED (Four Speed Snychromesh) (Warner)  TRANSMISSION CASE, GEARS, CLUTCH HOUSING AND RELATED PARTS - Continued		
	17	/   \$40 Ki	blocking (T87D-14) (2)	50	103 565	PIN, reverse shifting arm screw
	18	71 835 R91	SYNCHRONIZER, mainshaft third and high speed clutch (IAT870-2-1/2C)	51	147 921 R1	PIN, reverse shifting arm pivot (T98-55N)
			RING, third and high speed synchronizer hub	52	71 855 R1	GASKET, control lever housing (T98-115)
	19	71 841 R1	snap (4747)	53	80 224 R11	RETAINER W/SLEEVE, 26 905 H (AT98-7A)
	Z0	91 092 R1	RING, reverse idler gear snap (4757) (2)	54	30 221 1111	WASHER 3/8" external lock 151
	21	91 091 R1	WASHER, reverse idler gear thrust (T98-84A)	55		SCREW, 3/8 = 1" hex-hd cap (3
	22	91 094 R1	(2) ROLLER, reverse idler goar bearing (F1-42)	56 57	59 586 R91	OIL SEAL, mainshaft SCREW, 3/8 x 2" hex-hd cap
			(74)	58	80 225 R1	GASKET, mainshaft rear bearing retainer, .010" thick (T98-145-1/2)
	Z3	91 089 R11	GEAR ASSEMBLY, reverse idler (AT-98-10A)		80 ZZ6 R1 80 ZZ7 R1	015" thick (T98-145-1/2A)
	24 25	91 095 R1 91 093 R1	SLEEVE, reverse idler gear bearing (T98-85A) SPACER, reverse idler gear bearing (T98-87A)		80 228 R1	.025" thick (T98-145-1/2C)
	26	59 423 R1	SMAFT, reverse idler gear (T97-35)	60	103 881	PLUG, 3/4" sq-hd pipe (Steel) (optional with 219 301) (2)
	27	317 628 R1	PLATE, countershaft reverse idler gear shift lock (T97-48)	60	219 301	PLUG, 3/4" sq-hd pipe (malleable from) (optional with 103 881) (2)
	28		SCREW, 3/8 x 3/4" hex-hd cap (2) 3/8" lock WASHER (2)	61 62		SCREW, 3/8 x 5/8" hex-hd cap (6) WASHER, 3/8" external lock (6)
	<b>Z</b> 9	71 860 R1	COUNTERSHAFT (T98-3)	63 64	23 045 H 111 082 R1	COVER, power take-off opening (T53-160B) GASKET, power take-off opening cover (T9-150)
	30	71 859 R1	WASHER, countershaft rear thrust (outer) (T98-33)	4-	01 <b>0</b> 404 P.I	CASE, transmission (T98-1N)
	31	(54 078 R1	WASHER, countershaft rear thrust (inner) (T98A-32)	65	317 626 RI	WASHER, 5/16" external lock (4)
	32	59 572 R1	WASHER, countershaft bearing spacer (T97-29) (6)	69 70		SCREW. 5/16 x 7/8" hex-hd cap (4) RETAINER, main drive gear bearing (T98-on)
	33	59 574 R1	ROLLER, countershaft gear bearing (T97-166) (88)	71	317 631 R1	•••
	34	95 363 R1	SPACER, countershaft gear bearing (T98-48A)	7 Z	147 920 R1	OIL SEAL, pivot pin (T89-108)
	35	154 077 R1	GEAR, countershaft (T98A-8)	73	317 633 R1	HOUSING, clutch (T98-1-1/2C)
	36	71 85 <b>7</b> R1	WASHER, countershaft thrust (T98-30)	74	317 634 R1	COVER, hand hole (T9-74) 5/16 x 5/8" fil-hd 5CREW (2) 5/16" lock WASHER (2)
	37	91 090 R1	SHOE, reverse shifting (T98-51A)	75	317 635 RI	SHAFT, throwout (short) (T9-310)
	38	1 <b>47</b> 922 R1	ARM, reverse shifting (T98-54N)	76	317 63 <b>7</b> R1	YOKE, throwout (T64J-360D)
	39	82 084 RI	WASHER, "C" shifting shoe (4747A)	77	317 638 RI	SCREW, lock (5573) (2)
	40		GASKET, main drive gear bearing retainer .009" thick (T98-145)	78	317 636 R1	SHAFT, throwout (long) (T9A-3FLM)
		77 946 R1 77 947 R1 77 948 R1	.0135" thick (T98-145A) .018" thick (T98-145B) .0225" thick (T98-145C)	79	2 <b>71 285</b>	FITTING, 1/8 x 90° lubrication (Alemite
	42	77 949 R1	RING, drive gear bearing snap (small)	79	109 462	of Transmission ASSEMBLY, 313 739 R.91) FITTING, 1/8 x 90 lubrication (Lincoln 5400) (optional with 271 285) (2) (not part of Transmission ASSEMBLY, 313 739 R.91)
		137 245 R1 137 246 R1 137 247 R1	.120" thick (4816A) .123" thick (4816B) .127" thick (4816G)		115 617 H 72 202 R1	BOLT, 3/8 x 3/4" (X775) (2) BUSHING, mainshaft third speed gear (T98-19)
	43	77 945 R1	RING, main drive gear bearing snap (large) (4745 E)		2 750 061 R1	DECALCOMANIA, shifting diagram (not part of Transmission ASSEMBLY, 313 739 R91)
	44	82 076 R1	RING, main drive gear bearing spacer (4774)		82 082 Rt	RING, shift plate retaining (4773)
	45	ST 236	BEARING, main drive gear ball			SCREW. 1/2 x 1-1/4" hex-hd cap (6)
			13 (2000)			1/2" lock WASHER (6)

GEAR, main drive (T98A-16G)

80 175 Ri

154 074 RI

47

BAFFLE, main drive gear oil (T90A-136A)

26 905 H

SCREW. 1/2 x 1-1/4" hex-hd cap (6) 1/2" lock WASHER (6)

SLEEVE, speedometer drive gear (T54A-172)


. 55..

#### Ů

## ATTACHMENTS

ANSMISSION our Speed Synchromesh) (Warner)

TRANSMISSION CONTROL HOUSING AND LEVER



NEP. NO.	I, M, PART NUMBER	DESCRIPTION
ı	71 877 RI	HOUSING, control lever (T98-148A)
z	82 075 R91	BREATHER (T94-95)
3		NOT USED
4	103 736	PIN, control housing
5	103 892	PLUG, expansion (6)
6	59 412 R1	PIN, shift bar interlock plunger (T97-86)
7	71 879 R!	RAIL, third and direct speed shift (T98-40)
8	2 <b>7</b> 096 H	PLUNGER, shift bar interlock (T8-86) (2)
9	16 0!2 R1	BALL, 3/8" shift bar poppet (3)
10	23 074 H	SPRING, shift bar poppet (T85-42) (3)
11	71 884 R1	RAIL, reverse speed shaft (T98-99)
	8Z 090 RI	END, reverse speed shift (T98-37)

### ÄTTÄCHMENTS

REF.	I. H. PART	DESCRIPTION	
NO,	NUMBER	- MITT	

TRANSMISSION - Continued (Four Speed Synchromesh) (Warner)

#### TRANSMISSION CONTROL HOUSING AND LEVER - Continued

13	82 083 R1	WASHER, "C" reverse speed plunger (4/47B)
14	23 079 H	SCREW, shift fork set (4418) (4)
15	16 008 R1	BALL, 1/4" reverse speed shift and plunger; poppet
16	8Z 077 R1	SPRING, reverse speed shift end plunger poppet (4750)
17	: 	PIN, 1/8 x l" cotter
18:	62 892 HC	SPRING, reverse speed shift end plunger (T9A-39)
19	82 086 R1	PLUNGER, reverse speed shift end (T98-40).
20	71 881 R1	FORK, third and direct speed shift (T98-23)
21	71 883 R1	END, low and second speed shift (T98-38)
22	71 880 R1	RAIL, low and second speed shift (T98-21)
23	71,882 R1	FORK, low and second speed shift (T98-24)
24	16 780 H	BALL, control lever (C37J-50A)
25	317 632 R1	LEVER, control
z6	82 078 R1	CAP, control housing (4496L)
27	92 192 RI	WASHER, control lever spring (4497H)
28	27 098 HA	5PRING, control lever (4498 HA)
29		WASHER, 3/8" lock (6)
30		SCREW. $3/8 \times 7/8$ " hex-hd cap (6)
	83 780 R1	BALL, fulcrum (C82-1/2C)
	14 189 H	PLUG, speedometer opening (not part of transmission ASSEMBLY, 313 739 R91)

-116A-

-116A-SUPPLEMENT TO NUMERICAL INDEX

GUDDI EM		A- JMERICAL INDEX		SUPPLE	EMENT TO NUM	ERICAL INDEX	
PART	PAGE	PART Humber	PAGE	PART MJSTOCK	PAGE	PART Number	PAGE
	ì	PLEMENT TO NUME. Refer to this list first be found refer to Num	for part num	her required. If p	ert cannot	Ξ.	
12 215 D     481 D     251 480 R1     268 169 R1     276 835 R91     306 913 R91     309 592 R91     367 651 R21     367 653 R2     367 669 R1     367 739 R2     367 741 R1     368 938 R92     371 088 R93     372 709 R91     371 088 R93     372 708 R2     374 794 R91     376 590 R91     378 878 R1     378 878 R1     393 405 C91     612 321 C91     612 321 C91	51150085511110101851011011188111	be found refer to Num	erical index				

NOV-27-2001 17:26 SS/L 650 852 5865 P.13/13

-116B-MEMORANDA -116B -MEMORANDA

PRINTED IN UNITED STATES OF AMERICA
(Rev. No. 3 4-'67)

PRINTED IN UNITED STATES OF AMERICA

or green and a

 $||e^{-i\omega_{1}}e^{-i\omega_{2}}e^{-i\omega_{1}}e^{-i\omega_{2}}||_{L^{2}(\mathbb{R}^{N})}\leq 2\pi e^{-i\omega_{1}}e^{-i\omega_{2}}e^{-$ 

1. <u>85</u>. %

-117-

-117-	
NUMERIÇAL,	INDEX

	NUMERICAL	L INDEX			NUMERIC	AL, INDEX	
FART Number	PAGÉ	PART Number	PAGÉ	PART Number	PAGE	PART NUMBER	PAG
12442330186 A HHHHHHHDDDDCCC 12442330018661123330027366380273660000000000000000000000000000000000	1011111941758131111111111111111111111111111111111	00691 H H H H H H H H H H H H H H H H H H H	111 111 111 111 111 111 111 111 111 11	DDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDD	732722222222222229097342N22222222222222222222222222222222222	56 4430 DD A1 56 56 56 56 56 56 56 56 56 56 56 56 56	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

-118-



-118-NUMERICAL INDEX

PRINTED IN UNITED STATES OF AMERICA

1		NUMERICAL	INDEX PART	PAGE	PART NUMBER	NUMERICA **Ag#	L INDEX	PAGE
	699 6670 7777 777 777 777 777 777 777 777 7	4283844371828989116111717171717171717171717171717171717	82 076 RR1 82 0778 RR1 82 0778 RR1 82 0778 RR1 82 0778 RR1 82 078 RR1 82 078 RR1 82 078 RR1 82 086 RR1 82 089 RR1 82 089 RR1 82 089 RR1 82 089 RR1 82 089 RR1 82 089 RR1 82 82 82 82 82 82 82 82 82 82 82 82 82 8	11566456566462488872648882444444444455555555518830844447772157610889415	121 131 131 131 131 131 131 131 131 131	677777555578445527627777756838995366366446559977778805738157111111111111111111111111111111111	RR11121 1111 1111 1111 1111 1111 1111 1	10078385785796734567858579558981453357133571353571357135571355715571

\_8\_

-119-

-119-

NUMERICAL INDEX	71 31	304 585 R11	PA-9E
266 681 R1 90 273 017 R91 84 277 366 R1 276 682 R1 266 682 R1 90 273 018 R91 92 90 277 366 R2 277 366 R2 277 366 R2 277 366 R91 92 273 020 R91 97 277 368 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 366 R2 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 277 370 R91 87 278 277 R1 87 278 271 R1 87 278 271 R1 87 278 271 R1 266 694 R1 87 273 212 R1 90 278 267 R1 266 696 R1 87 273 212 R1 90 278 266 R1 87 273 215 R91 91 278 266 R1 86 278 278 278 278 278 278 278 278 278 278	31		
268 865 R91 91 277 169 R1 23 304 539 R1 268 866 R1 85 277 170 R1 23 304 539 R1 268 866 R1 87 277 195 R91 30 304 540 R1 268 866 R1 91 277 196 R91 30 304 540 R1 268 866 R1 93 277 197 R1 30 304 540 R1 268 869 R1 85 277 198 R1 30 304 541 R1 268 958 R91 269 103 R91 55 277 350 R1 30 304 543 R11 269 103 R91 58 277 351 R1 30 304 543 R11 269 103 R91 58 277 352 R1 30 304 548 R12 269 103 R91 60 277 353 R1 30 304 547 R1 269 103 R91 60 277 355 R1 30 304 576 R91 269 103 R91 80 277 355 R1 30 304 576 R91 269 103 R91 80 277 356 R1 30 304 576 R91 269 103 R91 80 277 356 R1 30 304 577 R91 269 103 R91 93 277 356 R1 30 304 577 R91 269 103 R91 93 277 358 R91 30 304 577 R91 269 103 R91 93 277 358 R91 30 304 578 R91 269 103 R91 93 277 358 R91 30 304 578 R91 269 103 R91 93 277 358 R91 30 304 578 R91 304 588 R91 277 066 R92 79 277 360 R1 31 304 588 R2 277 705 R91 14	31 31 31 31 31 31 31 31 31 31 31 31 31 3	304 586 R1 304 587 R1 304 587 R1 304 587 R1 304 596 R1 304 596 R1 304 696 R2 304 602 R2 304 603 R2 304 854 R2 304 854 R2 305 167 R2 305 167 R2 305 167 R2 305 187 R2 305 187 R2 305 187 R2 305 187 R2 305 188 R2 305 189 R2 305 192 R2 305 192 R2 305 193 R2	868081899599995899999999999999999999999999

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

(Rev. No. 2 1-67)

-120-



-120-NUMERICAL INDEX

370 137 R91 3395 320 138 R11 995 370 139 R1 388	320 138 R11 320 139 R1 320 140 R91 320 141 R11 320 149 R1 320 163 R91 320 165 R91 320 166 R91 320 273 R91 320 273 R91 321 004 R91 321 005 R1 321 005 R1 321 005 R91 321 005 R91 321 005 R91 321 005 R91 321 005 R91 321 005 R91 321 005 R91
115 320 140 R91 39 114 320 141 R11 320 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 149 R1 39 115 321 005 R1 39 115 321 052 R91 39 111 321 054 R91 39 111 321 054 R91 39 111 321 054 R91 39 111	321 057 R91 99 321 481 R1 85 321 481 R1 87

-121-

	-121 NUMERICA			ů.	-121 NUMERICA		
PART NUMBER	PAGE	PART Humper	PAGE	PAST MUMBER	PAGE	PART NUMBER	FAGE
336 113 328 3344 3346 3346 56318 RRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRRR	3339133357140987714074443391347437731303235715713913913930389767677776588856822889975768910699988677339766868689988689856856858687766666669	349 148 R1 349 148 R1 349 148 R1 349 364 R1 351 588 R1 351 959 R91 352 221 R1 352 221 R1 352 227 R1 352 27 R1 353 901 R1 354 R1 355 901 R1 357 R1 357 R1 358 R1 359 R	500076031255776757555555555923793557655517620999998888899085796577894691	RI 367 191 R1 367 192 R1 367 192 R1 367 2259 R1 367 2259 R1 367 2259 R2 367 2258 R8991 367 2250 R8991 367 2260 R8991 367 22712 R8991 367 22712 R8991 367 22712 R8991 367 72 2288 R8991 367 72 2288 R8991 367 72 2288 R891 367 72 2288 R891 367 7367 7367 7367 7367 7367 7367 7367	91777177668444444445555555555558989112222289898989888889000000008111002210009	836 8 144 8 8 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	10

PRINTED IN UNITED STATES OF AMERICA

PRINTED IN UNITED STATES OF AMERICA

(Rev. No. 2 1-67)

500

**9**Ü**s** 

-122-NUMERICAL INDEX



- 122-NUMERICAL INDEX

371 097 R11 371 098 R1 371 100 R91 371 100 R91 371 102 R1 371 105 R1 371 105 R1 371 105 R1 371 215 R1 371 215 R1 371 226 R91 371 237 R11 371 238 R1 371 238 R2 371 829 R92 371 829 R92 371 829 R92 371 829 R92 371 833 R92 372 829 R92 372 443 R91 372 444 R91 372 444 R91 372 444 R91 372 444 R91 372 498 R1 372 498 R1 372 498 R1 372 498 R1 372 568 R1 372 569 R91 372 615 R94 372 615 R94 372 723 R92	PAGE	PART Number			1		
371 098 R1 371 100 R91 371 100 R91 371 102 R1 371 103 R1 371 105 R1 371 106 R2 371 215 R1 371 236 R91 371 237 R11 371 238 R1 371 237 R11 371 238 R2 371 633 R91 371 699 R2 371 699 R2 371 829 R92 371 829 R92 371 829 R92 371 839 R92 371 839 R92 372 084 R92 372 084 R91 372 443 R91 372 443 R91 372 443 R91 372 498 R1 372 498 R1 372 498 R1 372 498 R1 372 567 R91 372 569 R91 372 569 R91 372 699 R91 372 708 R93 372 708 R93 372 708 R12			PAGE	FART NUMBER	PAGE	PART NUMBER	FAGE
372 770 R92 372 770 R92 372 867 R92 372 867 R92 372 868 R11 372 951 R91 373 173 R1 373 189 R1 373 189 R1 373 331 R91 373 423 R21 373 939 R1 373 925 R1 374 325 R1 374 326 R1 374 327 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 328 R1 374 548 R91 376 666 R91 376 666 R91 376 666 R91 376 667 R91 376 667 R91	18804444445860024441888889542444671766225555119895669567777801971111010898989	11111111111111111111111111111111111111	895555589129999676679999276445555555557111111112112112117777008895589898	91 111 111 1111 122	120 AA 49977777777463363677667766689813138342668901909179101917777177 10000036776677668898131383426689917991991917777177 110000336776677668898131383426689019919910191777177	R1 91 91 934 8 91 995 995 995 995 995 995 995 995 995	2918891434X000007327790069091907232317022323232333109190900091903790723919445445445445454555555555555555555555

-123-



98	-12 NUMERICA				-123- NUMERICAL	INDEX	
PART	PAGE	PART Number	PAGE	PART NUMBER	PAGE	PART NUMBER	<b>FAGE</b>
1 911 324 1 912 324 1 912 3008 1 912 176 1 92 177 1 93 1	10919232397000919190901323939006299777777771107323323777779177727776207267	1 946 926 1 948 338 1 949 553 1 950 069 1 950 070 1 950 306 1 950 307 1 950 307 1 953 041 1 953 872 1 953 1275 1 188 R1 2 751 188 R1 2 751 188 R1 2 751 1534 R1 2 751 2 445 2 752 447 2 752 445 2 752 445	116676667770267769115227222222222222222222222222222222222				

-124-

NUMERICAL INDEX



-124-NUMERICAL INDEX

		NUMERICAL INDEX				NUMERIC	AL INDEX		
	PART Number	PAGE	PART Number	PAGE	PART	PAGE	PART Humber	PAGE 6	
# #									
				}					
					4 T			· · · · · · · · · · · · · · · · · · ·	
_								ie v Constant	
						•	:	12114	
					'				
						ļ			
								_	
†#									
į									
						;			
								the state of the state of	
:								The second secon	
<b>!</b> —			STATES OF AMERICA		<u> </u>		STATES OF AMERICA		

# FOR YOUR PROTECTION

OEQ